

**JLR-8600**

**NWZ-1650**

---

GPS NAVIGATOR

INSTRUCTION  
MANUAL

## Foreword

Thank you for purchasing the JRC GPS Navigator JLR-8600.

This equipment is a high-performance navigation equipment consisting of a GPS sensor and navigator, can retrieve the position data using the GPS sensor to display various navigation information on the display.

- Thoroughly read this instruction manual before operating the equipment.
- Keep this manual nearby the equipment to allow ready access to it if necessary. It may provide valuable information on how to deal with a given situation that may arise during the operation.

## Before Commencing the Operation

### Symbols

Several symbols are used in this manual to ensure safety and proper operation of the equipment and to avoid possible human injury or property damage. These symbols and their meanings are shown below. Please read and understand these symbols before proceeding to read this manual.



### WARNING

Instructions shown with this symbol represent what can cause death or serious injury if not observed.



### CAUTION

Instructions shown with this symbol represent what may cause injury or property damage if not observed.

### Examples of the Symbols



The symbols shown in the  $\Delta$  mark represent those that require attention (including potential dangers and warnings). A depiction of the type of caution is shown inside the symbol (the left symbol indicates a general caution).



The symbols shown in the  $\ominus$  mark represent actions which are prohibited. A depiction of the type of prohibited action is shown inside the symbol (the left symbol indicates that disassembly is prohibited).



The  $\bullet$  symbol indicates required actions. A depiction of the type of required action is shown inside the symbol (the left symbol indicates that the power plug must be disconnected from the outlet).

## Precautions Upon the Operation

### **WARNING**



Do not disassemble or modify the equipment. Doing so may result in fire, electric shock, or equipment failure.



Do not allow the display to become wet. Doing so may result in fire, electric shock, or equipment failure.



Operate the equipment only at the indicated voltage. Failure to do so may result in fire, electric shock, or equipment failure.



Install this unit at least 1 m away from any magnetic compasses. Installation near a magnetic compass may result in interference with the magnetic compass, and may result in an accident.



Do not perform internal inspections or modifications of the equipment. Inspection or modification by unauthorized personnel may result in fire, electric shock, or equipment failure. Please consult with JRC or an affiliate to perform internal inspections or repair.



When disposing of the used lithium battery, place insulating tape over the battery terminals, or otherwise insulate the battery. Failure to do so may result in heating, explosion, or fire due to a shorted battery.



## CAUTION



This equipment is not designed to automatically make judgments on the position data. The navigation information including the position data needs to be judged by the user himself.



Do not use the equipment in the environment other than those provided in the specification. Doing so may result in equipment failure, malfunction, or injury.



Do not install the display unit in the location where it may come in contact with water, oil, or chemicals. Doing so may result in equipment failure, malfunction, or injury.



Do not install the equipment in the place subject to vibration or shock. Doing so may result in the equipment falling or collapsing, resulting in equipment failure or injury.



Do not place any item on the top of the equipment. Doing so may result in equipment failure, malfunction, or injury.



Please consult with JRC or an affiliate to perform installation. Installation by unauthorized personnel may result in malfunction.



Use only the specified battery. Failure to do so may result in battery leakage or rupture, resulting in fire, injury, or equipment failure.



Do not use benzine, alcohol or thinner when caring this equipment. Doing so may result in removing the paint or changing of properties. Wipe off the grime lightly with a dry soft cloth.



Use the indicated screws when installing the display unit to a stable wooden surface. Failure to do so may result in the display unit falling over, causing injury or property damage.



Use only the specified fuse. Failure to do so may result in fire or equipment failure.



Use only the specified battery. Failure to do so may result in equipment failure or malfunction.

# CAUTION



When connecting the cable attached to the equipment, do not bend it acutely, twist it, or impart excessive force. Doing so sometimes causes cracks or damage to the coating, resulting in fire or electrocution.



Do not install the sensor where there is excessive vibration. Vibration may cause sensor failure.



Do not paint the sensor. Doing so may result in reception problems.



Do not install the sensor where temperature exceeds 55 degrees Celsius and there is covered with exhaust gas from funnel. Doing so may result in flood and cause sensor failure.



The junction box rubber gaskets (25 f Gland side) fit  $\phi$  10mm – 20mm cables.



Install the sensor where there are no obstacles, in order to ensure that GPS signals can be directly received from satellites without interference or reflection of signals from surrounding objects. Whenever possible, select a place with the following characteristics.

1. **An open space, which allows uniform reception of satellite signals.**
2. **Far away from any high power transmission antennas.**
3. **Outside radar beams.**
4. **Away from the INMARSAT antenna by at least 5 meters and outside the INMARSAT beam.**
5. **Away from the antenna of a VHF transmitter and a direction finder by at least 3 meters.**
6. **Away from a Magnetic Compass by at least 1 meter.**
7. **3 meters or more away from amateur radio antennas.**

If it is difficult to find an ideal site, select a place temporarily and install the equipment. Conduct a test to make sure that the proper performance can be obtained and then fix the equipment in position. If it is installed at an improper place, reception accuracy may be impaired.



If occurs bad positioning of such as satellite can not be received, please execute the master reset of sensor.



There are cases when time lags in the gps navigator and gps compass. This is not a malfunction due to the delay in the internal processing.



There are cases when time lags in the main display unit and sub display unit. This is not a malfunction due to the delay in the internal processing.

## Appearance of the Equipment

### ●NWZ-1650 Display Unit



### ●NDC-4100 Processor Unit



### ●JLR-4350 GPS Sensor Unit



## Terminology

Term	Meaning (Descriptions)
2D (2 dimension)	Positioning with antenna elevation height in addition to satellite data.
3D (3 dimension)	The three dimensional position fix, 4 or more satellites required.
Active route	Route that is currently used by a ship
Anchor alert	This alert monitors that the own ship is the preset distance or more away from the waypoint.
Arrival alert	This alert informs that the own ship has traveled the preset distance, approaching the waypoint.
Beacon information	Beacon data which is broadcast by message type 16.
BeiDou	BeiDou is a satellite positioning system that is managed by China.
Boundary alert	This alert informs that the own ship has got into the preset route.
CCRP	Abbreviation of Consistent Common Reference Point. Reference position of the own ship.
CDI	Abbreviation of Course Deviation Indicator. This indicator shows information on the deviation from the scheduled route and on the direction into which the ship should be steered.
Checksum	An error detection method to check that the data has been correctly transmitted.
COG	Course Over Ground.
Course	Direction in which the ship is traveling, which is the bearing mainly displayed by the GPS.
CURRENT	Sea and ocean currents, expressed in speed and direction.
Data route	Ship route data that is stored in the memory of the equipment
Default gateway	Equipment connected externally from a constructed network.
DGPS	Abbreviation of Differential Global Positioning System. GPS satellite error data sent from a reference station whose position is accurately known is received via beacon from a beacon station, improving positioning accuracy.
DISP-DPU	The main circuitry of display unit.
FRAM	Nonvolatile memory using a ferroelectric substance.
Geodetic	Conditions for expressing position via latitude and longitude.
GPS Satellite (GPS)	Abbreviation of Global Positioning System. Refers to satellites launched for navigational support of military vessels managed by the United States Department of Defense.
GLONASS	GLONASS is a satellite positioning system that is managed by Russia.
HDOP	Abbreviation of Horizontal Dilution of Precision. Indicates accuracy of positioning. The smaller the number, the higher the accuracy. If GPS satellites are unevenly distributed, this number will grow. If GPS satellites are evenly distributed, this number will be smaller.
IEC	IEC is the abbreviation of International Electrotechnical Commission. It is an international standard governing electrical and electronic technologies.
IPXX	IPXX is Degrees of protection provided by enclosures (IP Code)



	1st numeral: Against ingress of solid foreign objects (0 – 6) 2nd numeral: Against ingress of water with harmful effects (0 - 8). (IPX4: splash-proof, IPX6: waterproof)
IP address	ID number assigned to equipment on a constructed network.
LAN	Abbreviation of Local Area Network. A network is constructed for transmitting and receiving data.
LCD Unit (LCD)	Liquid Crystal Display Unit.
Log Pulse	Contact output signal, output in 1 pulse per nm. Expressed in units of "p/nm". mi/h Unit of ship speed.
Loran time difference display	Method for expressing the present position with loran system time difference. (The method is for operators who have a background in loran navigation.)
MAC address	ID number assigned to LAN IC
Multi GNSS	Positioning using multiple satellite systems at the same time.
Master reset	This function changes the settings of the display unit and GPS sensor back to the factory settings. The function clears all the data.
Multipath Wave	Waves received from multiple directions due to reflection or refraction of an initial wave by obstacles.
Mutual monitoring mode	When two navigators are installed, they monitor their position fixing status each other by using this function.
NMEA0183 (NMEA)	Abbreviation of National Marine Electrical Association 0183. International standard for naval equipment transmission established by the National Marine Electrical Association.
QZSS	QZSS is a Quasi-zenith satellite system that is managed by Japan and complements GPS.
Positioning	Use of GPS or DGPS receiving functions to determine the current position of a ship.
RAIM Accuracy Standard (RAIM)	Abbreviation of Receiver Autonomous Integrity Monitoring. This system automatically detects failed satellites and deselects their positioning data from calculations. Including data from failed satellites will result in a decrease in positioning accuracy; the RAIM accuracy standard indicates the accuracy degradation base for removal of failed satellites from positioning calculations.
Ranging	Positioning with the use of SBAS satellite in addition to GPS satellite.
Reception Level	GPS signal reception level.
Route plan	Plan registered with multiple waypoints in the navigation order
RS-232C	Serial data transmission standard. It is unbalanced, and hence can only be used for short distance transmission.
RS-422	Balanced serial transmission standard.
SBAS	Abbreviation of Satellite Based Augmentation System. It is a blanket term for wide scale GPS support systems using fixed position satellites which send GPS error correction data over a wide range.
SBAS Search	SBAS reception mode (manual / automatic).

Shared route	Function that uses the same route as other functions such as ECDIS do. The route can be updated automatically by sharing the active route.
Smoothing	Function for averaging over a specified number of seconds.
SOG	Speed Over Ground, This is the ship's relative speed to the ground.
SPEED	The speed mainly measured by the GPS.
STW	Speed Through Water.
Subnet mask	Value for identifying the network address
Symbol information	Information of symbols displayed on the plotting screen. The information includes symbol positions, comments, etc.
TD	Abbreviation of Time Difference. Time difference from the master-station signal of the loran system to the slave-station signal.
Message Type 0	SBAS satellite test broadcasting.
UTC	Abbreviation of Coordinated Universal Time.
XTD alert	This alert informs that the own ship has got out of the scheduled route by the preset distance or more.

# Index

Foreword .....	ii
Before Commencing the Operation .....	iii
Precautions Upon the Operation .....	iv
Appearance of the Equipment .....	vii
Terminology.....	viii
1.1 Functions.....	1-1
1.2 Features .....	1-1
1.3 Configuration .....	1-2
1.3.1 Standard Configuration.....	1-2
1.3.2 Option .....	1-3
1.4 Construction .....	1-4
1.5 System Diagram.....	1-14
Chapter 2 Name and Function of Each Unit.....	2-1
2.1 NWZ-1650 DISPLAY UNIT.....	2-1
2.2 JLR-4350 GPS Sensor.....	2-3
2.3 NDC-4100 Processor .....	2-3
Chapter 3 Display Screens.....	3-1
3.1 Display Screens .....	3-1
3.1.1 Switching display .....	3-1
3.1.2 Navigation information screen .....	3-1
3.1.3 Plotting screen 1 .....	3-5
3.1.4 Plotting screen 2 .....	3-5
3.1.5 Analogue screen.....	3-6
3.1.6 Highway screen .....	3-7
3.1.7 Satellite information screen .....	3-7
3.1.8 Waypoint information screen .....	3-8
3.1.9 Beacon text screen .....	3-8
3.1.10 Navigation aid screen .....	3-9
Chapter 4 Operation .....	4-1
4.1 Menu List.....	4-1
4.1.1 Main Menu .....	4-1
4.1.2 Function menu .....	4-7
4.2 Basic Operation.....	4-8
4.2.1 Turning on the power of the unit.....	4-8
4.2.2 Startup .....	4-8
4.2.3 Turning off the power of the unit .....	4-9
4.2.4 Adjusting the backlight.....	4-10
4.2.5 Menu operation.....	4-10
4.2.6 Alert and acknowledgment (ACK) .....	4-11
4.2.7 Screen operation .....	4-13
4.2.8 Inputting numeric values.....	4-13
4.2.9 Inputting comments .....	4-14
4.2.10 List operation .....	4-15
4.2.11 Entering a password in CODE INPUT .....	4-15
4.3 Setting Display .....	4-16
4.3.1 Setting a theme.....	4-16
4.3.2 Setting a beep tone.....	4-16
4.3.3 Setting reverse video display.....	4-16
4.3.4 Selecting a display screen .....	4-17
4.4 Registering Waypoints .....	4-18
4.4.1 Displaying a waypoint list.....	4-18
4.4.2 Registering waypoints.....	4-19
4.4.3 Editing waypoints.....	4-22
4.4.4 Copying waypoints.....	4-22
4.4.5 Deleting waypoints.....	4-23
4.5 Route Plan.....	4-24
4.5.1 Displaying a route list.....	4-24
4.5.2 Creating routes .....	4-25
4.5.3 Editing routes.....	4-27

4.5.4	Copying routes.....	4-28
4.5.5	Deleting routes.....	4-29
4.5.6	Sharing a route with another piece of equipment.....	4-31
4.5.7	Setting route initial values.....	4-32
4.6	Executing a Route.....	4-33
4.6.1	Executing a route by selecting from a route list.....	4-33
4.6.2	Selecting a waypoint/route by using the GOTO key.....	4-34
4.6.3	Ending a route.....	4-37
4.7	Event/Mark.....	4-38
4.7.1	Displaying an event/mark list.....	4-38
4.7.2	Registering events.....	4-38
4.7.3	Registering marks.....	4-39
4.7.4	Editing events/marks.....	4-40
4.7.5	Deleting events/marks.....	4-40
4.8	Plotting Screen.....	4-42
4.8.1	Operating the cursor.....	4-42
4.8.2	Changing the cursor size.....	4-42
4.8.3	Moving a screen.....	4-43
4.8.4	Moving own ship to the centre of the screen.....	4-43
4.8.5	Screen Zoom In/Out.....	4-44
4.8.6	Changing North Up/Course Up.....	4-44
4.8.7	Displaying tracks.....	4-45
4.8.8	Displaying an own ship vector and a distance circle.....	4-46
4.8.9	Setting symbols to display/non-display.....	4-47
4.8.10	Displaying symbol information.....	4-47
4.8.11	Changing a background colour.....	4-48
4.9	Setting MOB.....	4-49
4.10	Setting Alerts.....	4-50
4.10.1	Setting alert/buzzer sounds.....	4-50
4.11	Alert List.....	4-56
4.11.1	Displaying alert history.....	4-56
4.11.2	Displaying the alert that is occurring.....	4-56
4.11.3	Displaying the alerts that occurred in LAN.....	4-57
4.12	Initial Settings of GNSS/Beacon/SBAS.....	4-58
4.12.1	Setting a positioning system.....	4-58
4.12.2	Setting a position fixing mode.....	4-59
4.12.3	Setting an elevation mask.....	4-59
4.12.4	Setting HDOP.....	4-60
4.12.5	Setting position, speed, and course smoothing.....	4-60
4.12.6	Setting RAIM.....	4-61
4.12.7	Setting a geodetic system.....	4-61
4.12.8	Initialising sensors.....	4-62
4.12.9	Setting a DGPS correction mode.....	4-62
4.12.10	Setting a beacon.....	4-64
4.12.11	Setting SBAS.....	4-65
4.12.12	Displaying a beacon station list.....	4-65
4.13	Configuring a System.....	4-66
4.13.1	Setting time difference/date display.....	4-66
4.13.2	Setting units.....	4-66
4.13.3	Setting magnetic correction.....	4-67
4.13.4	Setting LORAN A/C.....	4-67
4.13.5	Selecting a sensor.....	4-68
4.14	Printing.....	4-69
4.15	Setting a Language.....	4-69
4.16	Verifying Versions.....	4-69
4.17	Displaying a total trip distance.....	4-70
4.17.1	Starting/stopping measurement of a trip distance.....	4-70
4.17.2	Resetting a trip distance.....	4-70
4.17.3	Resetting a total trip distance.....	4-70
4.18	Measuring a trip distance.....	4-71
4.18.1	Starting/stopping measurement.....	4-71
4.18.2	Resetting a trip distance.....	4-71
4.19	Displaying external equipment information.....	4-72

4.20	Measuring a distance and an azimuth between two points .....	4-73
Chapter 5	Maintenance and Inspection.....	5-1
5.1	General Maintenance and Inspection .....	5-1
5.2	Alerts .....	5-2
5.3	Troubleshooting.....	5-5
5.4	Replacement Parts.....	5-7
5.4.1	Repair units.....	5-7
5.4.2	Regular replacement parts .....	5-7
Chapter 6	After-Sales Service .....	6-1
6.1	Warranty .....	6-1
6.2	Repair parts stocking Period .....	6-1
6.3	When Requesting Service.....	6-1
6.4	Recommended Checks Inspection .....	6-1
Chapter 7	Disposal .....	7-1
7.1	Disposal of Equipment .....	7-1
7.2	Disposal of Used Batteries .....	7-1
Chapter 8	Specification .....	8-1
8.1	NWZ-1650 DISPLAY UNIT .....	8-1
8.1.1	Basic .....	8-1
8.1.2	Environment.....	8-1
8.2	JLR-4350 GPS Sensor.....	8-1
8.2.1	Basic .....	8-1
8.2.2	Environment.....	8-2
8.3	NDC-4100 Processor Unit.....	8-2
8.3.1	Basic .....	8-2
8.3.2	Environment.....	8-2
8.3.3	Interface .....	8-3
Appendix	.....	Appendix-1
Appendix 1	List of Geodetic System .....	Appendix-1
Appendix 2	List of standard terms, units and abbreviations .....	Appendix-2
Appendix 3	List of Symbols.....	Appendix-7
Appendix 4	List of Default Setting Values .....	Appendix-8
Appendix 5	Data Format .....	Appendix-13
Appendix 6	Compass Safe Distance .....	Appendix-30



# Chapter 1 Equipment Overview

## 1.1 Functions

This equipment (JLR-8600) is a GPS navigator with a JLR-4350GPS sensor that is connected to the NWZ-1650 display unit and the NDC-4100 processing unit.

JLR-4350, which is a multi-GNSS receiver that is capable of receiving data from GPS as well as GLONASS or BeiDou, operates around-the-clock to measure positions with high accuracy anywhere in the world and in all weather conditions by using the GPS satellite and the GLONASS satellite, or the BeiDou satellite, and produces highly reliable positioning results. In addition, the GPS navigator can increase the accuracy of position fixing by receiving correction data from the DGPS beacon station and SBAS satellites.

## 1.2 Features

- Registration of up to 100 routes and 10000 waypoints
- Many output ports installed with the built-in buffer unit
- Enables sharing of a route with ECDIS by the mounted LAN
- High visibility 6.5-inchi large colour LCD
- Provided with many graphic display modes
- Mutual acknowledgment through a contact or ALR
- Improved operability by touch panel and abundant menus
- High reliability by the multi-GNSS receivers (GPS/GLONASS/BeiDou/QZSS/SBAS)
- Built-in RAIM function

## 1.3 Configuration

### 1.3.1 Standard Configuration

#### JLR-8600

No	Name	Model	Q'ty	Note
1	GPS Sensor Unit	JLR-4350	1	
1-1	Screw Adapter	MTV302007A	1	
1-2	Mounting Band	MPBP02520	1	Include 2 bands
1-3	Instruction manual	7ZPNA4695	1	English
1-4	Cable guard rubber	MPPK31462	1	
2	Processor Unit	NDC-4100	1	
2-1	Fuse	MF51NR 250V 5 MF51NR 250V 2	1	MF51NR 250V 5 :4 Fuses MF51NR 250V 2 :1 Fuses
3	Display Unit	NWZ-1650	1	
3-1	Model Identification Plate	MPNN50903	1	
3-2	Clamp Filter	5MBIR00009	1	
3-3	Flush mount kit	MPBX50891	1	
4	Display cable	CFQ-7540	1	LAN 15m for DISPLAY
5	Instruction manual	7ZPNA4699	1	7ZPNA4698(Japanese)/7ZPNA4699(English)

#### NWZ-1650

No	Name	Model	Q'ty	Note
1	Display Unit	NWZ-1650	1	Refer to JLR-8600(3~3-3)
2	Instruction manual	7ZPNA4699	1	7ZPNA4698(Japanese)/7ZPNA4699(English)




### 1.3.2 Option

No	Name	Model	Q'ty	Note
1	AC/DC Power supply unit	NBG-320	1	100/220VAC,24VDC Input 12VDC Output
2	AC/DC Power supply unit	NBD-577C	1	100/220VAC,24VDC Input 24VDC Output
3	AC/DC Power supply unit	NBD-904	1	100/220VAC,24VDC Input 24VDC Output
4	Data Power Cable	CFQ-7539	1	For Remote Display/ 8 cores 15m
5	Data power Cable	CFQ-7539-5	1	For Remote Display/ 8 cores 5m
6	Printer	DPU-414	1	
7	Printer	NKG-104	1	
8	Printer Cable	7ZCNA4109	1	Single end D-Sub/ 3m For DPU-414
9	Printer Cable	7ZCNA4112	1	Single end D-Sub9/ 10m For DPU-414
10	Printer Paper	6ZCAF00252A	1	For DPU-414
11	Printer Paper	7ZPJD0384	1	For NKG-104
12	Extension Cable	CFQ-9002	1	Dual end 6 cores connector 15m/ For Sensor
13	Extension Cable	CFQ-9000	1	Single end 6 cores 5m
14	Junction Box	NQE-7700A	1	6 terminals
15	Pole Mounting Kit	MPBP30608	1	For NQE-7700A
16	Coaxial Cable Kit	NQD-4414	1	Outdoor NQD-4410, Indoor NQD-4411
17	Select Switch	NCZ-777	1	Manual
18	Select Switch	NCZ-1537B	1	Automatic
19	Junction Box	CQD-10	1	16 terminals
20	Screw Adapter	MTV302007A	1	For Sensor
21	Mounting Band	MPBP02520	1	For Sensor
22	Output Buffer	NQA-4351	1	
23	Select Switch	NCZ-1663	1	For NQA-4351
24	External Dimmer unit	NCM-227	1	
25	Printer	RP-D10	1	Network printer
26	Power supply	NBG-980		Power supply unit for Network printer
27	Base kits	MPBX50347	1	with Tapping screws


# 1.4 Construction

## NWZ-1650 Display Unit



Unit: mm  
 Mass: Approximately 2kg  
 Color: Munsell N2.5  
 IP Grade: IP56


## NDC-4100 Processor Unit



Unit: mm  
 Mass: Approximately 2.2kg  
 Color: Munsell N2.5  
 IP Grade: IP22


**JLR-4350 GPS Sensor Unit**

---




Unit: mm  
Mass: Approximately 1.5kg (include 15m cable)  
Color: Munsell N9  
IP Grade: IP56 (IEC60945)

**NBD-904 Power Supply**




Unit: mm  
Mass : Approximately 2.6 kg

**NBD-577C Power Supply**




Unit: mm  
Mass: Approximately 5.4 kg



## NBG-320 Power Supply



Unit: mm  
Mass: Approximately 3.5 kg




## NQE-7700A Junction Box




Unit: mm  
Mass: Approximately 0.6 kg

**NQD-4414 Coaxial Cable Kit (NQD-4410)**






**NQD-4414 Coaxial Cable Kit (NQD-4411)**





**NQA-4351A Output Buffer**

DC Input (IEC61162-1 or NMEA)      Data Output (IEC61162-1 or NMEA)  
 Select signal





Data Output (IEC61162-1 or NMEA)      Data Output (IEC61162-1 or NMEA)

JUMPER SETTING for DC Input	
DC Input	JUMPER Terminal
DC 12V	TB1-IN  JUMPER ON 9-16V JUMPER Cable 0.25~2.5mm <sup>3</sup>
DC 24V	TB1-IN  JUMPER ON 9-16V Not connect



Unit: mm  
 Mass: 0.8 kg

**NCZ-777 Select Switch**



Unit: mm  
Mass: Approximately 0.5 kg


**NCZ-777 Select Switch (Flush Mounting)**




Unit: mm  
Mass: Approximately 0.7 kg



**NCZ-1663 Select Switch**




**NCZ-1663 Select Switch (Flush Mounting)**




Unit: mm  
 Mass: 0.2 kg

**NCZ-1537A/B Select Switch (Flush Mounting)**




Unit: mm  
 Mass: 0.55 kg

**CQD-10 Junction Box**




Unit: mm  
Mass: Approximately 1.1 kg


**NKG-104 Printer**



Unit: mm  
Mass: Approximately 2.1 kg




# 1.5 System Diagram



# Chapter 2 Name and Function of Each Unit

## 2.1 NWZ-1650 DISPLAY UNIT



### Touch panel

Key	Name	Function
	Alert	Displays the icon when an alert is issued. The icon changes according to the alert state.
	MOB	Displays a plotting screen and stores the Man OverBoard position.
	DIM UP	Increases the brightness.
	DIM DOWN	Reduces the brightness.
	Menu	Displays a menu. Displays a freeze indicator.
	Screen	Switches a main screen. Select from a main screen list.
	Function	Displays the operation menu on the main screen.
	Screen switch	Switches to a sub screen.
	Screen switch	Switches to a sub screen.

How to read the information on the display

**Geodetic positioning system**

**Status**  
See the status list for the contents of the status.

**Date and time display (note1)**

- U: UTC
- L: Local

In the 12-hour display, AM/PM is displayed.

**RAIM**  
Displays the currently set accuracy level.

- RAIM operating: 10m, 30m, 50m, 100m
- RAIM OFF : OFF

No faulty satellite: SAFE  
RAIM disabled: CAUTION  
Faulty satellite: UNSAFE

**note1**  
Although the displayed time may be out of sync with other display devices, it is because the data output timing is different and it is not a malfunction.


Status list

1	2	3	4	5	6	7	8	9	10	11	12	13


No	Icon	Description
1		Display unit number M: Main display unit R: Remote display unit
2		Received beacon information. Displayed when beacon information is received.
3		Magnetic correction Displayed when magnetic correction is set.
4		Waypoint update state Displays the waypoint update mode during route execution. AUTO: Automatic MAN: Manual
5		Route sharing Displayed when an Active route is shared. 1: Share 1, 2: Share 2, 3: Share 3, 4: Share 4, 5: Share 5
6		Installation mode Displayed in the installation setting mode.
7		MOB Displays when MOB is active.

No	Icon	Description
8		Demo mode Displayed in demo mode.
9		DGPS switched. Indicates that the mode has just changed from GPS to DGPS. This icon is cleared automatically five minutes after the switch.
10		HDOP alert Displayed when the value exceeded the setting value.
11		Sensor number using display AUTO: A sensor is selected automatically. MAN: A sensor is selected manually.
12		Positioning system Indicates the currently set positioning system. The positioning system that is set but cannot be used is displayed in yellow. GPS: GPS GLO: GLONASS QZSS: QZSS BDS: BeiDou
13		Position fixing status GNSS: GNSS position fixing GPS: GPS position fixing DGPS: Beacon DGPS position fixing SBAS: SBAS position fixing 2D: 2 dimensional position fixing 3D: 3 dimensional position fixing  No Fix: Non position fixing

## 2.2 JLR-4350 GPS Sensor



## 2.3 NDC-4100 Processor








# Chapter 3 Display Screens

## 3.1 Display Screens

### 3.1.1 Switching display

When the screen key **NAV** is tapped, a display screen list is displayed. Select a screen to be displayed from the list. The screen name is displayed on the screen key.


On the navigation information screen, the analogue screen, and the navigation support screen, a sub screen can be displayed by using **<** or **>**.



### 3.1.2 Navigation information screen

The navigation information screen displays the position, speed, and course of own ship. When a waypoint is available, the waypoint number and estimated time of arrival are also displayed.

A sub screen can be displayed by using **<** or **>**. The sub screen varies depending on the presence or absence of the waypoint.



Sub screen

a) If there are no waypoints

Sub Screen 1 (4 digit position screen)


Own ship's position  
(latitude and longitude)



Speed




Course



Sub Screen 2 (SOG and COG screen)


Own ship's position  
(latitude and longitude)



Speed



Course



b) If there are waypoints

Sub Screen 1 (4 digit position screen)

Number of the waypoint for which the ship is heading

Speed

Distance from the own ship's position to the waypoint

Estimated arrival time at the waypoint

Route number

Own ship's position (latitude and longitude)

Course

Bearing from the own ship's position to the waypoint

Estimated arrival time at the final waypoint

WPT	00019	ROUTE	008
POSN	35°00.1157' N 137°00.2680' E		
SOG	10.6 kn	COG	73.2°
DTG	9.4 NM	BRG	62.0°
ETA	APR 25, '18 10:53 (U)		
FINAL	ETA APR 25, '18 21:29 (U)		

Sub Screen 2 (Detail screen)

Number of the waypoint for which the ship is heading

Speed

Distance from the own ship's position to the waypoint

Speed of the destination component (See Memo.)

Deviation from the route and the steering direction  
L: Steered to the left  
R: Steered to the right

Own ship's position (latitude and longitude)

Course

Bearing from the present position to the waypoint

Speed of the COG component (See Memo.)

Average bearing (See Memo.)

Estimated arrival time at the waypoint

WPT	00019		
POSN	35°00.1473' N 137°00.3816' E		
SOG	8.5 kn	COG	69.5°
DTG	9.3 NM	BRG	61.9°
VTD	8.4 kn	VEAR	8.4 kn
XTD	0.02L NM	CMG	71.7°
ETA	APR 25, '18 11:05 (U)		

Sub Screen 3 (SOG and COG screen)

Number of the waypoint for which the ship is heading

Speed

Estimated arrival time at the waypoint

Own ship's position (latitude and longitude)

Course

WPT	00019		
POSN	35°00.1692' N 137°00.4543' E		
SOG	8.2 kn		
COG	69.2°		
ETA	APR 25, '18 11:07 (U)		

Memo

VTD (Speed of the destination component)

VTD (An acronym of "Velocity Toward Destination")

This is an index that shows how fast the boat is approaching toward the destination in the unit of knot when it is navigating at a given bearing angle and speed.

VEAR (Speed of the COG component)


VEAR (An acronym of "Velocity Along Route")

This is an index that shows how fast the vessel is approaching along the planned route in the unit of knot when it is navigating at a given course and speed.

CMG (Average bearing)

CMG (An acronym of "Course Made Good")


The bearing angle to the current position when viewed from the starting point.



### 3.1.3 Plotting screen 1

Plotting screen 1 displays the course, speed, bearing, and distance at the bottom of the screen.


The screen can be enhanced and reduced by using **ZOOM IN** and **ZOOM OUT**.



### 3.1.4 Plotting screen 2



Plotting screen 2 displays a plotting screen in full screen mode.



The display contents and the operation are the same as for the plotting screen 1.



### 3.1.5 Analogue screen

The analogue screen displays the course, waypoint bearing, and CDI in graphic format. During route execution, the screen displays the off-course and distance to the waypoint.


The ship speed meter can be displayed by using  or .



### 3.1.6 Highway screen

The highway screen displays the CDI, course, speed, bearing, and distance.


The screen can be enhanced or reduced by using **ZOOM IN** and **ZOOM OUT** respectively.



### 3.1.7 Satellite information screen



The satellite information screen displays the GNSS satellite and the beacon reception state.


The GNSS system can be switched by using **<** or **>**.



### 3.1.8 Waypoint information screen

The waypoint information screen displays waypoint information on the route.

The information can be switched to the next waypoint information by using  or .




The screenshot shows the following fields and their corresponding labels:

- Waypoint number:** W84
- n-th waypoint:** 001/007
- Total number of waypoints:** 001/007
- Comment on the waypoint:** WPT1
- Waypoint position:** LAT 35°04.5270'N, LON 137°10.3780'E
- Bearing from the own ship's position to the displayed waypoint:** BRG 252.6°
- Distance from the own ship's position to the displayed waypoint:** DTG 119.3NM
- Expected arrival time at the displayed waypoint:** ETA APR 26, '18 04:39 (U)
- Time required for reaching the displayed waypoint:** TTG 000 DAY 12 hr 16 min
- Width of the port and starboard-side route:** WIDTH PORT 1.00NM, STBD 1.00NM
- Arrival-circle radius:** ARRIVAL RAD 1.00NM
- Planned ship speed:** SPEED 10.00kn

Navigation buttons at the bottom include MENU, WPT INFO, FUNC, left arrow, right arrow, and DIM -.

### 3.1.9 Beacon text screen

The beacon text screen displays the beacon text information (Type 16) that is received by the beacon receiver.



The screenshot shows the following beacon information:



- Beacon information:** 001 JUL 12, '29 04:46 (U) 0445,honmoku,N,13m,, ,
- 002 JUL 12, '29 04:45 (U) 0445,kannonsaki,N E,10m,1014dhPa,,
- 003 JUL 12, '29 04:44 (U) 0440,hachijoshima, WSW,15m,, Wave7m,
- 004 JUL 12, '29 04:43 (U) 0440,umihotaru,NN W,15m,, ,

Navigation buttons at the bottom include MENU, BEACON TEXT, FUNC, and DIM -.




### 3.1.10 Navigation aid screen

The navigation aid screen calculates and displays navigation information including a 4-split screen, navigation measurement, trip distance, external equipment information, and distance between two points.

The screen can be switched by using  or .

Navigation assistance screen 1



W84	MPT AUTO	AUTO No.2	GPS	GPS 3DFIX
NAV ASSIST 1 QUADRANT				
COG	59.1°		SOG	11.6kn
CTS	62.0°		DTG	8.7NM
XTD	◀ 0.02NM ▶		TTG	000DAY 00hr 45min
MENU	NAV ASSIST	FUNC	<	>
				DIM -

Course —————

Speed —————


CTS —————

Distance from the own ship's position to the waypoint —————

Deviation from the route —————

Time required for reaching the waypoint —————

Navigation assistance screen 2 (measurement for navigation)



W84	AUTO No.2	GPS	GPS 3DFIX
NAV ASSIST 2 NAV CALC			
CALC STATE	RUNNING		
LAT	35°46.3608'N		
LON	139°37.6598'E		
SOG	11.5kn		
COG	359.0°		
START	NOV 25, '18 12:49:10 (U)		
END	--- --, '--- --:-- (U)		
TIME	0000 DAY 01 hr 19 min		
TRIP DIST	14.7NM		
TOTAL DIST	3031.2NM		
MENU	NAV ASSIST	FUNC	<
			>
			DIM -

Own ship position —————

Speed —————

measurement start time —————

Total time —————

Trip —————

RUNNING: Measurement in progress

END: Measurement complete

Course —————

measurement end time —————

Total distance —————

Navigation assistance screen 3 (measurement for navigation)

Navigation assistance screen 3 (measurement for navigation) displays trip calculation data. The screen is divided into two sections for 'RUNNING' and 'END' states.

**Left side labels:**

- measurement start time
- Total time
- Average speed
- measurement start time
- measurement end time
- Total time
- Average speed

**Right side labels:**

- RUNNING: Measurement in progress
- END: Measurement complete
- measurement end time
- trip
- RUNNING: Measurement in progress
- END: Measurement complete
- trip

TRIP1	CALC	STATE	END
START	NOV 25, '18	12:48:52 (U)	
END	NOV 25, '18	13:28:12 (U)	
TIME	0000 DAY	00 hr 39 min	
AVG SPD	12.4kn	TRIP	8.1NM
TRIP2	CALC	STATE	RUNNING
START	NOV 25, '18	12:48:56 (U)	
END	---	---	(U)
TIME	0000 DAY	02 hr 53 min	
AVG SPD	10.5kn	TRIP	30.4NM

Navigation assistance screen 4 (External equipment screen)

Navigation assistance screen 4 (External equipment screen) displays various sensor data. The screen shows bow and stern speed through water, water depth, and current data across five layers (A-E).

**Left side labels:**

- Forward/backward speed through water  
▲:Forward  
▼:Backward
- Water depth
- Current direction, speed and depth.  
Layer A  
Layer B  
Layer C  
Layer D  
Layer E

**Right side labels:**

- Bow speed through water  
◀ Leftward  
▶ Rightward
- Stern speed through water  
◀ Leftward  
▶ Rightward
- Water temperature

DIR	SPD	DEPTH	
A	125.7°	3.3kn	51.0m
B	132.2°	2.8kn	102.0m
C	128.4°	2.6kn	155.0m
D	130.7°	2.3kn	178.0m
E	131.2°	2.1kn	200.0m

Navigation assistance screen 5 (Calculation of a distance/bearing between two points)

Navigation assistance screen 5 (Calculation of a distance/bearing between two points) displays the results of a distance and bearing calculation between two points.

**Left side labels:**

- Starting point (Latitude and longitude)
- Distance
- Bearing

**Right side labels:**

- Terminal point (Latitude and longitude)
- Distance calculation method  
GC: Great circle sailing  
RL: Rhumb line sailing

STARTING POINT	
LAT	35°42.5563'N
LON	139°34.9947'E
TERMINAL POINT	
LAT	35°36.5422'N
LON	138°08.1036'E
SAIL	RL
DIST	71.17NM
BRG	265.1°

# Chapter 4 Operation

## 4.1 Menu List

### 4.1.1 Main Menu

MENU	Sub Menu	Sub Menu	Sub Menu	Range	Reference	
DISPLAY	THEME			DAY/DUSK/NIGHT		
	BEEP			OFF / ON		
	DAY SCREEN			OFF / ON		
	NAV			OFF / ON		
	PLOT			OFF / ON		
	ANALOG			OFF / ON		
	HIGHWAY			OFF / ON		
	SAT INFO			OFF / ON		
	WPT INFO			OFF / ON		
	BEACON TEXT			OFF / ON		
NAV ASSIST			OFF / ON			
VOYAGE	WPT	WPT LIST				
	ROUTE	ROUTE LIST				
	RUN					
	EVENTMARK	EVENTMARK LIST				
	WPT COPY					
	ROUTE COPY					
	WPT DELETE					
	ROUTE DELETE					
	EVENT DELETE					
	SHARED	ROUTE SEND				
		ROUTE RECEIVE	SOURCE IP			
	DEFAULT SETTINGS	WIDTH PORT(NM)			0.00~9.99	
		WIDTH STBD(NM)			0.00~9.99	
ARRIVAL RADIUS(NM)				0.00~9.99		
SPEED(kn)				00.00~99.99		
SAIL				GC/RL		
SOG SMOOTHING(s)				0~99		
ALERT	SYSTEM	SET		OFF / ON		
		SOUND		OFF / ON		
	ARRIVAL/ ANCHOR	SET			OFF / ARRIVAL / ANCHOR	
		SOUND			OFF / ON	
	XTD/ BOUNDARY	SET			OFF / XTD / BOUNDARY	
		SOUND			OFF / ON	
	HDOP	SET				
		SOUND			OFF / ON	
	SPD	SET				
		SOUND			OFF / ON	
	TRIP	SET				
		SOUND			OFF / ON	
	EARLY COURSE CHANGE	SET				
		SOUND			OFF / ON	
END OF TRACK	SET					
	SOUND			OFF / ON		
ARRIVED AT WOL	SET			OFF / ON		
	SOUND			OFF / ON		

MENU	Sub Menu	Sub Menu	Sub Menu	Range	Reference	
ALERT	ACTUAL COURSE CHANGE	SET		OFF / ON		
		SOUND		OFF / ON		
	TEMP	SET				
		SOUND			OFF / ON	
	DPTH	SET				
		SOUND			OFF / ON	
	DGPS	SET			OFF GPS→DGPS DGPS→GPS GPS↔DGPS	
		SOUND			OFF / ON	
	BUFFER	SET			OFF / ON	
		SOUND			OFF / ON	
	POWER	SET			OFF / ON	
		SOUND			OFF / ON	
GNSS SETTING	SENSOR1	GNSS	GPS MODE	GPS		
		FIX MODE		2D / 3D / AUTO		
		ELV MASK		5~89 deg		
		HDOP		4/10/20		
		SMOOTH	POSN SMOOTHING(s)		0~99	
			SPEED SMOOTHING(s)		0~99	
			COURSE SMOOTHING(s)		0~99	
		RAIM	RAIM ACCURACY LEVEL(m)		OFF/10/30/50/100	
		DATUM				
		INIT	QUADRANT			
			LAT			
			LON			
			ANT HEIGHT(m)			
			YEAR			
			MONTH			
			DAY			
			HOUR(hr)			
		MINUTE(min)				
		DGPS			OFF / AUTO BEACON / SBAS	
		BEACON	AUTO			
			MANUAL		FREQUENCY/ BITRATE	
			SEMI AUTO			
			MONITOR			
		SBAS	SAT SEARCH		AUTO / MANUAL (SBAS SETTING)	
			TYPE0		OFF / ON	
			RANGING		OFF / ON	
		STN LIST				

MENU	Sub Menu	Sub Menu	Sub Menu	Range	Reference
GNSS SETTING	SENSOR2	GNSS	GPS MODE	GPS	
		FIX MODE		2D / 3D / AUTO	
		ELV MASK		5~89 deg	
		HDOP		4/10/20	
		SMOOTH	POSN SMOOTHING(s)	0~99	
			SPEED SMOOTHING(s)	0~99	
			COURSE SMOOTHING(s)	0~99	
		RAIM	RAIM ACCURACY LEVEL(m)	OFF/10/30/50/100	
		DATUM			
		INIT	QUADRANT		
			LAT		
			LON		
			ANT HEIGHT(m)		
			YEAR		
			MONTH		
			DAY		
			HOUR(hr)		
			MINUTE(min)		
		DGPS		OFF / AUTO BEACON / SBAS	
		BEACON	AUTO		
			MANUAL	FREQUENCY/ BITRATE	
			SEMI AUTO		
			MONITOR		
SBAS	SAT SEARCH	AUTO / MANUAL (SBAS SETTING)			
	TYPE0	OFF / ON			
	RANGING	OFF / ON			
STN LIST					
SYSTEM	DATE / TIME	TIME DIFF		+00:00~+13:30	
		DATE DISP		'YY-MM-DD DD MMM,'YY MMM DD,'YY	
		TIME DISP(hr)		12hr / 24hr	
	UNIT	DIST / SPEED		NM,km km,km/h mi,mi/h	
		HIGHT / DPTH		m / ft / fm	
		TEMP		°C / F	
	MAG CORR				
	LORAN		OFF / LORAN A,C		
	SENSOR SELECT		AUTO/ SENSOR1,2		
	LANGUAGE			JAPANESE/ ENGLISH	
VERSION	DISPLAY				
	PROCESSOR				
	SENSOR1				
	SENSOR2				
ALERT LIST	ALERT HISTORY				
	ACTIVE ALERT				
	LAN1				
	LAN2				

MENU	Sub Menu	Sub Menu	Sub Menu	Sub Menu	Range	Reference	
EQUIP	TYPE	TYPE1 / 2 DISPLAY	DISPLAY TYPE		MAIN REMOTE(LAN) REMOTE (SERIAL)		
			SFI		GP0000		
		TYPE2/2 PROCESSOR	DEVICE No.		No1.~No3.		
			SFI		GP0000		
			SENSOR1		OFF GPS COMPASS OTHER EQUIP		
			SENSOR2		OFF GPS COMPASS OTHER EQUIP		
	DATA I/O	IN/OUT1					
		IN/OUT2					
		IN/OUT3					
		OUT4					
		OUT5					
		OUT6					
		LAN	LAN1		DATA OUT		
					RMS SEND		
					PRINTER		
			LAN2		DATA OUT		
					RMS SEND		
					PRINTER		
			COMMON		ACTIVE ROUTE		
					DATA ROUTE		
					MUTUAL		
		CONTACT1	CONTACT OUT				
		CONTACT2	CONTACT OUT				
		CONTACT3	CONTACT OUT				
		CONTACT4	CONTACT OUT				
		BUFFER	FORMAT				
			BITRATE(bps)				
			VERSION				
			TALKER				
	SENSOR	SENSOR1 PORT2(bps)		4800 / 9600 19200 / 38400			
		SENSOR2 PORT2(bps)		4800 / 9600 19200 / 38400			
	RS-232C	FORMAT					
		BITRATE(bps)					
VERSION							
TALKER							
SWITCH	CONTROLL METHOD		OFF MFD FIX/NOFIX FIX/NOFIX + DOP				
	SWITCH SELECTION		PROCESSOR No1. PROCESSOR No2.				

MENU	Sub Menu	Sub Menu	Sub Menu	Sub Menu	Range	Reference		
EQUIP	DIMMER	SETTINGS	DIMMER GROUP		1~10			
			DISPLAY		OFF/ON			
			NCM-227		OFF/ON			
			DDC		OFF/ON			
			GPS		OFF/ON			
			GP DDC		OFF/ON			
		DIMMER CAL		MIN/MAX				
	IP	DISPLAY		IP ADDRESS				
				MAC ADDRESS				
				SUBNET MASK				
				DEFAULT GATEWAY				
		PROCESSOR LAN 0			IP ADDRESS			
					MAC ADDRESS			
					SUBNET MASK			
					DEFAULT GATEWAY			
		PROCESSOR LAN 1			IP ADDRESS			
					MAC ADDRESS			
					SUBNET MASK			
					DEFAULT GATEWAY			
		PROCESSOR LAN 2			IP ADDRESS			
					MAC ADDRESS			
	SUBNET MASK							
	DEFAULT GATEWAY							
	CCRP			BEAM (m)				
				LENGTH(m)				
				CCRP(m)				
				SENSOR1 (m)				
				SENSOR2 (m)				
	CTS			CLASS				
				TRACKING GAIN				
				TRACKING HIGH				
TORACING MIDDLE								
TRACKING LOW								
TRACKING MULTIPLE								
TRACKING COUNT A								
TRACKING D GAIN								
LOW SPEED COG	OUTPUT			OFF/ON				

MENU	Sub Menu	Sub Menu	Sub Menu	Sub Menu	Range	Reference	
EQUIP	MAINTENANCE	DIAGNOSIS	DISPLAY				
			PROCESSOR				
			SENSOR1				
			SENSOR2				
			MONITOR	DATA IN1			
				DATA IN2			
				DATA IN3			
				RS-232C			
				SWITCH			
				LAN1			
				LAN2			
				SENSOR1			
			SENSOR2				
					OPERATING TIME	OPERATING TIME(hr)	
				LCD TIME(hr)			
	RESET						
	DEMO		DEMO TYPE				
			START/ STOP				
			YEAR				
			MONTH				
			DAY				
			HOURL(hr)				
			MINUTE(min)				
			SECOND(s)				
			QUADRANT				
			LAT				
			LON				
			SPEED(kn)				
			COURSE(° )				
			RADIUS(NM)				
		ROUTE					
	ALL SETTING VALUE		BACKUP INFO				
		IMPORT/ EXPORT		MPORT/ EXPORT		PROCESSOR → DISPLAY DISPLAY → PROCESSOR	
			PROCESS		BACKUP/ OVERWRITE		



## 4.1.2 Function menu


DISPLAY	FUNC	
COMMON	PRINT	Outputs data to a printer.
	GOTO	Sets a waypoint.
	EVENT	Registers the own ship's position in the event mark list.
	DIMMER DEFAULT	Resets the dimmer setting to the default value.
PLOT1/PLOT2	MARK	Displays a mark at the cursor position.
	CURSOR MODE	Displays a cursor.
	HOME	Moves own ship to the centre of the screen.
	PLOT	Sets display/non-display on the plotting screen.
ANALOG	SPEED METER	Sets the maximum value of the ship speed meter.
HIGHWAY	BACK GROUND COLOUR	Changes the background colour of the HIGHWAY screen.
SAT INFO	NEAREST STN	Displays the nearest beacon station. JLR-8600 does not support this function.
BEACON TEXT	BEACON DELETE	Deletes the received data. JLR-8600 does not support this function.
	BUZZER	Sets whether to sound a buzzer when TYPE16 is received.
NAV ASSIST	CALC START	Starts distance calculation.
	TRIP RESET	Stops trip distance calculation.
	TOTAL TRIP RESET	Resets the total trip distance.
	TRIP 1 CAL START/END	Starts/Stops distance calculation of TRIP1.
	TRIP 2 CAL START/END	Starts/Stops distance calculation of TRIP2.
	TRIP 1 RESET	Resets distance calculation of TRIP1.
	TRIP 2 RESET	Resets distance calculation of TRIP2.
	CURRENT SETTING	Sets the layer of the current to be displayed.
CALC SETTING	Sets the position of two points between which the distance is to be calculated.	

## 4.2 Basic Operation

### 4.2.1 Turning on the power of the unit

When the power of the equipment is turned on by pressing the Power key, the startup screen appears.

When installation is completed, self-diagnosis starts and the setting value confirmation screen is changed to the normal screen.




#### Attention

If the power for the equipment is not turned on, check the main power supply of the power board, power cable connection to the processor, or cable connection to the display unit.

### 4.2.2 Startup


#### 1) Normal startup

If all the self-diagnosis results are 'OK' and all the settings of the processor and sensor settings match, the screen is switched to the normal screen automatically.



## 2) Error startup 1

The message that is shown below may be displayed in the receiver diagnosis.  
This message is displayed when the setting values do not match between the processor and the receiver due to the equipment replacement or other reason.



In this case, select one of the following items.

[USE SENSOR CONFIG.]: The setting value of the processor is rewritten so as to match the setting value of the receiver.

[USE PROCESSOR CONFIG.]: The setting value of the receiver is rewritten so as to match the setting value of the processor.

## 3) Error startup 2

If any one of the diagnosis results is 'NG', the result will be displayed continuously.  
The screen is not switched to the normal screen unless "SKIP" is tapped.

### Attention

When there is any error (NG), contact Nippon Signal or your distributor.

## 4.2.3 Turning off the power of the unit

When the Power key is pressed, the following message is displayed. When "YES" is selected, the power is turned off.

POWER OFF  
ARE YOU SURE

### Memo

- Even if the message is displayed, the power of the display is turned off forcibly if the Power key is held down for about 8 seconds. In this case, the power of the display is turned off, but the processor operates continuously.
- When the display unit is energised even if the power is Off, the LED of the Power key is lit.

## 4.2.4 Adjusting the backlight

The brightness can be adjusted to 17 levels/OFF by using the DIM key. Even if the brightness is set to OFF, the DIM key alone remains lit.

To reset the brightness to the default value, tap  from .

1. Whenever “DIM+” at the top right corner of the screen is pressed, the screen brightness increases.
2. Whenever “DIM-” at the bottom of the screen is pressed, the screen brightness decreases and finally is set to OFF.

## 4.2.5 Menu operation

When the MENU key is pressed, a menu is displayed.

When the MAIN key is pressed while a menu is displayed, the screen returns to the normal screen.










For the details of the menu, refer to “4.1 Menu List”.

## 4.2.6 Alert and acknowledgment (ACK)

### 1. Notifying the occurrence of an alert

When an alert occurs, an alert icon is displayed at the top left corner of the screen and the occurrence of an alert is notified by a buzzer sound. The alert target value is displayed with blinking.

#### Icon list

Icon	Priority	Status
	Alarm	Active-Unacknowledged
		Active-Silenced
		Active-Acknowledged
		Rectified- Unacknowledged
	Warning	Active-Unacknowledged
		Active-Silenced
		Active-Acknowledged
		Rectified- Unacknowledged
	Caution	Active

When any icon is tapped, an alert display bar is displayed at the centre of the screen.


### 2. Alert acknowledgment (ACK)

- 1) Tap the alert detail bar at the centre of the screen.
- 2) The alert icon changes to the acknowledged state and the buzzer sound stops. When a NOFIX alert occurs, the alert target value that is displayed is lit in yellow.

#### Memo

- When multiple alerts occur simultaneously, the alert with the highest priority is displayed first and all the alerts must be acknowledged.
- Even if the alert is rectified before being acknowledged, the “Unacknowledged” state icon is displayed. All the alerts that have occurred must be acknowledged.

Screen transition at the occurrence of an alert



1. Operating normally

An alert occurrence icon is displayed.

Alert occurred



2. Alert occurred (Non ACK)

Tap the alert occurrence icon.



3. Alert is occurring  
The alert contents are displayed.

The icon indicating an acknowledged state is displayed.

Acknowledge by tapping the alert contents.




4. Alert occurred (acknowledged)

Tap the icon indicating an acknowledged state.



5. The alert contents are cleared.


Rectified.



6. Rectified


## 4.2.7 Screen operation


See below for the screen operation.



## 4.2.8 Inputting numeric values


Numeric value input by numeric keys is allowed for the setting values with blue underline. Tap the blue underline of the numeric item to be input.



Enter a numeric value and confirm with .



## 4.2.9 Inputting comments

Input of characters by using numeric keys is allowed for the setting items with blue underline. Tap the blue underline of the setting item to be input. Change the input mode by tapping ABC (characters), #&\$ (symbols), or 123 (numeric values). Display the character or numeric value that is assigned to the key by tapping it. When entering the same character or symbol consecutively, take a small interval between them.

Enter a character and confirm it with .







## 4.2.10 List operation

This section shows the list operation method.

The same operation method is applied for a waypoint list, a route list, and an event mark list.



When the list is empty, the following message is displayed.



## 4.2.11 Entering a password in CODE INPUT


Some setting items are protected by a password to prevent them being changed easily.


If the power is turned off or no operation is performed for five minutes after a password is set, the password is reset.

To set a password, enter a password again in CODE INPUT.

Procedure

1.  → 


2. Enter a password and confirm it with .



## 4.3 Setting Display

Set a screen.

Set a THEME, a beep tone, and background colour.



### 4.3.1 Setting a theme

Screen brightness can be adjusted according to the time zone for using this equipment.

Procedure

1.  →  → THEME

THEME	Description
DAY	Specify this when using the equipment during daytime.
DUSK	Specify this when using the equipment at dusk.
NIGHT	Specify this when using the equipment at night.

### 4.3.2 Setting a beep tone

Set a beep tone ON/OFF when the screen is tapped.

Procedure

1.  →  → BEEP

BEEP	Description
ON	Sets the beep tone to ON.
OFF	Sets the beep tone to OFF.

### 4.3.3 Setting reverse video display

Set the background colour to white/black.

Procedure

1.  →  → DAY SCREEN

DAY SCREEN	Description
ON	Sets the background colour to white.
OFF	Sets the background colour to black.

#### 4.3.4 Selecting a display screen

A screen to be displayed can be selected.  
It is not possible to set all the screens to non-display.

Procedure

1.  →  → Select a display.


DISPLAY	Description
NAV	
PLOT1	ON: Set to Display.
PLOT2	OFF: Set to Non-display.
ANALOG	
HIGH WAY	
SAT INFO	
WPT INFO	
BEACON TEXT	
NAV ASSIST	

## 4.4 Registering Waypoints




- To execute a route, a waypoint must be registered in a waypoint list.
- This equipment allows registration of 10000 waypoints.
- A waypoint list is divided into three areas and it is managed by numbers from 1 to 11024.
  - 1 to 10000: Waypoints that are registered in this equipment are registered.
  - 10001 to 10512: Waypoints of the shared active routes that are sent from ECDIS are registered.
  - 10513 to 11024: Waypoints that were used by a temporary route are registered.
- While waypoints from number 1 to number 10512 are saved and are not cleared even if the power is turned off, waypoints from number 10513 to number 11024 are cleared if the power is turned off.
- Waypoints can be set up to North latitude/South Latitude 89 degrees.

### 4.4.1 Displaying a waypoint list


Registered waypoints (waypoint numbers from 1 to 10000) can be displayed. Waypoint number 00001 is registered as “HOME PORT”.



#### Procedure

1.  →  →  → A waypoint list is displayed.

#### Memo

- The position that is registered in HOME in a waypoint list can be set easily as a waypoint by the GOTO function. It is useful to register a point that is set as a waypoint frequently (such as home port). The GOTO function can be set from  on each screen.




## 4.4.2 Registering waypoints

The following five positions can be registered in a waypoint list.



- (1) Own ship's position
- (2) Any latitude and longitude
- (3) Cursor position
- (4) Position measured by the bearing and distance from any position
- (5) Position that is registered in an event/mark list

Up to 10000 points can be registered.

Procedure


1.  →  →  → A waypoint list is displayed.

2. Tap the number you want to register.



Item	Description
WPT No.	Enter a waypoint number.
COMMENT	Enter a comment.
POSN	Enter a waypoint position.
SYMBOL	Select a symbol.
COLOUR	Select a symbol colour.



3. Tap "POSN".
4. A registration method selection screen is displayed.



The registration method submenu is outlined below.


- (1) OWN SHIP: Register an own ship's position.
- (2) MANUAL: Register any latitude and longitude.
- (3) PLOT: Register a cursor position from the plotting screen.
- (4) BEG/DIST: Register based on the bearing/distance from any position.
- (5) EVENT LIST: Register from an event mark list.

(1) When selecting OWN SHIP


- a) Tap  .
- b) Set a comment, a symbol, and a colour, and tap  .

(2) When selecting MANUAL


- a) Tap  .




Item	Description
QUADRANT	Select North latitude/South latitude/East latitude/West latitude of the latitude/longitude.
	NE North latitude/East latitude
	NW North latitude/West latitude
	SE South latitude/East latitude
	SW South latitude/West latitude
LAT	Enter a latitude.
LON	Enter a longitude.

- b) Set a comment, a symbol, and a colour, and tap  .


(3) Selecting PLOT

- a) Tap  .
- b) A plotting screen is displayed.
- c) Move the cursor to the position you want to register by using the Up/Down/Left/Right arrows.
- d) Tap "SET".
- e) The cursor position is registered.


Cursor position  
Bearing/distance from own ship to the cursor position




Registered waypoint

- f) Set a comment, a symbol, and a colour and tap  .

#### (4) Selecting BRG/DIST

- a) Tap .
- b) When a waypoint position screen is displayed, tap WPT POSN.





- c) Set a starting position, a bearing, and a distance.


The submenu for setting a starting position is outlined below.


- (1) OWN SHIP: Set an own ship's position.
- (2) MANUAL: Set any latitude and longitude.
- (3) PLOT: Set a cursor position from the plotting screen.
- (4) WP LIST: Select from a waypoint list.
- (5) EVENT LIST: Select from an event mark list.
- (6) PRE WPT: Set the previous waypoint as the starting position.


Item	Description
STARTING POINT	Enter a starting point.
BRG	Enter a bearing.
DIST	Enter a distance.

- d) Confirm the setting by tapping .
- e) Set a comment, a symbol, and a colour and tap .

#### (5) Selecting EVENT LIST

- a) Tap .
- b) An event mark list is displayed.
- c) Select a number of the event mark you want to register.







- d) Set a comment, a symbol, and a colour and tap .

### 4.4.3 Editing waypoints

- Registered waypoint information (symbol shape, comment, and waypoint position) can be edited.
- The waypoint on the route that is currently being executed cannot be edited.

#### Procedure

1.  →  →  → A waypoint list is displayed.
2. Tap the number you want to edit.
3. Tap the item you want to edit and edit the item.
4. After editing, tap .




To edit a position, refer to “4.4.2 Registering waypoints”.

A symbol, a colour, and a comment can be edited from the plotting screen. For the editing method, refer to “4.9.10 Displaying symbol information”.


### 4.4.4 Copying waypoints

- Waypoint information can be copied on to another waypoint number. Information on an event and a mark can be copied on to a waypoint list. Number 1 in a waypoint list is handled as HOME.
- Waypoints that are saved under numbers from 10001 to 10512 and are used by the shared active route that is sent from ECDIS are automatically overwritten when next route is sent. Waypoints to be kept must be copied under numbers between 1 and 10000.
- Waypoints of a temporary route that are saved under numbers from 10513 to 11024 are cleared when another temporary route is created or the power is turned off. Waypoints to be kept must be copied under numbers between 1 and 10000.
- When no free area is available, waypoints can be overwritten. However, waypoints cannot be overwritten to those that are used by the route.

#### Procedure

1.  →  → 
2. Enter a starting point and an ending point of the copy source.  
When only one point is to be copied, enter the same number for a starting point and an ending point.
3. Tap a copy destination. The copy destination submenu is outlined below.
  - (1) Any input: Enter an input number.
  - (2) Waypoint list: Specify from a waypoint list.
- (1) Any input  
Enter a starting point of the copy destination.
- (2) Waypoint list  
When a waypoint list is displayed, tap a number of the copy destination.



4. Confirm the operation by tapping .





#### Memo

- When selecting copy sources with consecutive numbers, numbers that cross over a boundary such as 10000 or 10512 cannot be selected.  
Example) Numbers from 9999 to 10001 or numbers from 10511 to 10513 cannot be selected.

### 4.4.5 Deleting waypoints

- Waypoints registered from numbers 1 to 10000 can be deleted.
- Waypoints on the route that is currently executed cannot be deleted.
- If a waypoint is on the route that is not being executed is deleted, the waypoint is deleted from the route also.

#### Procedure

1.  →  → 
2. Tap a deletion source. A deletion source submenu is outlined below.
  - (1) Any input: Enter a waypoint number to be deleted.
  - (2) Waypoint list: Specify from a waypoint list.
  - (3) ALL: All the waypoints are deleted.
- (1) Any input  
Enter a starting point and an ending point of the number of the waypoint to be deleted.  
When deleting one point only, enter the same number for a starting point and an ending point.
- (2) Waypoint list  
When a waypoint list is displayed, select a starting point and an editing point of the waypoints to be deleted.  
When deleting one point only, enter the same number for a starting point and an ending point.
- (3) All  
All the waypoints are deleted.
3. The range to be deleted and the number of waypoints to be deleted are displayed.
4. Confirm the selection by tapping .

Waypoints can be deleted from a plotting screen. For the editing method, refer to “4.9.10 Displaying symbol information”.

## 4.5 Route Plan

- A route can be created by using registered waypoints.
- Up to 100 routes can be created in this equipment and up to 512 waypoints can be specified per route. Waypoint information can be set for each LEG such as a route width, an arrival radius, and GC/RL.


For the waypoint information that can be set, refer to “4.5.1 Displaying a route list”.

- A created route can be shared with external equipment such as ECDIS.
- A created route is registered in a route list.
- A route list is divided into three areas and is managed by numbers from 1 to 102.
  - Numbers from 1 to 100: The route that was created in this equipment is registered.
  - Number 101: The shared active route that is sent from ECDIS is registered.
  - Number 102: A temporary route is registered.
- Since routes from numbers 1 to 101 are saved, they are not cleared even if the power is turned off. However, route number 102 is cleared if the power is turned off since it is not saved.

### 4.5.1 Displaying a route list

Routes that were created can be displayed in a route list. Information on each LEG of the route and waypoint information of each LEG can be displayed.

The required time cannot be calculated for the route that contains the LEG without planned ship speed.



#### Procedure

1.  →  →  → A route list is displayed.

When a registered route is tapped, the LEG information can be displayed.


## 4.5.2 Creating routes

- To create a route, determine a route number and sequentially select the waypoints, which are turn points.
- The same waypoint cannot be selected continuously.
- Up to 100 routes can be created.
- Up to 512 waypoints can be set per route.
- Either a TCS route or a normal route can be selected.

### Procedure

1.  →  →  → A route list is displayed.

2. Tap a number to be registered.




3. Tap .

Item	Description	
ROUTE	ARRIVAL CIRCLE	Creates a normal route.
	WHEEL-OVER LINE(WOL)	Creates a TCS route.
COMMENT	Enter a comment.	

4. Tap .


When a waypoint input screen is displayed, tap 001.



Item	Description
POSN	When "POSN" is tapped, a waypoint list is displayed. Select a waypoint position from the waypoint list.
COMMENT	A comment cannot be set for a waypoint. It can be edited from the waypoint list.
SYMBOL	A waypoint symbol cannot be set. It can be edited from the waypoint list.
COLOUR	A colour of a waypoint cannot be set. It can be edited from the waypoint list.
ARRIVAL RADIUS	Set an arrival radius.
WIDTH PORT	Set a port route width.
WIDTH STBD	Set a starboard route width.
SPEED	Set a planned ship speed.
SAIL	Route distance calculation method for LEG GC: Calculated by the great circle sailing. RL: Calculated by the Meridional part sailing (Rhumb Line).
STATE	Set whether to use the waypoint. USE: Use the waypoint. SKIP: Although the waypoint is kept on the route, it is skipped. DELETE: The waypoint is deleted from the route. It is kept in the waypoint list. Waypoints of the route that is currently being executed cannot be deleted.
ROT	This item can be set for a TCS route only. Set a Rate Of Turn.
TURN RADIUS	This item can be set for a TCS route only. Set a turn radius.
TIME ZONE	This item can be set for a TCS route only. Set a time zone.

5. Set each item and tap .

First waypoint is set. To set two or more waypoints, repeat from Step 4.








6. Set a waypoint and tap .

### 4.5.3 Editing routes


Waypoint addition, change, and deletion are allowed for routes.

Procedure

1.  →  →  → A route list is displayed.
2. Tap a route you want to edit.
3. Tap .
4. Tap a waypoint you want to edit.



Item	Description
END ADD	Adds the final waypoint.
INSERT	Adds a waypoint before the waypoint that is tapped.
EDIT	Edits the waypoint that was tapped.
DELETE	Deletes the waypoint that was tapped from the route.

5. Set a waypoint and tap .

Headers can also be edited in the same way.

## 4.5.4 Copying routes

The route that was created can be copied on to a different route number.

The waypoint that is used by the shared active route and is sent from ECDIS and is saved in number 101 is overwritten automatically when the next route is sent. Routes that are to be saved must be copied on to numbers between 1 and 100.

The waypoint of a temporary route that is saved under number 102 is cleared when another temporary route is created or the power is turned off. To save the route, the route must be copied on to a number between 1 and 100.

Routes of consecutive numbers can be copied in bulk.


When no free area is available, a route can be overwritten. However, the route that is being executed cannot be overwritten.

Select a copy source and specify a copy destination number.

When a temporary route or a shared route is to be copied, the waypoints must also be copied.

### Procedure

1.  →  → 



2. Tap "COPY ORG" and enter a number of a starting point and an ending point of the copy source.

The input method is outlined below.

- (1) MANUAL: Enter an ending point and a starting point.
- (2) ROUTE LIST: Select from the route list.

When copying one point only, enter the same number for a starting point and an ending point.

### (1) MANUAL input

- a) Tap .

Item	Description
FROM	Set a starting number.
TO	Set an ending number.

### (2) Selecting from a ROUTE LIST

- a) Tap .

- b) Tap a starting point and an ending point on the route list.

c) Confirm the setting by tapping .

3. Tap "COPY DEST" and enter a starting point of the copy destination.

The input method is outlined below.

- (1) MANUAL: Enter an ending point.
- (2) ROUTE LIST: Select from the route list.


**(1) MANUAL input**

a) Tap .

Item	Description
INSART	Set a copy destination number.


b) Confirm the setting by tapping .

**(2) Select from a ROUTE LIST**

a) Tap .

b) Tap a copy destination on the route list.

c) Confirm the setting by tapping .


4. Execute by tapping .

**4.5.5 Deleting routes**

- Registered routes from numbers 1 to 100 can be deleted.
- The waypoints of the route to be deleted can be deleted concurrently.
- When deleting waypoints also, the waypoints that are used by another route cannot be deleted.
- An Active route cannot be deleted.

**Procedure**

1.  →  → 



2. Tap "DELETE" and enter a number of a starting point and an ending point of the deletion source.

The input method is outlined below.

- (1) MANUAL: Enter an ending point and a starting point.
- (2) ROUTE LIST: Select from the route list.
- (3) ALL: All the routes are deleted.

When copying one point only, enter the same number for a starting point and an ending point.

### (1) MANUAL input

- a) Tap  .

Item	Description
FROM	Set a starting number.
TO	Set an ending number.

### (2) Selecting from a ROUTE LIST

- a) Tap  .

- b) Tap a starting point and an ending point on the route list.

- c) Confirm the selection by tapping  .


### (3) Selecting ALL

- a) Tap  .

All the routes are selected.

3. Tap "DELETE METHOD" and select a deletion method.

DELETE METHOD	Description
ROUTE	Only the selected route is deleted. The waypoint is not deleted.
ROUTE+WPT	The selected route and the waypoint on the route are deleted.

4. Tap  and execute the deletion.




## 4.5.6 Sharing a route with another piece of equipment

The route that was created by this equipment can be sent to EDCIS or a radar and also the route that was created by ECDIS can be shared by receiving it (Data route sharing). To use the route sharing function, equipment (ECDIS or radar) corresponding to the sharing must be connected to LAN.

### Procedure

1.  →  → 



Item	Descriptions
ROUTE SEND	Sends a route.
ROUTE RECEIVE	Sets route reception.

### (1) Sending a route

- a) Tap .

- b) Set each item.

Item	Description	
CONNECT	Select multicast, unicast, or broadcast.	
IP	Set a destination ID when selecting unicast.	
PORT	Set a destination port when selecting unicast.	
OUTPUT	Set a LAN port for output.	
FORMAT	NMEA VER1.5	Sends under the RTE/WPL sentence of NMEA Ver 1.5.
	NMEA VER2.1	Sends under the RTE/WPL sentence of NMEA Ver 2.1.
	NMEA VER2.3	Sends under the RTE/WPL sentence of NMEA Ver 2.3.
	NMEA VER4.0	Sends under the RTE/WPL sentence of NMEA Ver 4.0.
	IEC	Sends under the RTE/WPL sentence of IEC.
	JRC	Sends the route in the JRC format.
SHARE ROUTE	Use ROUTE to set the route to be sent.	
DATA	Select the data to be sent.	
	ALL WPT	Sends all the waypoints.
	ALL WPT+ROUTE	Sends all the waypoints and routes.
	SELECT WPT+ROUTE	Sends the selected route and the waypoint.
	ALL ROUTE	Sends all the routes.
SELECT ROUTE	Sends the selected route.	
ROUTE	This item can be set when SHARE ROUTE is selected. Select a route to be sent.	
TOTAL	This item can be set when SHARE ROUTE is selected. Displays the number of selected routes.	


A ROUTE can be selected manually or from a route list.

c) When  is tapped, the route is sent.

## (2) Receiving a route

a) Tap .

Item	Description
SOURCE IP	Set a sending source IP.


b) Tap  to set the sending source.

### 4.5.7 Setting route initial values

Set an initial value of each parameter of the route.  
The values are applied to the route that was created by GOTO.

Procedure

1.  →  → 



2. Set each item.

Item	Description
WIDTH PORT	Set a port route width.
WIDTH STBD	Set a starboard route width.
ARRIVAL RADIUS	Set an arrival radius.
SPEED	Set a planned ship speed.
SAIL	Route distance calculation method for LEG GC: Calculated by the great circle sailing. RL: Calculated by the Meridional part sailing (Rhumb Line).
SOG SMOOTHING	Set a SOG smoothing constant. Smoothing is applied to the ship speed for calculating the estimated time of arrival and the estimated time required. Smoothing can be applied up to 99 seconds. When the estimated time of arrival fluctuates significantly, increase the smoothing value.

3. Confirm the setting by tapping .

## 4.6 Executing a Route


- A registered route or a temporary route can be executed.
- The following route selection methods are available.
  - (1) Select a route from a route list.
  - (2) Select a waypoint by using the GOTO key.
  - (3) Select a route by using the GOTO key.
  - (4) Select a temporary route by using the GOTO key.
- A route cannot be executed at the position exceeding North latitude/South latitude 89 degrees.
- For the route width, arrival radius, planned ship speed of the temporary route that was created by GOTO, the initial values of the route are used. For the setting of route initial values, refer to "4.5.7 Setting route initial values".
- The waypoint is updated when the ship arrives at the arrival circle.

### 4.6.1 Executing a route by selecting from a route list

A route can be executed by selecting from a route list.

Procedure

1.  →  → 



2. Set each item.

Item	Description
ROUTE	Displays the route number to be executed.
LEG CHANGR	<p>Select a waypoint update method.</p> <p>AUTO: When the ship arrives at the arrival circle (normal route) or WOL (TSC route), the waypoint is updated automatically.  <b>WPT            AUTO</b> is displayed.</p> <p>"WPT CHANGE" is displayed for 5 seconds.</p> <p>MANUAL: When the ship arrives at the arrival circle (normal route) or WOL (TSC route), the effect is notified to the user. The waypoint is to be updated manually.  <b>WPT            MAN</b> is displayed.</p> <p>"PLEASE PUSH "OK" AND CHANGE A ROUTE is displayed. Tap "OK".            The waypoint is updated.</p>
DIRECTION	<p>Set an order of the waypoints to be executed.</p> <p>ORDER: Executes the route in the order of waypoints.</p> <p>REVERSE: Executes the route starting from the last waypoint.</p>
NAVIGATION	<p>Executes the route.</p> <p>START: Executes the route.</p> <p>END: Ends the route.</p>

3. Select "START" in "NAVIGATION".

4. Execute the route by tapping .



#### 4.6.2 Selecting a waypoint/route by using the GOTO key


When a waypoint or a route is selected by using GOTO that is assigned to "FUNC" of each screen, the route is executed towards the waypoint.

When a waypoint on the route that is being executed is selected by using the GOTO key, the route restarts from the waypoint.

The route that was created by GOTO is registered under route number 102 as a temporary route.

Procedure

1. Each screen →  → 



The GOTO submenu is outlined below.


- (1) HOME: Sets HOME in the waypoint list as the waypoint.
- (2) WPT No.: Enter a waypoint number.
- (3) ROUTE No.: Enter a route number.
- (4) EVENT No.: Enter an event number.
- (5) CURSOR POSN: The cursor position is specified as the waypoint (a temporary route can be created by setting up to 512 waypoints).
- (6) WPT LIST: Select from a waypoint list.
- (7) ROUTE LIST: Select from a route list.
- (8) EVENT LIST: Select from an event list.
- (9) ROUTE END: The route can be ended during the execution of the route.

##### (1) Entering "HOME"



a) Tap  .

##### (2) Entering a waypoint number



a) Tap  and enter a waypoint number.

b) Execute by tapping .


### (3) Entering a route number


- a) Tap  and enter a waypoint number.
- b) Execute by tapping .

### (4) Entering an event number

- a) Tap  and enter an event number.
- b) Execute by tapping .

### (5) Specifying the cursor position as the waypoint


- a) When  is tapped, a plotting screen is displayed.




- b) Move the cursor to the waypoint and tap "WPT SET". Cancels GOTO processing

To create a route, repeat the operation b).  
To delete a waypoint, tap "CLR".

- c) Tap "ROUTE SET".




d) The following popup window is displayed.




Item	Description
YES	Registers the route in the route list. When a route list is displayed, set a route number.
NO	Stores the route as a temporary route. A temporary route is cleared when the power is turned off.

### (6) Selecting a waypoint from a waypoint list

- a) When  is tapped, a waypoint list is displayed.
- b) Tap the number to be set as for the waypoint.


### (7) Selecting from a route list

- a) When  is tapped, a waypoint list is displayed.
- b) Tap the route number to be executed.
- c) Select a waypoint update method and an execution sequence.


Item	Description
LEG CHANGE	Select a waypoint update method.
	AUTO: When the ship arrives at the arrival circle (normal route) or WOL (TSC route), the waypoint is updated automatically. <b>WPT AUTO</b> is displayed.  "WPT CHANGE" is displayed for 5 seconds.
	MANUAL: When the ship arrives at the arrival circle (normal route) or WOL (TSC route), the effect is notified to the user. The waypoint is to be updated manually. <b>WPT MAN</b> is displayed.  "PLEASE PUSH "OK" AND CHANGE A ROUTE" is displayed. Tap "OK". The waypoint is updated.
DIRECTION	Set a direction of the waypoints to be executed. ORDER: Executes the route in the order of waypoints. REVERSE: Executes the route starting from the last waypoint.


d) Select "START" in "NAVIGATION".

### (8) Selecting from an event list

- a) Tap  to display an event list.
- b) Tap the number to be set as the waypoint.

### (9) Ending the route that is currently being executed

- a) Tap  .
- b) The following popup window is displayed.







- c) Tapping YES will end the route.

## 4.6.3 Ending a route

End a route.


Procedure

- 1.  →  → 
- 3. Select "END" in "NAVIGATION".
- 4. Execute by tapping  .


### Ending by using GOTO

- 1.  → 

- 2. Tap  .



- 3. The following popup window is displayed.




- 4. Tapping YES will end the route.

## 4.7 Event/Mark

- Events, marks, MOB, and lines are registered in an event mark list.

### 4.7.1 Displaying an event/mark list

- All the registered events and marks can be displayed in a list.
- MOB is registered under event number 000.



#### Procedure

1. MENU → VOYAGE → EVENT MARK

### 4.7.2 Registering events


Register an own ship's position as an event.

#### Procedure

1. FUNC → EVENT

#### Registering from a screen

1. Tap the position display section at the top of the screen.






### 4.7.3 Registering marks

Register a cursor position as a mark.

Procedure

1. Display the PLOT1 or PLOT2 screen.
2. Display a cursor and move the cursor to the position to be marked.

3. 


## 4.7.4 Editing events/marks


Symbols, colours, and comments of events/marks can be edited.

Procedure

1.  →  → 

2. Tap an event or a mark to be edited.



3. Edit the symbol, colour, or comment and tap .

## 4.7.5 Deleting events/marks

Events/marks can be deleted.



Procedure

1.  →  → 

The event/mark deletion submenu is outlined below.

- (1) EVENT MARK LIST: Select a deletion range from the event mark list.
- (2) ALL EVENT: Deletes all the events.
- (3) ALL MARK: Deletes all the marks.
- (4) ALL EVENT MARK: Deletes all the events/marks.

### (1) EVENT MARK LIST

- a) When  is tapped, an event mark list is displayed.
- b) Tap a starting point and an ending point of the event marks to be deleted.  
When deleting only one point, specify the same number for a starting point and an ending point.
- c) Confirm by using .

**(2) ALL EVENT**

a) Tap  .

**(3) ALL MARK**

a) Tap  .

**(4) ALL EVENT MARK**

a) Tap  .

2. When a deletion confirmation popup window is displayed, tap “YES”.

## 4.8 Plotting Screen


### 4.8.1 Operating the cursor

Procedure

1. Display the PLOT1 or PLOT2 screen.

2. **FUNC** → **CURSOR MODE**

3. Move the cursor by using the Up/Down/Left/Right arrow keys.



### 4.8.2 Changing the cursor size

A cursor size can be selected from LARGE/MIDDLE/SMALL.

Procedure


1. Display the PLOT1 or PLOT2 screen.

2. **FUNC** → **PLOT** → **CURSOR**

3. Select a size and confirm it with **✓**.

### 4.8.3 Moving a screen


The mouse can be used to move the tapped position to the centre of the screen.



### 4.8.4 Moving own ship to the centre of the screen

When own ship is within the screen range, the own ship's position can be moved to the centre of the screen by tapping it.

When own ship is moved to the position outside of the screen range, disabling its display, tap "HOME" at the bottom left corner of the screen.




#### Memo

- When own ship is moved to the end of the screen, own ship is returned to the centre of the screen automatically.
- Own ship can also be moved to the centre of the screen by selecting "FUNC" → "HOME".

## 4.8.5 Screen Zoom In/Out

The plotting screen horizontal width is set in the following scale.  
0.2, 0.5, 1.0, 2.0, 5.0, 10.0, 20.0, 50.0, 100.0, 200.0, and 300.0 [NM]



## 4.8.6 Changing North Up/Course Up


The screen mode can be changed to North Up, Course Up, or Relative North Up.

North Up: Own ship moves on the screen with North Up.

Course Up: The course of own ship is constantly set to the up position on the screen and the surrounding image moves.

Relative North Up: The top of the screen faces North and own ship's position is fixed and the surrounding image moves.

Whenever screen mode switching is tapped, the screen mode changes.



## 4.8.7 Displaying tracks




Tracks can be displayed.  
A track storage interval can be set by time or distance.


Procedure

1. Display the PLOT1 or PLOT2 screen.

2.  →  → 



Item	Description
TRACK LINE	Select a track drawing line.
	 A track is drawn with dots.
	 A track is drawn with a line.
	 A track is drawn with a dotted line.
TRACK PERIOD	Set a track storage interval.
	TIME Up to 60 minutes can be set in second units by MIN/SEC.
	DIST Up to 99.99NM can be set in 0.01NM units.
	OFF Not stored


3. Set a storage interval and confirm with .

### Deleting a track

1. Display the PLOT1 or PLOT2 screen.

2.  →  → 

When the following popup window is displayed, select “YES”.




When “YES” is selected, the entire track is deleted. Partial deletion is not allowed.

## 4.8.8 Displaying an own ship vector and a distance circle

When a radius is specified, a circle is displayed positioning own ship at the centre. The range that can be set is from 0.1NM to 9.9NM.


By setting a time, a vector line up to the position where the ship reaches within the set time can be displayed. The time can be set within the range from 0.1 to 9.9 minutes.



### Procedure

1. Display the PLOT1 or PLOT2 screen.

2. **FUNC** → **PLOT** → **OWN SHIP**



Item	Description
OWN CIRCLE	Set a distance circle from own ship.
RADIUS(NM)	Displayed when OWN CIRCLE is set to ON. Input a radius of the distance circle.
OWN VECTOR	Set an own ship's vector.
TIME(min)	Displayed when OWN VECTOR is set to ON. Displays the vector line up to the position that is reached within the time that is set.

3. Set a radius and a time and confirm the setting with **✓**.



## 4.8.9 Setting symbols to display/non-display


- Symbols that are displayed on a plotting screen can be set to non-display individually.
- Set the symbols that are not to be displayed to "OFF".
- Set the symbols that are to be displayed to "ON".
- The following symbols can be set to display/non-display.  
Waypoint, waypoint number, mark, event, event/mark number, track, arrival circle, route width, scale bar, symbol information, cursor position information, grid line, grid latitude, and grid longitude

### Procedure

1. Display the PLOT1 or PLOT2 screen.

2.  →  → 

3. Set the items to be displayed to "ON".



4. Confirm the setting with .

## 4.8.10 Displaying symbol information


When the cursor is moved to a waypoint, an event, or mark symbol, the contents of each symbol are displayed.

### Procedure

1. Display the PLOT1 or PLOT2 screen.

2.  →  → A cursor is displayed...

3. Move the cursor to symbol whose information is to be displayed.



When a water temperature, a depth, and a current are received from external equipment, the water temperature, depth, and current at the storing of EVENT can be displayed. However, the external equipment must be connected.

To clear symbol information, move the cursor from the symbol.

To edit the information, tap "EDIT" and to clear the information, tap "CLR".

## 4.8.11 Changing a background colour


A background colour of a plotting screen can be changed.  
The colors that can be set are DARK BLUE and WHITE.


Procedure

1. Display the PLOT1 or PLOT2 screen.


2.  →  → 

3. Select a background colour.

4. Confirm the selection with  .



DARK BLUE




WHITE


## 4.9 Setting MOB

- MOB (Man-overboard) stores the position when a person or a material item fell overboard, by executing the MOB function. This function enables the ship to return to the position quickly.
- The MOB function is available on all the screens.
- When MOB is executed, a plotting screen is displayed automatically, the MOB mark is displayed, indicating the bearing and distance from the current position to the man-overboard position.


### Procedure


1. Tap .

Countdown for 5 seconds starts at the bottom right corner of the screen. When  is tapped again within 5 seconds, the MOB function is cancelled.



### Ending MOB

1. Tap  again.
2. When the following popup window is displayed, select "YES".



## 4.10 Setting Alerts

Fifteen types of alerts can be set. ON/OFF setting and buzzer ON/OFF can be set individually. The alerts that can be set are outlined below.



- (1) SYSTEM: The alert is issued at the occurrence of non-position fixing.
- (2) ARRIVAL/ANCHOR: The alert is issued when the ship arrives at or crosses the track of the arrival circle radius.  
Arrival and cross-track cannot be set concurrently.
- (3) XTD/BOUNDARY: The alert is issued when the ship crosses from or approached the route width.  
Cross-track and approach cannot be set concurrently.
- (4) HDOP: The alert is issued when the HDOP value exceeds the setting value.
- (5) SPEED: When the speed reaches within the setting range, the alert is issued.
- (6) TRIP: The alert is issued when the trip exceeds the setting value.
- (7) EARLY COURSE CHANGE: The alert is issued when the time for reaching the wheel over point becomes below the setting value.
- (8) END OF TRACK: The alert is issued when the time for reaching the final waypoint is below the setting value.
- (9) ARRIVED AT WOL: The alert is issued when the ship reaches the wheel over point.
- (10) ACTUAL COURSE CHANGE: The alert is issued 30 seconds before the ship reaches the wheel over point.
- (11) TEMP: The alert is issued when the water temperature comes within the setting range.
- (12) DEPTH: The alert is issued when the water depth comes within the setting range.
- (13) DGPS: The alert is issued when position fixing is changed from GPS to DGPS or from DGPS or GPS.
- (14) BUFFER: The alert is issued at the occurrence of a built-in buffer unit error.
- (15) )POWER: The alert is issued at the occurrence of an external power supply error. External equipment is required for water temperature and water depth alerts.


### 4.10.1 Setting alert/buzzer sounds

To set an alert, a password is necessary. For the input method, refer to “4.2.11 Entering a password with CODE INPUT”.

Procedure


1. Enter a password by referencing “4.2.11. Entering a password with CODE INPUT”.  
Password: 1650

2.  →  → An alert list is displayed.



### (1) Setting the SYSTEM alert

a) Tap 



Item	Description
SET	Sets alert notification to ON/OFF. ON: Notifies the occurrence of an alert. OFF: Sets alert to OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

### (2) Setting ARRIVAL/ANCHOR alerts

The alert is issued when the ship arrives at or crossed the arrival circle radius that was set in the route. If the arrival circle radius is not set in the route, the alert is issued when the ship reaches the arrival circle radius that is set as the route initial value.

Arrival and cross-track cannot be set concurrently.

a) Tap 

Item	Description
SET	Sets alert notification to ON/OFF. ARRIVAL: Notifies the waypoint arrival alert. ANCHOR: Notifies the waypoint cross-track alert. OFF: Sets the alert to OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

### (3) Setting XTD/BOUNDARY alerts

The alert is issued when the ship cross-tracks from or approaches the route width that was set in the route. When the route width is not set in the route, an alert is issued when the ship cross-tracks from or enters in the route width that is set as the initial value in the route.

Cross-track and approach cannot be set concurrently.

a) Tap 

Item	Description
SET	Sets alert notification to ON/OFF. XTD: Notifies a cross-track distance alert. BOUNDARY: Notifies a route approach alert. OFF: Sets the alert to OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

#### (4) Setting the HDOP alert

a) Tap  .

Item	Description
SET	Sets alert notification to ON/OFF. THRESHOLD: The alert is issued when HDOP exceeded the threshold value. OFF: Sets the alert to OFF.
THRESHOLD	Sets a HDOP threshold value. This item is not displayed when SET is OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

#### (5) Setting the SPEED alert

a) Tap  .

Item	Description
SET	Sets alert notification to ON/OFF. OVER: The alert is issued when the ship speed exceeds the set speed. UNDER: The alert is issued when the ship speed is below the set speed. IN RANGE: The alert is issued when the ship speed is within the set speed range. OUT RANGE: The alert is issued when the ship speed is outside of the set ship speed range. OFF: Sets the alert to OFF.
THRESHOLD	Set a ship speed threshold value when selecting "OVER"/"UNDER" in "SET".
THRESHOLD(OVER) THRESHOLD(UNDER)	Set an upper limit and a lower limit of the ship speed range when selecting "IN RANGE"/"OUT RANGE" in "SET".
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

#### (6) Setting the TRIP alert

a) Tap  .

Item	Description
SET	Sets alert notification to ON/OFF. THRESHOLD: The alert is issued when the trip exceeds the set trip. OFF: Sets the alert to OFF.
THRESHOLD	Set a threshold value of the trip. This item is not displayed when SET is OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

**(7) Setting the EARLY COURSE CHANGE alert**

a) Tap 

Item	Description
SET	Sets alert notification to ON/OFF. THRESHOLD: The alert is issued when the time to reach the Wheel Over Point is less than the threshold value. OFF: Sets the alert to OFF.
THRESHOLD	Set a threshold value of EARLY COURSE CHANGE. A value from 3 minutes to 6 minutes can be set. This item is not displayed when SET is OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

**(8) Setting the END OF TRACK alert**

a) Tap 


Item	Description
SET	Sets alert notification to ON/OFF. THRESHOLD: The alert is issued when the time to reach the final waypoint is less than the threshold value. OFF: Sets the alert to OFF.
THRESHOLD	Set a threshold value of END OF TRACK. A value from 3 minutes to 6 minutes can be set. This item is not displayed when SET is OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

**(9) Setting the ARRIVED AT WOL alert**

a) Tap 

Item	Description
SET	Sets alert notification to ON/OFF. ON: Notifies the alert. OFF: Sets the alert to OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

**(10) Setting the ACTUAL COURSE CHANGE alert**

a) Tap 

Item	Description
SET	Sets alert notification to ON/OFF. ON: Notifies the alert. OFF: Sets the alert to OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

## (11) Setting the water temperature alert

a) Tap  .

Item	Description
SET	Sets alert notification to ON/OFF. OVER: The alert is issued when the water temperature exceeds the set temperature. UNDER: The alert is issued when the water temperature is below the set temperature. IN RANGE: The alert is issued when the water temperature is within the set temperature range. OUT RANGE: The alert is issued when the water temperature is outside of the set water temperature range. OFF: Sets the alert to OFF.
THRESHOLD THRESHOLD(OVER) THRESHOLD(UNDER)	Set a water temperature threshold value when selecting "OVER"/"UNDER" in "SET".  Set an upper limit and a lower limit of the water temperature range when selecting "IN RANGE"/"OUT RANGE" in "SET".
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

The water temperature alert requires external equipment.

## (12) Setting the water depth alert

a) Tap  .

Item	Description
SET	Sets alert notification to ON/OFF. OVER: The alert is issued when the water depth exceeds the set depth. UNDER: The alert is issued when the water depth is below the set depth. IN RANGE: The alert is issued when the water depth is within the set water depth range. OUT RANGE: The alert is issued when the water depth is outside of the set water depth range. OFF: Sets the alert to OFF.
THRESHOLD THRESHOLD(OVER) THRESHOLD(UNDER)	Set a water depth threshold value when selecting "OVER"/"UNDER" in "SET".  Set an upper limit and a lower limit of the water depth range when selecting "IN RANGE"/"OUT RANGE" in "SET".
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

The water depth alert requires external equipment.



**(13) Setting the DGPS alert**

a) Tap  .

Item	Description
SET	Sets alert notification to ON/OFF. GPS→DGPS: The alert is issued when the positioning system is changed from GPS to DGPS. DGPS→GPS: The alert is issued when the positioning system is changed from DGPS to GPS. GPS⇔DGPS: The alert is issued when the positioning system is changed from GPS to DGPS or DGPS to GPS. OFF: Sets the alert to OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

The DGPS alert is not notified to external equipment.

**(14) Setting the BUFFER alert**

a) Tap  .

Item	Description
SET	Sets alert notification to ON/OFF. ON: Notifies the alert. OFF: Sets the alert to OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

**(15) Setting the POWER alert**

a) Tap  .

Item	Description
SET	Sets alert notification to ON/OFF. ON: Notifies the alert. OFF: Sets the alert to OFF.
SOUND	Sets the buzzer sound upon the issuance of an alert to ON/OFF. ON: When an alert is issued, the alert is notified with a buzzer sound. OFF: Even if an alert is issued, a buzzer sound is not emitted.

3. Confirm the settings with  .

## 4.11 Alert List

The alerts that have occurred so far and the alert that is occurring, and the alerts that occurred in LAN can be displayed.


### 4.11.1 Displaying alert history

The alerts that have occurred so far can be displayed.

Up to 100 alerts can be displayed. If the number of alerts exceeds 100, the existing alerts are overwritten from the oldest one.

Procedure

1.  →  → 



Rad :Alarm  
Orange :Warning  
Yellow :Caution  
Green :Recovery


### 4.11.2 Displaying the alert that is occurring

The alert that is occurring can be displayed.

After the alert is resolved, the alert is deleted from the alert list.

Procedure

1.  →  → 



### 4.11.3 Displaying the alerts that occurred in LAN

The number of errors that occurred in LAN1/LAN2 is displayed.  
The error count is cleared when the power is turned off.

#### Procedure


1.  → 

(1) Displaying the error count of LAN1

a) Tap 

(2) Displays the error count of LAN2

a) Tap 



#### Clearing an alert

1. Enter a password by referencing “4.2.11 Entering a password in CODE INPUT”.  
Password: 1650

2.  →  →  → 

To clear the LAN2 alert list, select 

## 4.12 Initial Settings of GNSS/Beacon/SBAS

Set the GNSS sensor.

JLR-4350 supports multi-GNSS.

The available GNSS system combinations are as follows.

- (1) GPS mode
  - a) GPS
- (2) Multi-GNSS mode
  - a) GPS+QZSS
  - b) GPS+GLONASS
  - c) GPS+QZSS
  - d) GPS+QZSS+GLONASS
  - e) GPS+QZSS+BeiDou

Even in multi-GNSS mode also, GLONASS and BeiDou cannot be used concurrently.

DGLONASS and DBeiDou are not supported. When using DGPS by SBAS/beacon, use it in GPS mode.

In multi-GNSS mode also, position fixing is performed without using the systems that cannot be received by the satellites.

### Memo

GPS: Global Positioning System. Positioning system that is operated by the U.S.A.

QZSS: Quasi-Zenith Satellite System (Michibiki). Positioning system that is operated by Japan.

GLONASS: Global Navigation Satellite System. Positioning system that is operated by Russia.

BeiDou: Positioning system that is operated by China.

In JLR-4350, only QZSS No.1 can be used. Correction data cannot be received from QZSS.

### 4.12.1 Setting a positioning system

Select a GNSS system to be used.

In the processor with two sensors installed, the sensors must be set individually.

In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2.

Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".

Password: 1650

2.  →  →  → 

GPS MODE	Description
GPS	Operates in GPS mode. Only GPS is used. To perform DGPS by SBAS/beacon, set "GPS".
GPS+QZSS	Operates in multi-GNSS mode. GPS and QZSS are used concurrently.
GPS+GLONASS	Operates in multi-GNSS mode. GPS and GLONASS are used concurrently.
GPS+BDS	Operates in multi-GNSS mode. GPS and BeiDou are used concurrently.
GPS+QZSS+GLONASS	Operates in multi-GNSS mode. GPS, QZSS, and GLONASS are used concurrently.
GPS+QZSS+BDS	Operates in multi-GNSS mode. GPS, QZSS, and BeiDou are used concurrently.

### Memo

When a positioning system is changed, non-positioning is set temporarily. Although the condition is rectified immediately, note that the information to the external equipment that is connected is also set to non-positioning.

## 4.12.2 Setting a position fixing mode

A position fixing mode can be selected from Automatic, 3-dimensional position fixing, and 2-dimensional position fixing.

For a processor with two sensors connected, the sensors must be set individually. In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2 also.

### Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650

2. 

FIX MODE	Description
AUTO	Switches to the optimum position fixing mode automatically from the 3-dimensional position fixing or 2-dimensional position fixing mode.
2D	Positions in 2-dimensional position fixing mode.
3D	Positions in 3-dimensional position fixing mode.

## 4.12.3 Setting an elevation mask

Set an elevation mask.

When an elevation mask is set, the satellites of the elevations lower than the set value are not used for position fixing.

For a processor with two sensors connected, the sensors must be set individually. In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2 also.

### Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650

2. 

ELV MASK	Description
SAT ELV MASK	Set an elevation mask. Set an elevation within the range from 5 to 89 degrees.

#### 4.12.4 Setting HDOP

Set a HDOP limit of the sensor. When HDOP exceeded the set value, the system is set to a non-position fixing mode.

For a processor with two sensors connected, the sensors must be set individually. In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2 also.

##### Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650



HDOP	Description
HDOP	Set the threshold value of HDOP. Select 4, 10, or 20.

#### 4.12.5 Setting position, speed, and course smoothing

Smoothing can be applied to the position that is fixed, speed, and course for the smooth changes. If the smoothing value is increased, processing becomes smoother, however, the trackability deteriorates. If the smoothing value is reduced, changes increase, however, the trackability improves. Set the optimum value according to the purpose.

JLR-4350 supports individual smoothing of position, speed, and course.

For a processor with two sensors connected, the sensors must be set individually. In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2 also.

##### Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650



SMOOTH	Description
POSN SMOOTHING	Applies smoothing to position changes. A value between 0 second and 99 seconds can be set.
SPEED SMOOTHING	Applies smoothing to speed changes. A value between 0 second and 99 seconds can be set.
COURSE SMOOTHING	Applies smoothing to course changes. A value between 0 second and 99 seconds can be set.

#### Memo

When the smoothing value is increased, the trackability of quick turning and sudden speed change deteriorates.

Normally, the setting of 10 seconds or less is recommended. The default value is 10 seconds. When setting a higher value, adequate caution is necessary.

## 4.12.6 Setting RAIM

RAIM (Receiver Autonomous Integrity Monitoring) checks the accuracy of GPS with the accuracy level and displays the status.

When the reliability of the error that was obtained is 95% or higher, the state is displayed as "SAFE" or "UNSAFE". When the reliability is 95% or lower, "CAUTION" is displayed.

SAFE: The position error is within the set accuracy level.

CAUTION: Cannot calculate with the set accuracy level.

UNSAFE: The position error exceeded the set accuracy level.

An accuracy level of RAIM can be set.

An accuracy level can be selected from OFF, 10m, 30m, 50m, and 100m.

To perform GPS independent position fixing, set 30m or more. If GPS independent position fixing is performed by setting 10m, the reliability 95% is not satisfied and this may result in "CAUTION".

When OFF is set, "RAIM OFF" is displayed on the screen, and the RAIM function stops. Therefore, when RAIM is OFF, the system cannot perform calculation as to whether the reliability is within the accuracy level.

For a processor with two sensors connected, the sensors must be set individually.

In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2 also.

Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".

Password: 1650

2. 

RAIM	Description
RAIM ACCURACY LEVEL	Set an accuracy level of RAIM. Select from OFF, 100m, 50m, 30m, and 10m.

### Memo

RAIM

RAIM is the abbreviation of Receiver Autonomous Integrity Monitoring and checks, in the receiver, if the position accuracy that was fixed by GNSS is within the necessary accuracy.

## 4.12.7 Setting a geodetic system

A geodetic system of the position that was fixed can be set.

For the geodetic systems that can be set, refer to "Appendix 1 Geodetic System".

For a processor with two sensors connected, the sensors must be set individually.

In this example, sensor 1 connected. The same procedure is applied for setting sensor 2 also.

Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".

Password: 1650

2. 

DATUM	Description
DATUM	Set a geodetic system. For the geodetic systems that can be set, refer to "Appendix 1 Geodetic System".

## 4.12.8 Initialising sensors

Initialise sensors.

Set a general position and current date and time (UTC) of the sensor.

For a processor with two sensors connected, the sensors must be set individually.

In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2 also.

Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650



INIT	Description
QUADRANT	Select North latitude/South latitude/East latitude/West latitude of the sensor position.
LAT	Enter a general position (latitude) of the sensor.
LON	Enter a general position (longitude) of the sensor.
ANT HEIGHT	Enter a general position (height) of the sensor. For 2-dimensional position fixing, this height is used.
YEAR	Enter the current year (UTC).
MONTH	Enter the current month (UTC).
DAY	Enter the current day (UTC).
HOURL	Enter the current hour (UTC).
MINUTE	Enter the current minute (UTC).

## 4.12.9 Setting a DGPS correction mode

A DGPS correction mode can be selected.

To perform DGPS correction, set the positioning system to "GPS".

In multi-GNSS mode, DGPS positioning cannot be performed.

If a correction mode is set in multi-GNSS mode, the positioning system is automatically set to "GPS".

JLR-4350 does not support DGLONASS and DBeiDou. Correction data of QZSS cannot be received.

For a processor with two sensors connected, the sensors must be set individually.

In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2 also.

Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650





DGPS	Description
AUTO	Selects beacon or SBAS automatically. When both a beacon and SBAS can be received, priority is given to a beacon. When neither a beacon nor SBAS can be received, GPS positioning is performed.
BEACON	Performs DGPS by using a beacon. When a beacon cannot be received, GPS positioning is performed.
SBAS	Performs DGPS by SBAS. When SBAS cannot be received, GPS positioning is performed.
OFF	DGPS positioning is not performed.

### Memo

- When a correction mode is set in multi-GNSS mode, the positioning system is automatically switched to “GPS”. In this case, the system is set to non-positioning temporarily.
- When setting SBAS, it takes time to SBAS positioning because it searches SABS satellites.

## 4.12.10 Setting a beacon

Set DGPS by using a beacon.

For a processor with two sensors connected, the sensors must be set individually. In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2 also.

Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650



3. Set a beacon station selection method.

The selection method is outlined below.

- (1) **AUTO**: Selects an optimum beacon station from the GPS position.
- (2) **MANUAL**: Set a frequency and a baud rate of the beacon station manually.
- (3) **SEMI AUTO**: Automatically selects an optimum beacon station from up to three stations that are selected from the adjacent stations at random. JLR-8600 does not support this function.
- (4) **MONITOR**: JLR-8600 does not support this function.


### (1) **AUTO**

- a) Tap .

### (2) **MANUAL**

- a) Tap .

MANUAL	Description
FREQUENCY	Set a frequency.
BITRATE	Set a bit rate.

- b) Tap  to confirm the setting.

### 4.12.11 Setting SBAS

Set DGPS by SBAS.

For a processor with two sensors connected, the sensors must be set individually. In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2 also.

Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650

2. 

SBAS	Description
SAT SEARCH	AUTO: Selects an optimum SBAS satellite. MANUAL: Set a SBAS satellite number.
SBAS TYPE 0	When SAT SEARCH is set to MANUAL, set a SBAS satellite number. Set the use of TYPE 0 data (test data) to ON/OFF. Normally, set to "OFF".
RANGING	Set whether the SBAS satellite is used for positioning in the same way as the GPS satellite. Since JLR-4350 is not equipped with the ranging function, set to "OFF".

### 4.12.12 Displaying a beacon station list

JLR-8600 does not support this function.

Display a list of all the beacon stations.  
Up to 1024 stations can be displayed.

For a processor with two sensors connected, the sensors must be set individually. In this example, sensor 1 is connected. The same procedure is applied for setting sensor 2 also.

## 4.13 Configuring a System

### 4.13.1 Setting time difference/date display


A time difference between UTC and the local time can be set.  
In the case of a Japan time, enter +-9:00 since the time difference is +9 hours.  
When a time difference is set, the local time ("L") is displayed.  
A date/time display format can be selected.

#### Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650

2.  →  → 

Item	Description
TIME DIFF	Set a time difference.
DATE DISP	Select a date display format from the following: 'YY-MM-DD / DD MMM, 'YY / MMM DD, 'YY.
TIME DISP	24hr: Displays a time from 00:00 to 23:59. 12hr: Displays a time from AM/PM 00:00 to 11:59.

3. Confirm the setting with .

### 4.13.2 Setting units


Set units of ship speed, distance, height, depth, and temperature.

#### Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650

2.  →  → 

Item	Description
DIST/SPEED	Select a unit of a distance and a ship speed from NM, kn / km, km/h / mi, mi/h.
HIGHT/DPTH	Select a unit of a height and a depth from m / ft / fm.
SETTING METHOD	Case where fm is selected MANUAL: A converted value between fm and m can be set. DEFAULT: A converted value between fm and m is 1.8288m.
CONVERTED VALUE	Set a converted value between fm and m.
TEMP	Select a water temperature from Celsius/Fahrenheit.

3. Confirm the selecting with .

### 4.13.3 Setting magnetic correction


Magnetic correction can be applied to the route that was obtained from GPS.

Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650

2.  →  → 

MAG CORR	Description
AUTO	Performs correction automatically by calculating the correction value from the GPS position.
MANUAL	Performs correction with the correction value that was input. EAST/WEST: Select East longitude or West longitude. CORRECTION VALUE: Enter a correction value.
OFF	Does not perform correction.

3. Confirm the setting with .

### 4.13.4 Setting LORAN A/C





A position can be displayed or set with a time difference.

When LORAN A/C is set, all the position information is displayed in time difference.


Procedure

1. Enter a password by referencing "4.2.11 Entering a password in CODE INPUT".  
Password: 1650

2.  →  → 

LORAN	Description
LORAN A	  : Moves to the LORAN A setting screen.
LORAN C	  : Moves to the LORAN C setting screen.
OFF	Displays in the latitude/longitude.

3. Enter each setting value.

4. Tap  to confirm the setting.

#### Memo

- LORAN A stations that can be set  
1S1, 1S2, 1S3, 1S4, 1S6, 1L0, 1L1, 1L4, 1L5, 2S0, 2S1, 2S2, 2S3, 2S4, 2S5, 2S6, 2S7, 2H4, 2H5, 2H6
- LORAN C chains that can be set  
4990, 5930, 5970, 5980, 5990, 6730, 6731, 6780, 7001, 7030, 7170, 7270, 7430, 7499, 7930, 7950, 7960, 7970, 7980, 7990, 8000, 8290, 8390, 8830, 8930, 8970, 8990, 9007, 9610, 9930, 9940, 9960, 9970, 9980, 9990

### 4.13.5 Selecting a sensor

Specify which sensor will be displayed when two sensors are connected to one processor.

Procedure

1. Enter a password by referencing "4.2.11 Entering a password in CODE INPUT".  
Password: 1650

2.  →  → Select a sensor.


Item	Description
AUTO	Preferentially displays the sensor of sensor port 1.
SENSOR1	Displays the sensor connected to sensor port 1.
SENSOR2	Displays the sensor connected to sensor port 2.

## 4.14 Printing

When a network printer or serial printer (DPU-414/NKG-104) is connected, data is transmitted to the printer.

Procedure

1.  → 

Whenever  is tapped, printing data is transmitted.

### Memo

To perform printing, a port must be set in the installation.  
To perform interval printing, a port must be set in the installation.

## 4.15 Setting a Language

Select a display language.  
Japanese and English can be selected as the language.

Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650

2.  → 



## 4.16 Verifying Versions

Display version information of each unit.

Procedure

1. Enter a password by referencing "4.2.11. Entering a password with CODE INPUT".  
Password: 1650

2.  → 

3. Change the unit by using   .

## 4.17 Displaying a total trip distance



A total trip distance can be displayed on navigation aid screen 2.

A trip distance can be calculated on the total trip distance display screen.

Total trip distance calculation continues even if the trip distance measurement is interrupted.

### 4.17.1 Starting/stopping measurement of a trip distance

Procedure

1. Display navigation aid information screen 2 by selecting  and tapping  several times.


2.  → 

Trip distance calculation starts.

Tap the following to interrupt the calculation.

3.  → 

Trip distance calculation is interrupted.



By tapping  again, trip distance calculation can be restarted.

### 4.17.2 Resetting a trip distance

A trip distance can be reset even during the calculation of a total trip distance.

Even if a trip distance is reset, the total trip distance is not reset.

Procedure

1. Display navigation aid information screen 2 by selecting  and tapping  several times.

2.  → 



The trip distance is reset.

### 4.17.3 Resetting a total trip distance

A total trip distance can be reset.

Once a total trip distance is reset, it is reset to zero. The trip distance is also reset to zero.

Procedure

1. Display navigation aid information screen 2 by selecting  and tapping  several times.

2.  → 

The total trip distance is reset.





## 4.18 Measuring a trip distance

A trip distance can be measured on navigation aid screen 3.  
Two trip distances can be measured simultaneously in this equipment.


### 4.18.1 Starting/stopping measurement

Procedure



1. Display navigation aid information 3 screen by selecting  and tapping  several times.

2.  → 

Measurement of trip distance 1 starts.


To start measurement of trip distance 2, tap .

To stop measurement, do the following.

3. Display navigation aid information 3 screen by selecting  and tapping  several times.

4.  → 



Measurement of trip distance 1 stops.

To stop measurement of trip distance 2, tap .

### 4.18.2 Resetting a trip distance


A trip distance can be reset.  
Once a trip distance is reset, it is set to zero.

Procedure

1. Display navigation aid information screen 3 by selecting  and tapping  several times.

2.  → 

Trip distance 1 is reset.



To reset trip distance 2, tap .

## 4.19 Displaying external equipment information



Information on the ship speed through water, water temperature, water depth, and tidal stream can be displayed by entering it on the external equipment.

It is possible to make the setting of each layer of the tidal stream to be displayed. Up to five layers can be displayed.

### Procedure

1. Display navigation aid information screen 4 by selecting  and tapping  several times.

2.  → 

3. By using  or , select a layer (layer A to layer E) to be set.

Item	Description
SELECT	SELECT: Set a Layer Number. ALL: Displays the data having the highest Layer Number.
LAYER	Specify a Layer Number to be displayed.
DATA SETTING METHOD	SELECT: Set a data set number. ALL: Displays data of all the data set numbers.
DATA	Specify a data set number to be displayed.



### Recommended setting

Item	LAYER A	LAYER B	LAYER C	LAYER D	LAYER E
SELECT	SELECT	SELECT	SELECT	SELECT	SELECT
LAYER	1	2	3	4	5
DATA SETTING METHOD	ALL	ALL	ALL	ALL	ALL
DATA	—	—	—	—	—

## 4.20 Measuring a distance and an azimuth between two points

A distance and an azimuth between any two points can be measured.

Procedure

1. Display navigation aid information screen 5 by selecting  and tapping  several times.

2.  → 

3. Enter a start position.

4. Enter an end position.

5. Select a calculation method.





6. Tap  .



# Chapter 5 Maintenance and Inspection

Proper maintenance may greatly affect the lifespan of the equipment. In order to maintain the equipment in peak state, perform the following regularly.

 <span style="font-size: 24pt; font-weight: bold; margin-left: 10px;">WARNING</span>	
	<p>Do not perform internal inspections or modifications of the equipment. Inspection or modification by unauthorized personnel may result in fire, electric shock, or equipment failure. Please consult with JRC or an affiliate to perform internal inspections or repair.</p>

 <span style="font-size: 24pt; font-weight: bold; margin-left: 10px;">CAUTION</span>	
	<p>Do not use benzine, alcohol or thinner when caring this equipment. Doing so may result in removing the paint or changing of properties. Wipe off the grime lightly with a dry soft cloth.</p>
	<p>Use only the specified fuse. Failure to do so may result in fire or equipment failure.</p>
	<p>Use only the specified batteries. Failure to do so may result in equipment failure or malfunction.</p>

## 5.1 General Maintenance and Inspection

- Operate the equipment under standard power voltage levels (DC 10.8 - 31.2 V).
- The following shows general maintenance and inspection methods using standard tools.

No.	Item	Maintenance and Inspection
1	Cleaning	Clean the panel screen, knobs, and switches with a soft cloth. There are no gears in the unit, so oil lubrication is unnecessary.
2	Parts Securing	Check for loose screws, nuts, and connectors, and connect securely any that have loosened.

Perform inspection of the displayed items when the equipment is functioning normally. Compare operating results to the normal operation values in order to det

## 5.2 Alerts

Refer to "4.12 Alert Lists" and check if any alert is given or not. If it is, check the details referring to the list shown below.

### Main GPS Sensor

Alert Number	Alert text	Causes	Category	Priority
103	GPS1 no fix	No Fix	B	W
106	GPS2 no fix	No Fix	B	W
109	GPS3 no fix	No Fix	B	W
002	GPSn HDOP over	HDOP value has been exceeded setting level	B	C
003	GPSn no heading	No Heading	B	W
020	GPSn Ant open	GPS Antenna Open	B	W
021	GPSn Ant short	GPS Antenna Short	B	W
022	GPSn ROM error	GPS core ROM Error	B	W
023	GPSn RAM error	GPS core RAM Error	B	W
024	GPSn RTC error	GPS core RTC Error	B	W
025	CntIn ROM error	ROM Error (Controller of Sensor)	B	W
026	CntIn RAM error	RAM Error (Controller of Sensor)	B	W
027	CntIn FPGA error	FPGA Error (Controller of Sensor)	B	W
028	CntIn BACK error	Data Backup Error (Controller of Sensor)	B	W
029	GPSn ID error	Sensor Product information Error	B	C
030	GPSn core1 err	GPS core 1 Error	B	W
031	GPSn core2 err	GPS core 2 Error	B	W
032	GPSn core3 err	GPS core 3 Error	B	W
033	GPSn x gyro err	X axis Gyroscope Error	B	W
034	GPSn y gyro err	Y axis Gyroscope Error	B	W
035	GPSn z gyro err	Y axis Gyroscope Error	B	W
036	GPSn g sen err	Tilt meter Error	B	W
037	GPSn temp err	Temperature Sensor Error	B	W
038	GPSn inner err	Sensor inside Error	B	W
039	GPSn core1no prg	GPS core 1 program Error	B	W
040	GPSn core2no prg	GPS core 2 program Error	B	W
041	GPSn core3no prg	GPS core 3 program Error	B	W
042	GPSn Vibration	Excessive Vibration	B	W
043	GPSn ctrl no prg	Controller program Error	B	W

Sub GPS Sensor

Alert Number	Alert text	Causes	Category	Priority
113	GPS4 no fix	No Fix	B	W
116	GPS5 no fix	No Fix	B	W
119	GPS6 no fix	No Fix	B	W
012	GPSm HDOP over	HDOP value has been exceeded setting level	B	C
013	GPSm no heading	No Heading	B	W
060	GPSm Ant open	GPS Antenna Open	B	W
061	GPSm Ant short	GPS Antenna Short	B	W
062	GPSm ROM error	GPS core ROM Error	B	W
063	GPSm RAM error	GPS core RAM Error	B	W
064	GPSm RTC error	GPS core RTC Error	B	W
065	Cntlm ROM error	ROM Error (Controller of Sensor)	B	W
066	Cntlm RAM error	RAM Error (Controller of Sensor)	B	W
067	Cntlm FPGA error	FPGA Error (Controller of Sensor)	B	W
068	Cntlm BACK error	Data Backup Error (Controller of Sensor)	B	W
069	GPSm ID error	Sensor Product information Error	B	C
070	GPSm core1 err	GPS core 1 Error	B	W
071	GPSm core2 err	GPS core 2 Error	B	W
072	GPSm core3 err	GPS core 3 Error	B	W
073	GPSm x gyro err	X axis Gyroscope Error	B	W
074	GPSm y gyro err	Y axis Gyroscope Error	B	W
075	GPSm z gyro err	Y axis Gyroscope Error	B	W
076	GPSm g sen err	Tilt meter Error	B	W
077	GPSm temp err	Temperature Sensor Error	B	W
078	GPSm inner err	Sensor inside Error	B	W
079	GPSm core1no prg	GPS core 1 program Error	B	W
080	GPSm core2no prg	GPS core 2 program Error	B	W
081	GPSm core3no prg	GPS core 3 program Error	B	W
082	GPSm Vibration	Excessive Vibration	B	W
083	GPSm ctrl no prg	Controller program Error	B	W
103	GPS1 no fix	No Fix	B	W
106	GPS2 no fix	No Fix	B	W
109	GPS3 no fix	No Fix	B	W
113	GPS4 no fix	No Fix	B	W
116	GPS5 no fix	No Fix	B	W
119	GPS6 no fix	No Fix	B	W

Display Unit

Alert Number	Alert text	Causes	Category	Priority
150	DISP eMMC err	eMMC Deletion, Write Error	B	W
151	DISP E2PROM err	EEPROM Deletion, Write Error	B	W
152	DISP RAM err	RAM Read, Write Error	B	W
153	DISP SIO err	Serial Port Error	B	W
154	DISP LAN err	LAN Port Error	B	W

Processing Unit

Alert Number	Alert text	Causes	Category	Priority
200	Flash rom1 error	FLASH ROM Deletion, Write Error	B	W
201	Flash rom2 error	FLASH ROM2 Deletion, Write Error	B	W
202	Flash rom3 error	FLASH ROM3 Deletion, Write Error	B	W
203	RAM error	RAM Read, Write Error	B	W
204	SIO1 error	Serial Port 1 Error	B	W
205	SIO2 error	Serial Port 2 Error	B	W
206	SIO3 error	Serial Port 3 Error	B	W
207	SIO4 error	Serial Port 4 Error	B	W
208	SIO5 error	Serial Port 5 Error	B	W
209	SIO6 error	Serial Port 6 Error	B	W
210	SIO7 error	Serial Port 7 Error	B	W
211	SIO8 error	Serial Port 8 Error	B	W
212	SIO9 error	Serial Port 9 Error	B	W
213	SIO10 error	Serial Port 10 Error	B	W
214	SIO11 error	Serial Port 11 Error	B	W
215	SIO12 error	Serial Port 12 Error	B	W
216	SIO13 error	Serial Port 13 Error	B	W
217	LAN disp error	Display LAN port Error	B	W
218	LAN1 error	LAN 1 Error	B	W
219	LAN2 error	LAN 2 Error	B	W
220	BUFF error	Inside Buffer Error	B	W
221	main power fail	Main Power Unit Fail	B	W
230	GPSn no rx	Periodic input not possible from Main GPS Sensor	B	W
231	GPSn no res	Answer back not possible from Main GPS Sensor	B	W
232	GPSn data short	Main GPS data is invalid	B	W
233	GPSn no through	Sensor through data input not possible from Main GPS	B	W
240	GPSm no rx	Periodic input not possible from Sub GPS Sensor	B	W
241	GPSm no res	Answer back not possible from Sub GPS Sensor	B	W
242	GPSm data short	Sub GPS data is invalid	B	W
243	GPSm no through	Sensor through data input not possible from Sub GPS	B	W
250	Disp no rx	Input Data from Display not possible	B	W
251	Disp no res	Answer back from Display not possible	B	W
260	No mutal data	Unable to obtain mutual data	B	W
261	CCRP error	CCRP disagreement with other equipment	B	W
270	SIO1 HBT error	HBT can not receive for Serial Port 1	B	W
271	SIO2 HBT error	HBT can not receive for Serial Port 2	B	W
272	SIO3 HBT error	HBT can not receive for Serial Port 3	B	W
276	SIO7 HBT error	HBT can not receive for Serial Port 7	B	W
280	Temp alert	Temperature alert is occurred	B	W
281	Depth alert	Depth alert is occurred	B	A
282	Dist alert	Trip alert is occurred	B	W
283	SOG alert	Speed alert is occurred	B	W
284	Wind alert	Wind alert is occurred	B	W
300	Arrival wpt	Arrival at Waypoint	B	W
301	Anchor out	Anchor alert is occurred	B	A
302	Boundary	Boundary alert is occurred	B	W
303	Xtd	XTD alert is occurred	A	A
304	Early Crs change	Early course change	A	W/A
305	End of track	End of track	B	W
306	Arrived at wol	Arrived at WOL	B	W
307	Actual Crs chg	Actual course change	A	W/A



## 5.3 Troubleshooting

### WARNING



Never carry out internal inspection or repair of the equipment. Inspection or repair performed by anyone other than the specialized maintenance engineers may result in fire, electric shock, or failure. For inspection or repair, please contact us or your distributor.

For your reference, the guideline for detecting faulty sections is provided below.

Fault symptom	Possible cause/cause of failure	Action to be taken
The power is not supplied even if the power switch of the display unit is pressed.	The power is not supplied from the on-board power panel.	Check if the breaker and the power board are wired correctly.
	The power is not supplied from the power supply unit, which is the option.	Check if the power supply unit is wired correctly.
	The display is faulty.	Contact us or your distributor.
	The fuse of the processor is blown out.	After checking if the wiring is correct and replace the fuse.
	The main switch of the processor is set to OFF.	After checking if the wiring is correct, set the switch to ON.
	The LAN port for display connection on the processor is incorrect.	Connect to the correct LAN port.
LCD does not display a screen.	The display unit is faulty.	Contact us or your distributor.
	Power is not supplied to the display unit.	Check the cable connection.
The brightness is not changed.	The display unit is faulty.	Contact us or your distributor.
No buzzer sound is emitted.	The buzzer is faulty.	Contact us or your distributor.
	The buzzer is set to OFF.	Refer to 4.10.1 for the setting.
No key-tone is emitted.	The buzzer is faulty.	Contact us or your distributor.
	The key-tone is set to OFF.	Refer to 4.3.2 for the setting.
Symbols on the plot screen are not displayed.	The display of the symbols on the plot screen is set to OFF.	Refer to 4.8.9 for the setting.

Fault symptom	Possible cause/cause of failure	Action to be taken
Does not perform position fixing	The sensor is faulty.	Contact us or your distributor.
	The sensor is hidden behind the obstacle.	Move the sensor to the location free from obstacles.
	Noise is entered.	Move the sensor from the noise generating source.
	Power is not supplied to the sensor.	Check the cable connection. Check the output power from the processor.
Data is not received from the sensor to the processor.	The sensor cable is disconnected.	Check the cable connection.
	The connection terminal on the processor is incorrect.	Check the cable connection.
	Power is not supplied to the sensor.	Check the output power from the processor.
Data is not displayed.	The display is faulty.	Contact us or your distributor.
	The display cable is disconnected.	Check the cable connection.
Output to the external equipment does not function.	The setting of the output port is incorrect.	Check the port setting.
	The connection terminal on the processor is incorrect.	Check the cable connection.
	The processor is faulty.	Contact us or your distributor.
Reception from the external equipment does not function.	The setting of the input port is incorrect.	Check the port setting.
	The connection terminal on the processor is incorrect.	Check the cable connection.
	The processor is faulty.	Contact us or your distributor.
The built-in switch does not function.	The switch is faulty.	Contact us or your distributor.
	The setting of the switch port is incorrect.	Check the port setting.
	The connection terminal on the processor is incorrect.	Check the cable connection.
Output from the built-in buffer does not function.	The buffer is faulty.	Contact us or your distributor.
	The setting of the buffer port is incorrect.	Check the port setting.
	The connection terminal on the processor is incorrect.	Check the cable connection.
	The dip-switch setting is incorrect.	Check the dip-switch setting.
The route cannot be shared. The printer does not function.	The port setting is incorrect.	Check the port setting.
	The connection terminal on the processor is incorrect.	Check the cable connection.
	The processor is faulty.	Contact us or your distributor.
The printer does not function.	The setting of the printer is incorrect.	Check the printer setting.
	The connection terminal on the processor is incorrect.	Check the cable connection.
	The processor is faulty.	Contact us or your distributor.

## 5.4 Replacement Parts

### 5.4.1 Repair units

The following table shows the repair unit replacement units.

No.	Name	Model	Remarks
1	Receiver processing unit	CMJ-610	GPS sensor
2	Antenna radome replacement kit	MPTG32528	JLR-4350
3	Processing unit	CMJ-611	Processor
4	Terminal block	CMH-2500	NDC-4100
5	LCD panel kit	* * * *	Display unit
6	Control board	CMJ-612	NWZ-1650
7	Fuse	* * * *	Processor NDC-4100

To replace the sensor repair unit, also replace the radome and packing with the antenna radome replacement kit.

### 5.4.2 Regular replacement parts

No.	Name	Model	Replacement time	Remarks
1	LCD unit	* * * *	40,000 hours	About 5 years in continuous use as the guideline



# Chapter 6 After-Sales Service

## 6.1 Warranty

- Specific periods may vary based on our warranty policies, but the standard warranty period is **one year** from the date of purchase.

## 6.2 Repair parts stocking Period

- We keep functional repair parts for this equipment (parts necessary for the functioning of this equipment) in stock for 10 years from the discontinuation of production.

## 6.3 When Requesting Service

When you think the equipment is not operating properly, please read "5.3 Troubleshooting" carefully, and inspect the equipment again. If the problem persists, stop using the equipment, and consult your dealer, or a JRC branch or affiliate.

- **Repairs during the warranty period**  
Should a malfunction or failure occur when the equipment is operated according to the descriptions and instructions contained herein, it is repaired free of charge during the warranty period by JRC or another location specified by your dealer. However, any repair for failures resulting from misuse, negligence, or natural disasters, fire, or other Acts of God is charged.
- **Repairs after the warranty period**  
Repairs to restore the proper equipment operation can be made at a specified rate with the user's consent. In this case, the equipment can either be sent to JRC or an affiliate, or on-ship repairs can be performed at a location specified by JRC or a sales affiliate. Repairs which cannot be performed on-board the ship needs to be performed in a repair plant.
- **Information that needs to be provided when requesting service**
  - Name, model, production date, and serial number
  - Detailed description of the malfunction (alert number, etc.)
  - Name, address, and telephone number of your company or organization

## 6.4 Recommended Checks Inspection

Equipment performance is subject to degradation due to age and change of component conditions over time. In addition to your own routine check, additional inspection and maintenance is recommended. Please consult with your dealer or one of our local offices. Note that this inspection and maintenance is not free of charge.

If you have any other questions about after-sales service, please direct your inquiries to your dealer or nearest local office.

A list of branches is provided at the end of the "Contact List".



# Chapter 7 Disposal

## **WARNING**



When disposing of the used lithium battery, place insulating tape over the battery terminals, or otherwise insulate the battery. Failure to do so may result in heating, explosion, or fire due to a shorted battery.

### **7.1 Disposal of Equipment**

- Observe all rules and regulations of the local authorities when disposing of this equipment.

### **7.2 Disposal of Used Batteries**

This equipment contains a lithium battery.

- When disposing of the used lithium battery, place insulating tape over the battery terminals, or otherwise insulate the battery. Dispose of the battery properly as directed by the local authorities. Consult your dealer, our sales office, or the local authorities for further details on disposal methods.





# Chapter 8 Specification

## 8.1 NWZ-1650 DISPLAY UNIT

### 8.1.1 Basic

• Display Unit	6.5 inch Color LCD 640×480 dots
• Touch Screen	Available
• Brightness	1,000cd/m <sup>2</sup> (800cd/m <sup>2</sup> with Touch screen)
• Viewing Angle	80 degree at all angle
• Backlight	LCD and Key lighting
• Dimmer Levels	17 steps/OFF
• Data Input/Output	LAN × 1 IEC61162-1 input × 1
• Power Supply Voltage	DC12/24V (+30%,-10%)
• Power Consumption	less than 10W
• Dimension	160(W)×180(H)×50.5(D)mm (Not include Base)
• Mass	Approximately 2.0kg
• Software version	R56.00
• Viewing Distance	1m

### 8.1.2 Environment

• Operating Temperature	-15°C~+55°C
• Storage Temperature	-25°C~+70°C
• Vibration	IEC60945 Ed.4 conformant
• EMC	IEC60945 Ed.4 conformant
• Waterproofing	IP56 Permanent installation in an exposed section requires a waterproof cover.

## 8.2 JLR-4350 GPS Sensor

### 8.2.1 Basic

• GNSS	GPS/GLONASS/BeiDou Can not receive GLONASS and BeiDou at the same time.
• Maximum Number of Tracked Satellites	22 satellites
• Accuracy	GPS : 5m 2DRMS (HDOP ≤ 4 SA off) Beacon DGPS : 4m 2DRMS SBAS : 4m 2DRMS
• SBAS	WAAS、MSAS、EGNOS
• QZSS	QZSS(L1-C/A) No.1 Satellite only
• Geodetic datum	Selection among 49 geodetic datum (Default : WGS-84)
• Power Supply Voltage	DC12/24V (+30%,-10%)
• Power Consumption	less than 1.0W
• Dimensions	134(Φ)mm×129(H)mm
• Mass	Approximately 1.5kg
• Software version	R41.0

## 8.2.2 Environment

- Operating Temperature -25°C~+55°C
- Storage Temperature -40°C~+70°C
- Vibration IEC60945 ed.4 conformant
- EMC IEC60945 ed.4 conformant
- Waterproofing IP56

## 8.3 NDC-4100 Processor Unit

### 8.3.1 Basic

- Memories Waypoints 1000points maximum  
Event/Mark 1000points maximum (include MOB)  
Track 2000points maximum  
Route 100routes maximum
- Route plan 512 waypoints per one route
- Magnetic Variation Automatic or manual
- Navigation Calculation Grate circle or Rhumb line selectable
- Alert Arrival, Anchor, Boundary, XTD, No position fix, Speed, Trip, HDOP  
Temperature\*, Depth\*
- Plot Function Scale 0.2,0.5,1,2,5,10,20,50,100,200,300NM  
Interval 1~60min (1 sec) or 0.01~99.99NM (0.01NM) selectable
- Data Input/Output IEC61162-1 Output ×5, Input ×2  
IEC61162-2 Output ×1, Input ×1  
Buffer Unit: IEC61162-1 Output ×8  
LAN×2
- Dry Contact Output ×4, Input ×1
- Remote maintenance Available
- Unit Distance, Speed : NM, kn or km, km/h or mi, mi/h  
Height, Depth : m or ft or fm  
Temperature : °C or °F
- Loran C/A Latitude and Longitude can be converted into the Loran time difference
- Language Japanese or English
- 8ch Buffer Built-in
- 2ch Select Switch Built-in
- Power Supply Voltage DC12/24V (+30%,-10%)
- Power Consumption 15W 以下  
JLR-8600 : less than 25W
- Dimensions 264(W)mm×100(H)mm×281(D)mm
- Mass Approximately 2.2kg
- Software version R60.0

\* : External sensor must be connected

### 8.3.2 Environment

- Operating Temperature -15°C~+55°C
- Storage Temperature -25°C~+70°C
- Vibration IEC60945 ed.4 conformant
- EMC IEC60945 ed.4 conformant
- Waterproofing IP22

### 8.3.3 Interface

#### 1) Serial Transmission

Channel	Signal	Input / Output	Format
Data IN/OUT 1	RS-422	Input	IEC61162-2/NMEA
		Output	IEC61162-2/NMEA/JRC/SWITCH/SC-104
Data IN/OUT 2	RS-422	Input	IEC61162-1/NMEA
		Output	IEC61162-1/NMEA/JRC/SWITCH/SC-104
Data IN/OUT 3	RS-422	Input	IEC61162-1/NMEA
		Output	IEC61162-1/NMEA/JRC/SWITCH/SC-104
DATA OUT 4	RS-422	Output	IEC61162-1/NMEA/JRC/SWITCH/SC-104
DATA OUT 5	RS-422	Output	IEC61162-1/NMEA/JRC/SWITCH/SC-104
DATA OUT 6	RS-422	Output	IEC61162-1/NMEA/JRC/SWITCH/SC-104
Buffer Unit	RS-422	Output	IEC61162-1/NMEA
DATA IN/OUT 7	RS-232C	Input	IEC61162-1/NMEA
		Output	IEC61162-1/NMEA/Printer data for DPU-414

#### 1-1) NMEA

- Specification NMEA0183
- Version Ver1.5,2.1,2.3,4.0
- Bit Rate 4800,9600,19200,38400bps
- Data Bit 8bit
- Parity None
- Start Bit 1bit
- Stop Bit 1bit
- Output Sentence GGA,RMC, GLL,VTG,GSA,GSV,DTM,GBS,GRS,GST,ZDA,GNS,ALR,APB,BOD,BWC,BWR,RMB,XTE,ZTG,AAM,RTE,WPL,ACK HDT\*,THS\*,DBT\*,DPT\*,MTW\*,CUR\*,VBW\*,VHW\*
- Output Interval 1s,2s,3s,4s,5s,6s,7s,8s,9s,OFF
- Input Sentence HDT,THS,DBT,DPT,MTW,CUR,VBW,VHW,ACK,WPL,RTE,ALR

\*External sensor must be connected

Note) Some combinations of output sentence, bit rates, and output intervals may not be possible.

#### 1-2) IEC

- Specification IEC61162-1 Ed.5

#### 1-3)JRC

- Specification : JRC
- Bit Rate : 1200bps
- Data Bit : 8bit
- Parity : None
- Start Bit : 1bit
- Stop Bit : 2bit

#### 2) Dry Contact

Channel	Input / Output	None
Contact 1,2,3,4	Output	Alert, 200p/NM, 400p/NM, ACK
Contact 5	Input	ACK

#### 3)LAN

- Specification : IEC61162-450/JRC
- Bit Rate : 10/100Mbps
- Shared route : JRC Format
- Data output : NMEA,IEC



# Appendix

## Appendix 1 List of Geodetic System

Display	Setting		Geodetic System
W84	WGS-84	0	WGS-84
W72	WGS-72	1	WGS-72
TOY	JAPAN	2	Tokyo Datum
NAS	NAD27 USA	3	North American 1927 (USA)
NAS	NAD27 CAN	4	North American 1927 (Canada, Alaska)
EUR	EUROPE 50	5	Europe 1950 (Europe)
AUA	AUSTRALIA 66	6	Australian geodetic 1966 (Australia)
OGB	OSGB-36	7	Ordnance Survey of Great Britain (England)
008	NAD-83	8	NAD-83
ADI	ADI	11	Adindan (Ethiopia, Sudan)
ARF	ARF	12	ARC 1950 (Botswana)
AUG	AUG	13	Australian Geodetic 1984 (Australia)
BER	BER	14	Bermuda 1957 (Bermuda islands)
BOO	BOO	15	Bogota Observatory (Columbia)
CAI	CAI	16	Compo Inchauspe (Argentine)
CHI	CHI	17	Chatham 1971 (Chatham Islands)
CHU	CHU	18	Chua Astro (Paraguay)
COA	COA	19	Corrego Alegre (Brazil)
BAT	BAT	20	Djakarta (Vatavia) (Sumatra)
EUR	EUR	21	European 1979 (Europe)
GEO	GEO	22	Geodetic Datum 1949 (New Zealand)
GUA	GUA	23	Guam 1963 (Guam)
024	024	24	Hayford 1910 (Finland)
HJO	HJO	25	Hjorsey 1955 (Iceland)
IND	IND	26	Indian (India, Nepal)
IRL	IRL	27	Ireland 1965 (Ireland)
KEA	KEA	28	Kertau 1948 (West Malaysia, Singapore)
LCF	LCF	29	L.C.5 Astro (Cayman Brac island)
LIB	LIB	30	Liberia 1964 (Liberia)
LUZ	LUZ	31	Luzon (Philippines)
MER	MER	32	Merchich (Morocco)
MIN	MIN	33	Minna (Cameroon)
NAH	NAH	34	Nahrwan (Oman)
NAP	NAP	35	Naparima, BWI (Trinidad and Tobago)
OEG	OEG	36	Old Egyptian (Egypt)
OHA	OHA	37	Old Hawaiian (Hawaiian Islands )
PLN	PLN	38	Pico de las Nieves (Canary Islands)
PRP	PRP	39	Provisional south American 1956 (South America)
HIT	HIT	40	Provisional south Chilean 1963 (South Chile)
PUR	PUR	41	Puerto Rico (Puerto Rico, Virgin Islands)
QUO	QUO	42	Qornoq (South Greenland)
043	043	43	RT90 (Sweden)
SAO	SAO	44	Santa Braz (San Miguel, Santa Maria islands)
SAN	SAN	45	South American 1969 (South America)
046	046	46	Southwest Base (Faial, Gracinao, Pico, San Jorge, Terceira islands)
TIL	TIL	47	Timbalai 1948 (Brunei, Malaysia)
048	048	48	PZ-90.02
SPK	SPK	49	SK-42 (Pulkovo 42)

## Appendix 2 List of standard terms, units and abbreviations

Term	Abbreviation	Term	Abbreviation
Acknowledge	ACK	Calibrate	CAL
Acquire, Acquisition	ACQ	Cancel	CNCL
Acquisition Zone	AZ	Carried (for example, carried EBL origin)	C
Adjust, Adjustment	ADJ	Central Processing Unit	CPU
Aft	AFT	Centre	CENT
Alarm	ALARM	Change	CHG
Altitude	ALT	Circularly Polarised	CP
Amplitude Modulation	AM	Clear	CLR
Anchor Watch	ANCH	Closest Point of Approach	CPA
Antenna	ANT	Compact Disk Read Only Memory	CDROM
Anti Clutter Rain	RAIN	Consistent Common Reference Point	CCRP
Anti Clutter Sea	SEA	Consistent Common Reference System	CCRS
April	APR	Contrast	CONT
Audible	AUD	Coordinated Universal Time	UTC
August	AUG	Correction	CORR
Automatic	AUTO	Course	CRS
Automatic Frequency Control	AFC	Course Over the Ground	COG
Automatic Gain Control	AGC	Course Through the Water	CTW
Automatic Identification System	AIS	Course To Steer	CTS
Automatic Identification System – Search and Rescue Transmitter	AIS-SART	Course Up	C UP <sup>a</sup>
Automatic Radar Plotting Aid	ARPA	Cross Track Distance	XTD
Autopilot	AP	Cursor	CURS
Auxiliary System/Function	AUX	Dangerous Goods	DG
Available	AVAIL	Date	DATE
Azimuth Indicator	AZI	Day	DAY
Background	BKGND	Dead Reckoning, Dead Reckoned Position	DR
Bearing	BRG	December	DEC
Bearing Waypoint To Waypoint	BWW	Decrease	DECR
Bow Crossing Range	BCR	Delay	DELAY
Bow Crossing Time	BCT	Delete	DEL
Brilliance	BRILL	Departure	DEP
Built in Test Equipment	BITE	Depth	DPTH

<b>Term</b>	<b>Abbreviation</b>
<i>Destination</i>	<i>DEST</i>
<i>Deviation</i>	<i>DEV</i>
<i>Differential GLONASS</i>	<i>DGLONASS<sup>a</sup></i>
<i>Differential GNSS</i>	<i>DGNSS<sup>a</sup></i>
<i>Differential GPS</i>	<i>DGPS<sup>a</sup></i>
<i>Digital Selective Calling</i>	<i>DSC</i>
<i>Display</i>	<i>DISP</i>
<i>Distance</i>	<i>DIST</i>
<i>Distance Root Mean Square</i>	<i>DRMS<sup>a</sup></i>
<i>Distance To Go</i>	<i>DTG</i>
<i>Drift</i>	<i>DRIFT</i>
<i>Dropped (for example, dropped EBL origin)</i>	<i>D</i>
<i>East</i>	<i>E</i>
<i>Echo Reference</i>	<i>REF</i>
<i>Electronic Bearing Line</i>	<i>EBL</i>
<i>Electronic Chart Display and Information System</i>	<i>ECDIS</i>
<i>Electronic Chart System</i>	<i>ECS</i>
<i>Electronic Navigational Chart</i>	<i>ENC</i>
<i>Electronic Position Fixing System</i>	<i>EPFS</i>
<i>Electronic Range and Bearing Line</i>	<i>ERBL</i>
<i>Emergency Position Indicating Radio Beacon</i>	<i>EPIRB</i>
<i>Emergency Position Indicating Radio Beacon – AIS</i>	<i>EPIRB-AIS</i>
<i>Enhance</i>	<i>ENH</i>
<i>Enter</i>	<i>ENT</i>
<i>Equipment</i>	<i>EQUIP</i>
<i>Error</i>	<i>ERR</i>
<i>Estimated Position</i>	<i>EP</i>
<i>Estimated Time of Arrival</i>	<i>ETA</i>
<i>Estimated Time of Departure</i>	<i>ETD</i>
<i>European Geo-Stationary Navigational Overlay System</i>	<i>EGNOS</i>
<i>Event</i>	<i>EVENT</i>
<i>Exclusion Zone</i>	<i>EZ</i>
<i>External</i>	<i>EXT</i>
<i>F-Band (applies to radar)</i>	<i>F-Band</i>
<i>February</i>	<i>FEB</i>
<i>Foreword</i>	<i>FWD</i>
<i>Fishing Vessel</i>	<i>FISH</i>

<b>Term</b>	<b>Abbreviation</b>
<i>Fix</i>	<i>FIX</i>
<i>Forward</i>	<i>FWD</i>
<i>Frequency</i>	<i>FREQ</i>
<i>Frequency Modulation</i>	<i>FM</i>
<i>Full</i>	<i>FULL</i>
<i>Gain</i>	<i>GAIN</i>
<i>Geographics</i>	<i>GEOG</i>
<i>Geometric Dilution Of Precision</i>	<i>GDOP</i>
<i>Global Maritime Distress and Safety System</i>	<i>GMDSS</i>
<i>Global Navigation Satellite System</i>	<i>GNSS</i>
<i>Global Orbiting Navigation Satellite System</i>	<i>GLONASS</i>
<i>Global Positioning System</i>	<i>GPS</i>
<i>Great Circle</i>	<i>GC</i>
<i>Grid</i>	<i>GRID</i>
<i>Ground</i>	<i>GND</i>
<i>Grounding Avoidance System</i>	<i>GAS</i>
<i>Group Repetition Interval</i>	<i>GRI</i>
<i>Guard Zone</i>	<i>GZ</i>
<i>Gyro</i>	<i>GYRO</i>
<i>Harmful Substances (applies to AIS)</i>	<i>HS</i>
<i>Head Up</i>	<i>H UP<sup>a</sup></i>
<i>Heading</i>	<i>HDG</i>
<i>Heading Control System</i>	<i>HCS</i>
<i>Heading Line</i>	<i>HL</i>
<i>High Frequency</i>	<i>HF</i>
<i>High Speed Craft</i>	<i>HSC</i>
<i>Horizontal Dilution Of Precision</i>	<i>HDOP</i>
<i>Identification</i>	<i>ID</i>
<i>In</i>	<i>IN</i>
<i>Increase</i>	<i>INCR</i>
<i>Indication</i>	<i>IND</i>
<i>Information</i>	<i>INFO</i>
<i>Infrared</i>	<i>INF RED</i>
<i>Initialisation</i>	<i>INIT</i>
<i>Input</i>	<i>INP</i>
<i>Input/Output</i>	<i>I/O</i>
<i>Integrated Navigation System</i>	<i>INS</i>
<i>Integrated Radio Communication System</i>	<i>IRCS</i>
<i>Interference Rejection</i>	<i>IR</i>

Term	Abbreviation	Term	Abbreviation
<i>Interswitch</i>	<i>ISW</i>	Not Less Than	NLT
<i>Interval</i>	<i>INT</i>	Not More Than	NMT
<i>January</i>	<i>JAN</i>	Not Under Command	NUC
<i>July</i>	<i>JUL</i>	<i>November</i>	<i>NOV</i>
<i>June</i>	<i>JUN</i>	<i>October</i>	<i>OCT</i>
Label	LBL	<i>Off</i>	<i>OFF</i>
<i>Latitude</i>	<i>LAT</i>	<i>Officer On Watch</i>	<i>OOW</i>
Latitude/Longitude	L/L	<i>Offset</i>	<i>OFFSET</i>
Leeway	LWY	<i>On</i>	<i>ON</i>
<i>Limit</i>	<i>LIM</i>	<i>Out/Output</i>	<i>OUT</i>
<i>Line Of Position</i>	<i>LOP</i>	<i>Own Ship</i>	<i>OS</i>
<i>Log</i>	<i>LOG</i>	<i>Panel Illumination</i>	<i>PANEL</i>
<i>Long Pulse</i>	<i>LP</i>	<i>Parallel Index Line</i>	<i>PI</i>
<i>Long Range</i>	<i>LR</i>	<i>Past Positions</i>	<i>PAST POSN</i>
<i>Longitude</i>	<i>LON</i>	<i>Passenger Vessel</i>	<i>PASSV</i>
<i>Loran</i>	<i>LORAN</i>	<i>Performance Monitor</i>	<i>MON</i>
<i>Lost Target</i>	<i>LOST TGT</i>	<i>Permanent</i>	<i>PERM</i>
<i>Low Frequency</i>	<i>LF</i>	<i>Person Overboard</i>	<i>POB</i>
<i>Magnetic</i>	<i>MAG</i>	<i>Personal Identification Number</i>	<i>PIN</i>
Man Overboard	MOB	<i>Pilot Vessel</i>	<i>PILOT</i>
<i>Manoeuvre</i>	<i>MVR</i>	<i>Port/Portside</i>	<i>PORT</i>
<i>Manual</i>	<i>MAN</i>	<i>Position</i>	<i>POSN</i>
<i>Map(s)</i>	<i>MAP</i>	<i>Positional Dilution Of Precision</i>	<i>PDOP</i>
<i>March</i>	<i>MAR</i>	<i>Power</i>	<i>PWR</i>
<i>Maritime Mobile Services Identity number</i>	<i>MMSI</i>	<i>Predicted</i>	<i>PRED</i>
<i>Maritime Pollutant (applies to AIS)</i>	<i>MP</i>	<i>Predicted Area of Danger</i>	<i>PAD</i>
<i>Maritime Safety Information</i>	<i>MSI</i>	<i>Predicted Point of Collision</i>	<i>PPC</i>
<i>Marker</i>	<i>MKR</i>	<i>Pulse Length</i>	<i>PL</i>
<i>Master</i>	<i>MSTR</i>	<i>Pulse Modulation</i>	<i>PM</i>
<i>Maximum</i>	<i>MAX</i>	<i>Pulse Repetition Frequency</i>	<i>PRF</i>
<i>May</i>	<i>MAY</i>	<i>Pulse Repetition Rate</i>	<i>PRR</i>
<i>Medium Frequency</i>	<i>MF</i>	<i>Pulses Per Revolution</i>	<i>PPR</i>
<i>Medium Pulse</i>	<i>MP</i>	<i>Racon</i>	<i>RACON</i>
<i>Menu</i>	<i>MENU</i>	<i>Radar</i>	<i>RADAR</i>
<i>Minimum</i>	<i>MIN</i>	<i>Radar Plotting</i>	<i>RP</i>
<i>Missing</i>	<i>MISSING</i>	<i>Radar Transponder</i>	<i>TPR</i>
<i>Mute</i>	<i>MUTE</i>	<i>Radius</i>	<i>RAD</i>
<i>Navigation</i>	<i>NAV</i>	<i>Rain</i>	<i>RAIN</i>
<i>Night</i>	<i>NT</i>	<i>Range</i>	<i>RNG</i>
<i>Normal</i>	<i>NORM</i>	<i>Range Rings</i>	<i>RR</i>
<i>North</i>	<i>N</i>	<i>Raster Chart Display System</i>	<i>RCDS</i>
<i>North Up</i>	<i>N UP<sup>a</sup></i>		










<b>Term</b>	<b>Abbreviation</b>	<b>Term</b>	<b>Abbreviation</b>
<i>Raster Navigational Chart</i>	RNC	<i>Synchronised/ Synchronous</i>	SYNC
<i>Rate Of Turn</i>	ROT	<i>System Electronic Navigational Chart</i>	SENC
<i>Real-time Kinematic</i>	RTK	<i>Target</i>	TGT
<i>Receive</i>	RX <sup>a</sup>	<i>Target Tracking</i>	TT
<i>Receiver</i>	RCDR	<i>Test</i>	TEST
<i>Receiver Autonomous Integrity Monitoring</i>	RAIM	<i>Time</i>	TIME
<i>Reference</i>	REF	<i>Time Difference</i>	TD
<i>Relative</i>	REL <sup>b</sup>	<i>Time Dilution Of Precision</i>	TDOP
<i>Relative Motion</i>	RM	<i>Time Of Arrival</i>	TOA
<i>Revolutions per Minute</i>	RPM	<i>Time Of Departure</i>	TOD
<i>Rhumb Line</i>	RL	<i>Time to CPA</i>	TCPA
<i>Roll On/Roll Off Vessel</i>	RoRo	<i>Time To Go</i>	TTG
<i>Root Mean Square</i>	RMS	<i>Time to Wheel Over Line</i>	TWOL
<i>Route</i>	ROUTE	<i>Track</i>	TRK
<i>Safety Contour</i>	SF CNT	<i>Track Control System</i>	TCS
<i>Sailing Vessel</i>	SAIL	<i>Tracking</i>	TRKG
<i>Satellite</i>	SAT	<i>Trail(s)</i>	TRAIL
<i>S-Band</i>	S-BAND	<i>Transmit and Receive</i>	TXRX <sup>a</sup>
<i>Scan to Scan</i>	SC/SC	<i>Transceiver</i>	TCVR
<i>Search And Rescue</i>	SAR	<i>Transferred Line Of Position</i>	TPL
<i>Search And Rescue Transponder</i>	SART	<i>Transmit</i>	TX
<i>Search And Rescue Vessel</i>	SARV	<i>Transmitter</i>	TMTR
<i>Select</i>	SEL	<i>Transmitting Heading Device</i>	THD
<i>September</i>	SEP	<i>Trial</i>	TRIAL <sup>c</sup>
<i>Sequence</i>	SEQ	<i>Trigger Pulse</i>	TRIG
<i>Set (i.e., set and drift, or setting a value)</i>	SET	<i>True</i>	T
<i>Ship's Time</i>	TIME	<i>True Motion</i>	TM
<i>Short Pulse</i>	SP	<i>Tune</i>	TUNE
<i>Signal to Noise Ratio</i>	SNR	<i>Ultrahigh Frequency</i>	UHF
<i>Simulation</i>	SIM <sup>c</sup>	<i>Uninterruptible Power Supply</i>	UPS
<i>Slave</i>	SLAVE	<i>Universal Time, Coordinated</i>	UTC
<i>South</i>	S	<i>Universal Transverse Mercator</i>	UTM
<i>Speed</i>	SPD	<i>Unstabilised</i>	UNSTAB
<i>Speed and Distance Measuring Equipment</i>	SDME	<i>Variable Range Marker</i>	VRM
<i>Speed Over the Ground</i>	SOG	<i>Variation</i>	VAR
<i>Speed Through the Water</i>	STW	<i>Vector</i>	VECT
<i>Stabilized</i>	STAB	<i>Very High Frequency</i>	VHF
<i>Standby</i>	STBY	<i>Very Low Frequency</i>	VLF
<i>Starboard/Starboard Side</i>	STBD	<i>Vessel Aground</i>	GRND
<i>Station</i>	STN	<i>Vessel at Anchor</i>	ANCH
<i>Symbol(s)</i>	SYM		

<b>Term</b>	<b>Abbreviation</b>
<i>Vessel Constrained by Draught</i>	VCD
<i>Vessel Engaged in Diving Operations</i>	DIVE
<i>Vessel Engaged in Dredging or Underwater Operations</i>	DRG
<i>Vessel Engaged in Towing Operations</i>	TOW
<i>Vessel Not Under Command</i>	NUC
<i>Vessel Restricted in Manoeuvrability</i>	RIM
<i>Vessel Traffic Service</i>	VTS
<i>Vessel Underway Using Engine</i>	UWE
<i>Video</i>	VID

<b>Term</b>	<b>Abbreviation</b>
Visual Display Unit	VDU
Voyage	VOY
<i>Voyage Data Recorder</i>	VDR
<i>Warning</i>	WARNING
<i>Water</i>	WAT
<i>Waypoint</i>	WPT
Waypoint Closure Velocity	WCV
<i>West</i>	W
<i>Wheel Over Line</i>	WOL
Wheel Over Point	WOP
<i>Wheel Over Time</i>	WOT
<i>World Geodetic System</i>	WGS
<i>X-Band</i>	X-BAND

## Appendix 3 List of Symbols

Symbol name	Symbol graphic
Own ship - simplified symbol	Double circle 
Velocity vector	Short-dashed line 
Past track	Small filled circle 
Waypoint	Circle 
Route	Long-dashed line 
Event	Square with diagonal line 
User cursor	Cross line 

## Appendix 4 List of Default Setting Values

MENU	Sub Menu	Sub Menu	Sub Menu	Default			
DISPLAY	THEME			DAY			
	BEEP			ON			
	DAY SCREEN			OFF			
	NAV			ON			
	PLOT			ON			
	ANALOG			ON			
	HIGHWAY			ON			
	SAT INFO			ON			
	WPT INFO			ON			
	BEACON TEXT			ON			
	NAV ASSIST			ON			
VOYAGE	WPT	WPT LIST		-			
	ROUTE	ROUTE LIST		-			
	RUN			-			
	EVENTMARK	EVENTMARK LIST		-			
	WPT COPY			-			
	ROUTE COPY			-			
	WPT DELETE			-			
	ROUTE DELETE			-			
	EVENT DELETE			-			
	SHARED	ROUTE SEND	CONNECT		UNICAST		
			IP		000.000.000.000		
			PORT		0		
			OUTPUT		LAN1		
			FORMAT		NMEA VER 1.5		
			DATA		ALL WPT		
	DEFAULT SETTINGS	ROUTE RECEIVE	SOURCE IP		000.000.000.000		
		WIDTH PORT(NM)			1.00		
WIDTH STBD(NM)					1.00		
			ARRIVAL RADIUS(NM)			1.00	
				SPEED(kn)			10.00
					SAIL		
	SOG SMOOTHING(s)						
		SYSTEM				SET	
SOUND							ON
ARRIVAL/ ANCHOR		SET				ARRIVAL	
		SOUND		ON			
XTD/ BOUNDARY		SET		XTD			
	SOUND		ON				
HDOP	SET		THRESHOLD 4				
	SOUND		OFF				
SPD	SET		OFF				
	SOUND		ON				
TRIP	SET		OFF				
	SOUND		ON				
EARLY COURSE CHANGE	SET		OFF				
	SOUND		ON				
END OF TRACK	SET		OFF				
	SOUND		ON				
ARRIVED AT WOL	SET		OFF				
	SOUND		ON				
ACTUAL COURSE CHANGE	SET		OFF				
	SOUND		ON				

MENU	Sub Menu	Sub Menu	Sub Menu	Range	
ALERT	TEMP	SET		OFF	
		SOUND		ON	
	DPTH	SET		OFF	
		SOUND		ON	
	DGPS	SET		OFF	
		SOUND		OFF	
	BUFFER	SET		OFF	
		SOUND		ON	
	POWER	SET		ON	
		SOUND		ON	
GNSS SETTING	SENSOR1	GNSS	GPS MODE	GPS	
		FIX MODE		AUTO	
		ELV MASK		5	
		HDOP		10	
		SMOOTH	POSN SMOOTHING(s)		10
			SPEED SMOOTHING(s)		10
			COURSE SMOOTHING(s)		10
		RAIM	RAIM ACCURACY LEVEL(m)		100
		DATUM			WGS-84
		INIT	QUADRANT		-
			LAT		-
			LON		-
			ANT HEIGHT(m)		-
			YEAR		-
			MONTH		-
			DAY		-
			HOUR(hr) MINUTE(min)		-
		DGPS			AUTO
		BEACON	AUTO		-
			MANUAL		283.5kHz/25bps
			SEMI AUTO		-
			MONITOR		-
		SBAS	SAT SEARCH		AUTO
			TYPE0		OFF
RANGING			OFF		
STN LIST			-		
GNSS SETTING	SENSOR2	Same as SENSOR1			
SYSTEM	DATE / TIME	TIME DIFF		+00:00	
		DATE DISP		MMM DD,'YY	
		TIME DISP(hr)		24hr	
	UNIT	DIST / SPEED		NM,kn	
		HIGHT / DPTH		m	
		TEMP		°C	
		MAG CORR		OFF	
LORAN		OFF			
SENSOR SELECT			AUTO		
LANGUAGE				ENGLISH	
VERSION	DISPLAY			-	
	PROCESSOR			-	
	SENSOR1			-	
	SENSOR2			-	
ALERT LIST	ALERT HISTORY			-	
	ACTIVE ALERT			-	
	LAN1			-	
	LAN2			-	

MENU	Sub Menu	Sub Menu	Sub Menu	Sub Menu	Range		
EQUIP	TYPE	TYPE1 / 2 DISPLAY	DISPLAY TYPE		MAIN		
			SFI		GP0000		
		TYPE2/2 PROCESSOR	DEVICE No.		No1		
			SFI		GP0001		
			SENSOR1		GPS		
			SENSOR2		OFF		
		DATA I/O	IN/OUT1	FORMAT		NMEA	
				BITRATE		4800	
	VERSION				2.3		
	TALKER				GNSS		
	SENTENCE				GGA,RMC,VTG,DTM,ZD A,APB,RMB		
	IN/OUT2			FORMAT		SC-104	
				BITRATE		4800	
				VERSION		2.5	
			TALKER		GNSS		
	IN/OUT3		Same as IN/OUT1				
	OUT4		Same as IN/OUT1				
	OUT5		Same as IN/OUT1				
	OUT6		Same as IN/OUT1				
	LAN		LAN1	DATA OUT		MULTICAST 239.192.000.004 60004 NMEA/2.3/GNSS GGA,RMC,VTG,DTM,ZD A,APB,RMB	
					RMS SEND	ON MULTICAST 239.192.000.005 60005	
					PRINTER	UNUSED OFF 000.000.000.000 9100	
				LAN2	DATA OUT	Same as LAN1	
					RMS SEND	Same as LAN1	
					PRINTER	Same as LAN1	
			COMMON	ACTIVE ROUTE	OFF MULTICAST 239.000.096.001 6203		
		DATA ROUTE		Same as ACTIVE ROUTE			
		MUTUAL		OFF MULTICAST 239.000.000.001 5101			
		CONTACT1	CONTACT OUT		SYSTEM		
		CONTACT2	CONTACT OUT		XTD		
		CONTACT3	CONTACT OUT		ACK		
	CONTACT4	CONTACT OUT		ARV			
	BUFFER	FORMAT		NMEA			
		BITRATE(bps)		4800			
		VERSION		2.3			
		TALKER		GNSS			
		SENTENCE		GGA,RMC,VTG,DTM,ZD A,APB,RMB			

MENU	Sub Menu	Sub Menu	Sub Menu	Sub Menu	Range	
EQUIP	DATA I/O	SENSOR	SENSOR1 PORT2(bps)		4800	
			SENSOR2 PORT2(bps)		4800	
		RS-232C	FORMAT		NMEA	
			BITRATE(bps)		4800	
			VERSION		2.3	
			TALKER		GNSS	
			SENTENCE		GGA,RMC,VTG,DTM,ZD A,APB,RMB	
		SWITCH	CONTROLL METHOD			MFD
			SWITCH SELECTION			PROCESSOR No1.
		DIMMER	SETTINGS	DIMMER GROUP		1
	DISPLAY				OFF	
	NCM-227				OFF	
	DDC				OFF	
	GPS				OFF	
	GP DDC				OFF	
	DIMMER CAL				-	
	IP	DISPLAY	IP ADDRESS		172.018.001.169	
			MAC ADDRESS		-	
			SUBNET MASK		255.255.000.000	
			DEFAULT GATEWAY		000.000.000.000	
		PROCESSOR LAN 0	IP ADDRESS		172.018.001.163	
			MAC ADDRESS		-	
			SUBNET MASK		255.255.000.000	
			DEFAULT GATEWAY		172.016.060.001	
		PROCESSOR LAN 1	IP ADDRESS		172.016.060.163	
			MAC ADDRESS		-	
			SUBNET MASK		255.255.000.000	
			DEFAULT GATEWAY		172.016.060.001	
		PROCESSOR LAN 2	IP ADDRESS		172.017.060.163	
			MAC ADDRESS		-	
			SUBNET MASK		255.255.000.000	
			DEFAULT GATEWAY		172.016.060.001	
		CCRP	BEAM (m)			1.0
			LENGTH(m)			1.0
			CCRP(m)			0.0/0.0/0.0
			SENSOR1 (m)			0.0/0.0/0.0
	SENSOR2 (m)				0.0/0.0/0.0	

MENU	Sub Menu	Sub Menu	Sub Menu	Sub Menu	Range	
EQUIP	CTS	CLASS			TANKER	
		TRACKING GAIN			LOW	
		TRACKING HIGH			2880	
		TORACING MIDDLE			960	
		TRACKING LOW			270	
		TRACKING MULTIPLE			1.0	
		TRACKING COUNT A			6	
		TRACKING D GAIN			0.0	
	LOW SPEED COG	OUTPUT			OFF	
	MAINTENANCE	DIAGNOSIS	DISPLAY			-
			PROCESSOR			-
			SENSOR1			-
			SENSOR2			-
		MONITOR	DATA IN1			-
			DATA IN2			-
			DATA IN3			-
			RS-232C			-
			SWITCH			-
			LAN1			-
			LAN2			-
			SENSOR1			-
		SENSOR2			-	
		OPERATING TIME	OPERATING TIME(hr)			-
	LCD TIME(hr)				-	
	RESET				-	
	DEMO	DEMO TYPE			STATIC	
		START/ STOP			-	
		YEAR			-	
		MONTH			-	
		DAY			-	
		HOUR(hr)			-	
		MINUTE(min)			-	
		SECOND(s)			-	
		QUADRANT			-	
		LAT			-	
		LON			-	
		SPEED(kn)			-	
		COURSE(° )			-	
		RADIUS(NM)			-	
	ROUTE			-		
	ALL SETTING VALUE	BACKUP INFO			-	
IMPORT/ EXPORT		MPORT/ EXPORT			PROCESSOR → DISPLAY	
		PROCESS			BACKUP	



## Appendix 5 Data Format

### Output Sentence

#### • GGA – Global positioning system (GPS) fix data

\$--GGA, hhmmss.ss, llll.ll, a, yyyy.yy, a, x, xx, x.x, x.x, M, x.x, M, x.x, xxxx\*hh<CR><LF>  
1 2 3 4 5 6 7 8 9 10 11 12

- 1 : UTC of position
- 2 : Latitude N/S
- 3 : Longitude E/W
- 4 : GPS quality indicator (see Note 1)
- 5 : Number of satellites in use, 00-12, maybe different from the number in view
- 6 : Horizontal dilution of precision
- 7 : Antenna altitude above/below mean sea level (geoid)
- 8 : Units of antenna altitude, m
- 9 : Geoidal separation (see Note 3)
- 10 : Units of geoidal separation, m
- 11 : Age of differential GPS data (see Note 2)
- 12 : Differential reference station ID, 0000-1023

NOTE 1 All GPS quality indicators in headings 1 through 8 are considered "valid". The heading "0" is the only "invalid" indicator. The GPS quality indicator field should not be a null field.

0 = fix not available or invalid

1 = GPS SPS mode

2 = differential GPS, SPS mode

8 = Simulator mode

NOTE 2 Time in seconds since last SC104 type 1 or 9 update, null field when DGPS is not used.

NOTE 3 Geoidal separation: the difference between the WGS-84 earth ellipsoid surface and mean sea level (geoid) surface, " - " = mean sea level surface below the WGS-84 ellipsoid surface.

#### • RMC – Recommended minimum specific GNSS data

\$--RMC, hhmmss.ss, A, llll.ll, a, yyyy.yy, a, x.x, x.x, xxxxxx, x.x, a, a, a\*hh<CR><LF>  
1 2 3 4 5 6 7 8 9 10 11 12 13

- 1 : UTC of position fix
- 2 : Status (see Note 3) A = data valid V = navigation receiver warning
- 3 : Latitude, N/S
- 4 : Latitude, N/S
- 5 : Longitude, E/W
- 6 : Longitude, E/W
- 7 : Speed over ground, knots
- 8 : Course over ground, degrees true
- 9 : Date: dd/mm/yy
- 10 : Magnetic variation, degrees, E/W (see Note 1)
- 11 : Magnetic variation, degrees, E/W (see Note 1)
- 12 : Mode indicator (see Notes 2 and 3)
- 13 : Navigational status (see Note 4)

NOTE 1 E = Easterly variation subtracts from True course  
W = Westerly variation adds to True course

NOTE 2 Positioning system Mode Indicator:

A = Autonomous. Satellite system used in non-differential mode in position fix;

D = Differential. Satellite system used in differential mode in position fix;

P = Precise. Satellite system used in precision mode. Precision mode is defined as: no deliberate degradation (such as selective availability) and higher resolution code (P-code) is used to compute position fix. P is also

used for satellite system used in multi-frequency, SBAS or Precise Point Positioning (PPP) mode;  
S = Simulator mode.

NOTE 3 The positioning system mode indicator field supplements the positioning system status field, the status field should be set to V = Invalid for all values of indicator mode except for A= Autonomous and D = Differential. The positioning system mode indicator and status fields should not be null fields.

NOTE 4 The navigational status indicator is according to IEC 61108 requirements on 'Navigational (or Failure) warnings and status indications'. This field should not be a NULL field and the character should take one of the following values:

S = Safe when the estimated positioning accuracy (95 % confidence) is within the selected accuracy level corresponding to the actual navigation mode, and/or integrity is available and within the requirements for the actual navigation mode, and/or a new valid position has been calculated within 1 s for a conventional craft and 0,5 s for a high speed craft.

C = Caution when integrity is not available.

U = Unsafe when the estimated positioning accuracy (95 % confidence) is less than the selected accuracy level corresponding to the actual navigation mode, and/or integrity is available but exceeds the requirements for the actual navigation mode, and/or a new valid position has not been calculated within 1 s for a conventional craft and 0,5 s for a high speed craft.

V = Navigational status not valid, equipment is not providing navigational status indication.

### • GLL – Geographic position – Latitude/longitude

\$--GLL, llll.ll, a, yyy. yy, a, hhmmss.ss, A, a \*hh<CR><LF>  
1 2 3 4 5 6 7

1 : Latitude, N/S

2 : Latitude, N/S

3 : Longitude, E/W

4 : Longitude, E/W

5 : UTC of position

6 : Status (see Note 2) A=data valid V=data invalid

7 : Mode indicator (see Notes 1 and 2)

NOTE 1 Positioning system mode indicator:

D = Differential

S = Simulator

N = Data not valid

NOTE 2 The mode indicator field supplements the status field (field 6). The status field should be set to V = invalid for all values of operating mode except for A = Autonomous and D = Differential. The positioning system mode indicator and status fields should not be null fields.

### • VTG – Course over ground and ground speed

\$--VTG, x.x, T, x.x, M, x.x, N, x.x, K,a\*hh<CR><LF>  
1 2 3 4 5 6 7 8 9

1 : Course over ground, degrees true

2 : Course over ground, degrees true

3 : Course over ground, degrees magnetic

4 : Course over ground, degrees magnetic

5 : Speed over ground, knots (see Note 1)

6 : Speed over ground, knots (see Note 1)

7 : Speed over ground, km/h (see Note 1)

8 : Speed over ground, km/h (see Note 1)

9 : Mode indicator (see Note 2)

NOTE 1 The speed over the ground should always be non-negative.

NOTE 2 The mode indicator provides status information about the operation of the source device (such as positioning systems, velocity sensors, etc.) generating the sentence, and the validity of data being provided. The possible indications are as follows:

A = Autonomous mode;

D = Differential mode;

P = Precise. Satellite system used in precision mode. Precision mode is defined as: no deliberate degradation (such as selective availability) and higher resolution code (P-code) is used to compute position fix. P is also used for

satellite system used in multi-frequency, SBAS or Precise Point Positioning (PPP) mode;  
 S = Simulator mode;  
 N = Data not valid.  
 The mode indicator field should not be a null field.

• **GSA – GNSS DOP and active satellites**

\$--GSA, a, x, xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,x.x,x.x,x.x,h\*hh<CR><LF>  
           1 2                  3                  4 5 6 7

- 1 : Mode: M = manual, forced to operate in 2D or 3D mode  
           A = automatic, allowed to automatically switch 2D/3D
- 2 : Mode: 1 = fix not available, 2 = 2D, 3 = 3D
- 3 : ID numbers (see Note 1) of satellites used in solution
- 4 : PDOP
- 5 : HDOP
- 6 : VDOP
- 7 : GNSS System ID (see Note 2)

NOTE 1 Satellite ID numbers. To avoid possible confusion caused by repetition of satellite ID numbers when using multiple satellite systems, the following convention has been adopted.

- a) GPS satellites are identified by their PRN numbers, which range from 1 to 32.
- b) The numbers 33 to 64 are reserved for WAAS satellites. The WAAS system PRN numbers are 120 to 138. The offset from WAAS SV ID to WAAS PRN number is 87. A WAAS PRN number of 120 minus 87 yields the SV ID of 33. The addition of 87 to the SV ID yields the WAAS PRN number.
- c) The numbers 65 to 96 are reserved for GLONASS satellites. GLONASS satellites are identified by 64+satellite slot numbers. The slot numbers are 1 through 24 for the full GLONASS constellation of 24 satellites, thus giving a range of 65 through 88. The numbers 89 through 96 are available if slot numbers above 24 are allocated to on-orbit spares.

NOTE 2 GNSS System ID identifies the GNSS System ID according to the Table below.

• **GSV – GNSS satellites in view**

\$--GSV, x, x, xx, xx, xx, xxx, xx....., xx, xx, xxx, xx, h\*hh<CR><LF>  
           1 2 3 4 5 6 7 8                  9 10

- 1 : Total number of messages (see Note 1), 1 to 9
- 2 : Message number (see Note 1), 1 to 9
- 3 : Total number of satellites in view
- 4 : Satellite ID number (see Note 3)
- 5 : Elevation, degrees, 90° maximum
- 6 : Azimuth, degrees true, 000 to 359
- 7 : SNR (C/No) 00-99 dB-Hz, null when not tracking
- 8 : Second and third SVs (see Note 2)
- 9 : Fourth SV (see Note 2)
- 10 : Signal ID (see Note 4)

NOTE 1 Satellite information may require the transmission of multiple sentences all containing identical field formats when sending a complete message. The first field specifies the total number of sentences, minimum value 1. The second field identifies the order of this sentence (sentence number), minimum value 1. For efficiency it is recommended that null fields be used in the additional sentences when the data is unchanged from the first sentence.

NOTE 2 A variable number of "Satellite ID-Elevation-Azimuth-SNR" sets are allowed up to a maximum of four sets per sentence. Null fields are required for unused sets when less than four sets are transmitted.

NOTE 3 Satellite ID numbers. To avoid possible confusion caused by repetition of satellite ID numbers when using multiple satellite systems, the following convention has been adopted:

- a) GPS satellites are identified by their PRN numbers, which range from 1 to 32.
- b) The numbers 33 to 64 are reserved for WAAS satellites. The WAAS system PRN numbers are 120 to 138. The offset from WAAS SV ID to WAAS PRN number is 87. A WAAS PRN number of 120 minus 87 yields the SV ID of 33. The addition of 87 to the SV ID yields the WAAS PRN number.
- c) The numbers 65 to 96 are reserved for GLONASS satellites. GLONASS satellites are identified by 64+satellite slot number. The slot numbers are 1 through 24 for the full GLONASS constellation of 24 satellites, this gives a range of 65 through 88. The numbers 89 through 96 are available if slot numbers

above 24 are allocated to on-orbit spares.

NOTE 4 Signal ID see Table below.

#### • DTM – Datum reference

\$--DTM,ccc,a,x.x,a,x.x,a, x.x,ccc\*hh<CR><LF>  
1 2 3 4 5 6 7 8

1 : Local datum(see Note 1)

WGS84 = W84 / WGS72 = W72 / SGS85 = S85 / PE90 = P90

User defined = 999 / IHO datum code (see Note 4)

2 : Local datum subdivision code (see Note 2)

3 : Lat offset, min, N/S (see Note 3)

4 : Lat offset, min, N/S (see Note 3)

5 : Lon offset, min, E/W (see Note 3)

6 : Lon offset, min, E/W (see Note 3)

7 : Altitude offset, m (see Note 3)

8 : Reference datum (WGS84 = W84 / WGS72 = W72 / SGS85 = S85 / PE90 = P90)

NOTE 1 Three character alpha code for local datum. If not one of the listed earth-centred datums, or 999 for user defined datums, use IHO datum code from International Hydrographic Organisation Publication S-60, Appendices B and C. Null field if unknown. This field should be set to 999 when manual offsets are entered and in use by the position fixing device.

NOTE 2 One character subdivision datum code when available or user defined reference character for user defined datums, null field otherwise. Subdivision character from IHO Publication S-60, Appendices B and C.

NOTE 3 Latitude and longitude offsets are positive numbers, the altitude offset may be negative. Offsets change with position: position in the local datum is offset from the position in the reference datum in the directions indicated:

$$P_{\text{local datum}} = P_{\text{ref datum}} + \text{offset}$$

When field 1 contains a value of 999, these fields may not be null, and should contain the manually entered or user defined offsets.

NOTE 4 Users should be aware that chart transformations based on IHO S60 parameters may result in significant positional errors when applied to chart data.

#### • GBS – GNSS satellite fault detection

\$--GBS, hhmmss.ss, x.x, x.x, x.x, xx, x.x, x.x, x.x, h, h \*hh <CR><LF>  
1 2 3 4 5 6 7 8 9 10

1 : UTC time of the GGA or GNS fix associated with this sentence

2 : Expected error in latitude (see Note 1)

3 : Expected error in longitude (see Note 1)

4 : Expected error in altitude (see Note 1)

5 : ID number (see Note 2) of most likely failed satellite

6 : Probability of missed detection for most likely failed satellite

7 : Estimate of bias on most likely failed satellite(in metres)

8 : Standard deviation of bias estimate

9 : GNSS System ID (see Note 3)

10 : GNSS Signal ID (see Note 4)

NOTE 1 Expected error in metres due to bias, with noise = 0.

NOTE 2 Satellite ID numbers. To avoid possible confusion caused by repetition of satellite ID numbers when using multiple satellite systems, the following convention has been adopted (these legacy systems remain in effect for new systems see NOTE 3):

a) GPS satellites are identified by their PRN numbers, which range from 1 to 32.

b) The numbers 33-64 are reserved for WAAS satellites. The WAAS system PRN numbers are 120-138. The offset from WAAS SV ID to WAAS PRN number is 87. A WAAS PRN number of 120 minus 87 yields the SV ID of 33. The addition of 87 to the SV ID yields the WAAS PRN number.

c) The numbers 65-96 are reserved for GLONASS satellites. GLONASS satellites are identified by 64+ satellite slot number. The slot numbers are 1 through 24 for the full GLONASS constellation of 24 satellites; this gives a range of 65 through 88. The numbers 89 through 96 are available if slot numbers above 24 are allocated to on-orbit spares.

NOTE 3 System ID identifies the GNSS System ID according to the Table below. Note that legacy numbering system as above should remain in effect.

NOTE 4 GNSS Signal ID identifies the GNSS Signal ID according to the Table below.

### • GRS – GNSS range residuals

\$--GRS, hhmmss.ss,x,h,h \*hh<CR><LF>  
1 2 3 4 5

- 1 : UTC time of the GGA or GNS fix associated with this sentence
- 2 : Mode: 0 = residuals were used to calculate the position given in the matching GGA or GNS sentence  
1 = residuals were re-computed after the GGA or GNS position was computed
- 3 : Range residuals for satellites used in the navigation solution (see Notes 1 and 2)  
Order should match order of satellite ID (see Note 3) numbers in GSA.  
When GRS is used, GSA and GSV are generally required. Null for unused fields
- 4 : GNSS System ID (see Note 3)
- 5 : Signal ID (see Note 4)

NOTE 1 If the range residual exceeds  $\pm 99.9$  m, then the decimal part is dropped, resulting in an integer ( $-103.7$  becomes  $-103$ ). The maximum value for this field is  $\pm 999$ .

NOTE 2 The sense or sign of the range residual is determined by the order of parameters used in the calculation. The expected order is as follows: range residual = calculated range - measured range.

NOTE 3 When multiple GRS sentences are being sent then their order of transmission should match the order of corresponding GSA sentences. Listeners should keep track of pairs of GSA and GRS sentences and discard data if pairs are incomplete.

NOTE 4 Signal ID identifies the actual ranging signal according to the Table below.

NOTE 5 System ID, see Table below.

### • GST – GNSS pseudorange noise statistics

\$--GST, hhmmss.ss, x.x, x.x, x.x, x.x, x.x, x.x, x.x\*xh<CR><LF>  
1 2 3 4 5 6 7 8

- 1 : UTC time of the GGA or GNS fix associated with this sentence
- 2 : RMS value of the standard deviation of the range inputs to the navigation process. Range inputs include pseudoranges and DGPS corrections
- 3 : Standard deviation of semi-major axis of error ellipse (m)
- 4 : Standard deviation of semi-minor axis of error ellipse (m)
- 5 : Orientation of semi-major axis of error ellipse (degrees from true north)
- 6 : Standard deviation of latitude error (m)
- 7 : Standard deviation of longitude error (m)
- 8 : Standard deviation of altitude error (m)

### • ZDA – Time and date

\$--ZDA, hhmmss.ss, xx, xx, xxxx, xx, xx\*xh<CR><LF>  
1 2 3 4 5 6

- 1 : UTC
- 2 : Day, 01 to 31 (UTC)
- 3 : Month, 01 to 12 (UTC)
- 4 : Year (UTC)
- 5 : Local zone hours(see Note), 00 h to  $\pm 13$  h
- 6 : Local zone minutes (see Note), 00 to +59

NOTE Local time zone is the magnitude of hours plus the magnitude of minutes added, with the sign of local zone

hours, to local time to obtain UTC. Local zone is generally negative for East longitudes with local exceptions near the international date line.

Example: At Chatham Is. (New Zealand) at 1230 (noon) local time on June 10, 1995:

```
$GPZDA,234500,09,06,1995,-12,45*6C<CR><LF>
```

In the Cook Islands at 1500 local time on June 10, 1995:

```
$GPZDA,013000,11,06,1995,10,30*4A<CR><LF>
```

## • GNS – GNSS fix data

```
$-- GNS, hhmms.ss, llll.ll, a, yyyy.yy, a, c--c,xx,x.x,x.x,x.x,x.x,x.x,a *hh<CR><LF>
```

1            2 3    4    5 6 7 8 9 10 11 12 13

- 1 : UTC of position
- 2 : Latitude, N/S
- 3 : Latitude, N/S
- 4 : Longitude, E/W
- 5 : Longitude, E/W
- 6 : Mode indicator (see Note 1)
- 7 : Total number of satellites in use, 00-99
- 8 : HDOP (see Note 3)
- 9 : Antenna altitude, m, re: mean-sea-level (geoid)
- 10 : Geoidal separation, m (see Note 4)
- 11 : Age of differential data (see Note 2)
- 12 : Differential reference station ID (see Note 2)
- 13 : Navigational status indicator (see Note 5)

NOTE 1 Mode indicator. A variable length valid character field type with the first three characters currently defined. The first character indicates the use of GPS satellites, the second character indicates the use of GLONASS satellites and the third indicate the use of Galileo satellites. If another satellite system is added to the standard, the mode indicator will be extended to four characters, new satellite systems should always be added on the right, so the order of characters in the mode indicator is: GPS, GLONASS, Galileo, other satellite systems in the future. The characters should take one of the following values:

A = Autonomous. Satellite system used in non-differential mode in position fix

D = Differential. Satellite system used in differential mode in position fix

N = No fix. Satellite system not used in position fix, or fix not valid

P = Precise. Satellite system used in precision mode. Precision mode is defined as: no deliberate degradation (such as selective availability) and higher resolution code (P-code) is used to compute position fix. P is also used for satellite system used in multi-frequency, SBAS or Precise Point Positioning (PPP) mode

S = Simulator mode

The mode indicator should not be a null field.

NOTE 2 Age of differential data and Differential Reference Station ID:

a) When the talker is GN and more than one of the satellite systems are used in differential mode, then the "Age of differential data" and "Differential reference station ID" fields should be null. In this case, the "Age of differential data" and "Differential reference station ID" fields should be provided in following GNS sentences with talker IDs of GP, GL, etc. These following GNS messages should have the latitude, N/S, longitude, E/W, altitude, geoidal separation, mode, and HDOP fields null. This indicates to the listener that the field is supporting a previous \$GNGNS sentence with the same time tag. The "Number of satellites" field may be used in these following sentences to denote the number of satellites used from that satellite system.

Example: A combined GPS/GLONASS receiver using only GPS differential corrections has the following GNS sentence sent.

```
$GNGNS,122310.2,3722.425671,N,12258.856215,W,DA,14,0.9,1005.543,6.5,5.2,23*59<CR><LF>
```

Example: A combined GPS/GLONASS receiver using both GPS differential corrections and GLONASS differential corrections may have the following three GNS sentences sent in a group.

```
$GNGNS,122310.2,3722.425671,N,12258.856215,W,DD,14,0.9,1005.543,6.5,,*74<CR><LF>
```

```
$GPGNS,122310.2,,,,,7,,,5.2,23*4D<CR><LF>
```

```
$GLGNS,122310.2,,,,,7,,,3.0,23*55<CR><LF>
```

The Differential Reference station ID may be the same or different for the different satellite systems.

b) Age of Differential Data

For GPS Differential Data:

This value is the average age of the most recent differential corrections in use. When only RTCM SC104

Type 1 corrections are used, the age is that of the most recent Type 1 correction. When RTCM SC104

Type 9 corrections are used solely, or in combination with Type 1 corrections, the age is the average of the

most recent corrections for the satellites used. Null field when Differential GPS is not used.

NOTE 3 HDOP calculated using all the satellites (GPS, GLONASS, Galileo and any future satellites) used in computing the solution reported in each GNS sentence.

NOTE 4 Geoidal Separation: the difference between the earth ellipsoid surface and mean-sea-level (geoid) surface defined by the reference datum used in the position solution, "-" = mean-sea-level surface below ellipsoid. The reference datum may be specified in the DTM sentence.

NOTE 5 The navigational status indicator is according to IEC 61108 requirements on 'Navigational (or Failure) warnings and status indications'. This field should not be a NULL field and the character should take one of the following values:

S = Safe when the estimated positioning accuracy (95 % confidence) is within the selected accuracy level corresponding to the actual navigation mode, and integrity is available and within the requirements for the actual navigation mode, and a new valid position has been calculated within 1 s for a conventional craft and 0,5 s for a high speed craft

C = Caution when integrity is not available

U = Unsafe when the estimated positioning accuracy (95 % confidence) is less than the selected accuracy level corresponding to the actual navigation mode, and/or integrity is available but exceeds the requirements for the actual navigation mode, and/or a new valid position has not been calculated within 1 s for a conventional craft and 0,5 s for a high speed craft

V = Navigational status not valid, equipment is not providing navigational status indication.

#### • MSS – MSK receiver signal status

\$--MSS,x.x,x.x,x.x,x.x,x.x\*hh<CR><LF>  
1 2 3 4 5

- 1 : Signal strength (SS), dB/1 mV/m
- 2 : Signal-to-noise ratio (SNR), dB
- 3 : Beacon frequency, 283,5 kHz to 325,0 kHz
- 4 : Beacon bit rate (25, 50, 100, 200) bits/s
- 5 : Channel number (see Note)

NOTE Set equal to "1" or null for single channel receivers.

#### • ALR – Set alarm state

\$--ALR,hhmmss.ss,xxx,A, A,c--c\*hh<CR><LF>  
1 2 3 4 5

- 1 : Time of alarm condition change, UTC
- 2 : Unique alarm number (identifier) at alarm source
- 3 : Alarm condition (A = threshold exceeded, V = not exceeded)
- 4 : Alarm's acknowledge state, A = acknowledged / V = unacknowledged
- 5 : Alarm's description text

#### • APB – Heading/track controller (autopilot) sentence B

\$--APB, A, A, x.x, a, N, A, A, x.x, a, c--c, x.x, a, x.x, a, a\*hh<CR><LF>  
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

- 1 : Status: A = Data valid V = LORAN-C blink or SNR warning (see Note 2)  
V = general warning flag for other navigation systems when a reliable fix is not available
- 2 : Status: A = OK or not used V = LORAN-C cycle lock warning flag (see Note 2)
- 3 : Magnitude of XTE (cross-track-error)
- 4 : Direction to steer, L/R
- 5 : XTE units, nautical miles
- 6 : Status: A = arrival circle entered V = arrival circle not passed
- 7 : Status: A = perpendicular passed at waypoint  
V = perpendicular not entered
- 8 : Bearing origin to destination, M/T
- 9 : Bearing origin to destination, M/T
- 10 : Destination waypoint ID
- 11 : Bearing, present position to destination, magnetic or true
- 12 : Bearing, present position to destination, magnetic or true
- 13 : Heading to steer to destination waypoint, magnetic or true
- 14 : Heading to steer to destination waypoint, magnetic or true

15 : Mode indicator (see Notes 1 and 2)

NOTE 1 Positioning system mode indicator:

A = Autonomous mode;

D = Differential mode;

S = Simulator mode;

N = Data not valid.

NOTE 2 The positioning system mode indicator field supplements the positioning system status fields (fields 1 and 2), the status fields should be set to V = invalid for all values of mode indicator except for A = Autonomous and D = Differential. The positioning system mode indicator should not be null fields.

• **BOD – Bearing origin to destination**

\$--BOD, x.x, T, x.x, M, c--c, c--c\*hh<CR><LF>  
1 2 3 4 5 6

- 1 : Bearing, degrees true
- 2 : Bearing, degrees true
- 3 : Bearing, degrees magnetic
- 4 : Bearing, degrees magnetic
- 5 : Destination waypoint ID
- 6 : Origin waypoint ID

• **BWC – Bearing and distance to waypoint – Great circle**

\$--BWC, hhmmss.ss, llll.ll, a, yyyy.yy, a, x.x, T, x.x, M, x.x, N, c--c, a\*hh<CR><LF>  
1 2 3 4 5 6 7 8 9 10 11 12 13

- 1 : UTC of observation
- 2 : Waypoint latitude, N/S
- 3 : Waypoint latitude, N/S
- 4 : Waypoint longitude, E/W
- 5 : Waypoint longitude, E/W
- 6 : Bearing, degrees true
- 7 : Bearing, degrees true
- 8 : Bearing, degrees magnetic
- 9 : Bearing, degrees magnetic
- 10 : Distance, nautical miles
- 11 : Distance, nautical miles
- 12 : Waypoint ID
- 13 : Mode indicator (see Note)

NOTE Positioning system mode indicator:

A = Autonomous mode;

D = Differential mode;

S = Simulator mode;

N = Data not valid.

The mode indicator field should not be a null field.

• **BWR – Bearing and distance to waypoint – Rhumb line**

\$--BWR, hhmmss.ss, llll.ll, a, yyyy.yy, a, x.x, T, x.x, M, x.x, N, c--c, a\*hh<CR><LF>  
1 2 3 4 5 6 7 8 9 10 11 12 13

- 1 : UTC of observation
- 2 : Waypoint latitude, N/S
- 3 : Waypoint latitude, N/S
- 4 : Waypoint longitude, E/W
- 5 : Waypoint longitude, E/W





- 3 : Magnitude of cross-track error
- 4 : Direction to steer, L/R
- 5 : Units, nautical miles
- 6 : Mode indicator (see Notes 1 and 2)

NOTE 1 Positioning system mode indicator:

A = Autonomous mode;  
 D = Differential mode;  
 S = Simulator mode;  
 N = Data not valid.

NOTE 2 The positioning system mode indicator field supplements the positioning system status fields (fields 1 and 2); the status fields should be set to V = invalid for all values of indicator mode except for A = Autonomous and D = Differential. The positioning system mode indicator and status fields should not be null fields.

• **ZTG – UTC and time to destination waypoint**

\$--ZTG, hhmmss.ss, hhmmss.ss, c--c\*hh<CR><LF>  
                   1                  2                  3

- 1 : UTC of observation
- 2 : Time-to-go, hh = 00 to 99
- 3 : Destination waypoint ID

• **AAM – Waypoint arrival alarm**

\$--AAM, A, A,x.x, N, c--c\*hh<CR><LF>

- 1 : Status: A = arrival circle entered; V = not entered
- 2 : Status: A = perpendicular passed at waypoint; V = not passed
- 3 : Arrival circle radius
- 4 : Units of radius, nautical miles
- 5 : Waypoint ID

• **RTE – Routes**

\$--RTE, x.x, x.x, a, c--c, c--c,..... c--c\*hh<CR><LF>  
                   1  2  3  4  5  6  7  8

- 1 : Total number of sentences being transmitted (see Note 2)
- 2 : Sentence number (see Note 2)
- 3 : Message mode: c = complete route, all waypoints  
                   w = working route, first listed waypoint is "FROM",  
                   second is "TO" and remaining are rest of route
- 4 : Route identifier
- 5 : Waypoint identifier
- 6 : Additional waypoint identifiers (see Note 1)
- 7 : Additional waypoint identifiers (see Note 1)
- 8 : Waypoint "n" identifier (see Note 1)

NOTE 1 A variable number of waypoint identifiers, up to "n", may be included within the limits of allowed sentence length. As there is no specified number of waypoints, null fields are not required for waypoint identifier fields.

NOTE 2 A single route may require the transmission of multiple sentences, all containing identical field formats when sending a complex message. The first field specifies the number of sentences, minimum value = 1. The second field identifies the order of this sentence (sentence number), minimum value = 1. For efficiency, it is permitted that null fields be used in the additional sentences when the data is unchanged from the first sentence. (Note that this practice can lead to the incorrect assembly of sentences if there is a high risk of loss of sentence.)

• **WPL – Waypoint location**

\$--WPL, llll.ll, a, yyyy.yy, a, c--c\*hh<CR><LF>  
1 2 3 4 5

- 1 : Waypoint latitude, N/S
- 2 : Waypoint latitude, N/S
- 3 : Waypoint longitude, E/W
- 4 : Waypoint longitude, E/W
- 5 : Waypoint identifier

• **ACK – Acknowledge alarm**

\$--ACK,xxx\*hh<CR><LF>  
1

- 1 : Unique alarm number (identifier) at alarm source

• **HDT – Heading true**

\$--HDT, x.x, T\*hh<CR><LF>  
1 2

- 1 : Heading, degrees true
- 2 : Heading, degrees true

• **THS – True heading and status**

\$--THS,x.x,a\*hh<CR><LF>  
1 2

- 1 : Heading, degrees true
- 2 : Mode indicator (see Note)

NOTE Mode indicator. This field should not be null.  
A = Autonomous  
S = Simulator mode  
V = Data not valid (including standby)

• **DBT – Depth below transducer**

\$--DBT, x.x, f, x.x, M, x.x, F\*hh<CR><LF>  
1 2 3 4 5 6

- 1 : Water depth, feet
- 2 : Water depth, feet
- 3 : Water depth, m
- 4 : Water depth, m
- 5 : Water depth, fathoms
- 6 : Water depth, fathoms

• **DPT – Depth**

\$--DPT, x.x, x.x, x.x\*hh<CR><LF>  
1 2 3

- 1 : Water depth relative to the transducer, in metres
- 2 : Offset from transducer, in metres (see Notes 1 and 2)
- 3 : Maximum range scale in use

NOTE 1 “positive” = distance from transducer to water line; “-” = distance from transducer to keel.

NOTE 2 For IEC applications, the offset should always be applied so as to provide depth relative to the keel.

• **MTW – Water temperature**

\$-- MTW, x.x, C\*hh<CR><LF>  
1 2

- 1 : Temperature, degrees C
- 2 : Temperature, degrees C

• **CUR – Water current layer – Multi-layer water current data**

\$--CUR,A,x,x,x,x,x,x,x,x,x,x,x,x,x,x,x,x,a\*hh<CR LF>  
1 2 3 4 5 6 7 8 9 10 11

- 1 : Validity of the data, A = Valid, V = not valid
- 2 : Data set number, 0 to 9 (see Note 1)
- 3 : Layer number (see Note 2)
- 4 : Current depth in metres
- 5 : Current direction in degrees
- 6 : Direction reference in use, True/Relative T/R
- 7 : Current speed in knots
- 8 : Reference layer depth in metres (see Note 3)
- 9 : Heading
- 10 : Heading reference in use, True/Magnetic T/M
- 11 : Speed reference (see Note 4)
  - B: Bottom track
  - W: Water track
  - P: Positioning system

NOTE 1 The data set number is used to identify multiple sets of current data produced in one measurement instance. Each measurement instance may result in more than one sentence containing current data measurements at different layers, all with the same data set number. This is used to avoid the data measured in another instance to be accepted as one set of data.

NOTE 2 The layer number identifies which layer the current data measurements were made from. The number of layers that can be measured varies by device. The typical number is between 3 and 32, though many more are possible.

NOTE 3 The current of each layer is measured according to this reference layer, when the speed reference field is set to “water track”, or the depth is too deep for bottom track.

NOTE 4 “Speed reference” identifies the method of ship speed used for measuring the current speed.

• **VBW – Dual ground/water speed**

\$--VBW, x.x, x.x, A, x.x, x.x, A, x.x, A, x.x, A\*hh<CR><LF>  
1 2 3 4 5 6 7 8 9 10

- 1 : Longitudinal water speed (see Note 1), knots
- 2 : Transverse water speed (see Note 1), knots
- 3 : Status (see Note 2): water speed, A = data valid, V = data invalid
- 4 : Longitudinal ground speed (see Note 1), knots
- 5 : Transverse ground speed (see Note 1), knots
- 6 : Status (see Note 2), ground speed, A = data valid, V = data invalid
- 7 : Stern transverse water speed (see Note 1), knots
- 8 : Status (see Note 2): stern water speed, A = data valid, V = data invalid
- 9 : Stern transverse ground speed (see Note 1), knots
- 10 : Status (see Note 2): stern ground speed, A = data valid, V = data invalid

NOTE 1 Transverse speed: "-" = port,  
Longitudinal speed: "-" = astern.

NOTE 2 The status field should not be a null field.

• **VHW – Water speed and heading**

\$--VHW, x.x, T, x.x, M, x.x, N, x.x, K\*hh<CR><LF>  
1 2 3 4 5 6 7 8

- 1 : Heading, degrees true
- 2 : Heading, degrees true
- 3 : Heading, degrees magnetic
- 4 : Heading, degrees magnetic
- 5 : Speed, knots
- 6 : Speed, knots
- 7 : Speed, km/h
- 8 : Speed, km/h

## Input Sentence

### • HDT – Heading true

\$--HDT, x.x, T\*hh<CR><LF>  
1 2

1 : Heading, degrees true

2 : Heading, degrees true

### • THS – True heading and status

\$--THS,x.x,a\*hh<CR><LF>  
1 2

1 : Heading, degrees true

2 : Mode indicator (see Note)

NOTE Mode indicator. This field should not be null.

A = Autonomous

S = Simulator mode

V = Data not valid (including standby)

### • DBT – Depth below transducer

\$--DBT, x.x, f, x.x, M, x.x, F\*hh<CR><LF>  
1 2 3 4 5 6

1 : Water depth, feet

2 : Water depth, feet

3 : Water depth, m

4 : Water depth, m

5 : Water depth, fathoms

6 : Water depth, fathoms

### • DPT – Depth

\$--DPT, x.x, x.x, x.x\*hh<CR><LF>  
1 2 3

1 : Water depth relative to the transducer, in metres

2 : Offset from transducer, in metres (see Notes 1 and 2)

3 : Maximum range scale in use

NOTE 1 "positive" = distance from transducer to water line; "-" = distance from transducer to keel.

NOTE 2 For IEC applications, the offset should always be applied so as to provide depth relative to the keel.

### • MTW – Water temperature

\$-- MTW, x.x, C\*hh<CR><LF>  
1 2

1 : Temperature, degrees C

2 : Temperature, degrees C

• **CUR – Water current layer – Multi-layer water current data**

\$--CUR,A,x,x,x,x,x,x,a,x,x,x,x,x,a\*hh<CR LF>  
 1 2 3 4 5 6 7 8 9 10 11

- 1 : Validity of the data, A = Valid, V = not valid
- 2 : Data set number, 0 to 9 (see Note 1)
- 3 : Layer number (see Note 2)
- 4 : Current depth in metres
- 5 : Current direction in degrees
- 6 : Direction reference in use, True/Relative T/R
- 7 : Current speed in knots
- 8 : Reference layer depth in metres (see Note 3)
- 9 : Heading
- 10 : Heading reference in use, True/Magnetic T/M
- 11 : Speed reference (see Note 4)
  - B: Bottom track
  - W: Water track
  - P: Positioning system

NOTE 1 The data set number is used to identify multiple sets of current data produced in one measurement instance. Each measurement instance may result in more than one sentence containing current data measurements at different layers, all with the same data set number. This is used to avoid the data measured in another instance to be accepted as one set of data.

NOTE 2 The layer number identifies which layer the current data measurements were made from. The number of layers that can be measured varies by device. The typical number is between 3 and 32, though many more are possible.

NOTE 3 The current of each layer is measured according to this reference layer, when the speed reference field is set to "water track", or the depth is too deep for bottom track.

NOTE 4 "Speed reference" identifies the method of ship speed used for measuring the current speed.

• **VBW – Dual ground/water speed**

\$--VBW, x.x, x.x, A, x.x, x.x, A, x.x, A, x.x, A\*hh<CR><LF>  
 1 2 3 4 5 6 7 8 9 10

- 1 : Longitudinal water speed (see Note 1), knots
- 2 : Transverse water speed (see Note 1), knots
- 3 : Status (see Note 2): water speed, A = data valid, V = data invalid
- 4 : Longitudinal ground speed (see Note 1), knots
- 5 : Transverse ground speed (see Note 1), knots
- 6 : Status (see Note 2), ground speed, A = data valid, V = data invalid
- 7 : Stern transverse water speed (see Note 1), knots
- 8 : Status (see Note 2): stern water speed, A = data valid, V = data invalid
- 9 : Stern transverse ground speed (see Note 1), knots
- 10 : Status (see Note 2): stern ground speed, A = data valid, V = data invalid

NOTE 1 Transverse speed: "-" = port,  
 Longitudinal speed: "-" = astern.

NOTE 2 The status field should not be a null field.

• **VHW – Water speed and heading**

\$--VHW, x.x, T, x.x, M, x.x, N, x.x, K\*hh<CR><LF>  
1 2 3 4 5 6 7 8

- 1 : Heading, degrees true
- 2 : Heading, degrees true
- 3 : Heading, degrees magnetic
- 4 : Heading, degrees magnetic
- 5 : Speed, knots
- 6 : Speed, knots
- 7 : Speed, km/h
- 8 : Speed, km/h

• **RTE – Routes**

\$--RTE, x.x, x.x, a, c--c, c--c,..... c--c\*hh<CR><LF>  
1 2 3 4 5 6 7 8

- 1 : Total number of sentences being transmitted (see Note 2)
- 2 : Sentence number (see Note 2)
- 3 : Message mode: c = complete route, all waypoints  
w = working route, first listed waypoint is "FROM",  
second is "TO" and remaining are rest of route
- 4 : Route identifier
- 5 : Waypoint identifier
- 6 : Additional waypoint identifiers (see Note 1)
- 7 : Additional waypoint identifiers (see Note 1)
- 8 : Waypoint "n" identifier (see Note 1)

NOTE 1 A variable number of waypoint identifiers, up to "n", may be included within the limits of allowed sentence length. As there is no specified number of waypoints, null fields are not required for waypoint identifier fields.

NOTE 2 A single route may require the transmission of multiple sentences, all containing identical field formats when sending a complex message. The first field specifies the number of sentences, minimum value = 1. The second field identifies the order of this sentence (sentence number), minimum value = 1. For efficiency, it is permitted that null fields be used in the additional sentences when the data is unchanged from the first sentence. (Note that this practice can lead to the incorrect assembly of sentences if there is a high risk of loss of sentence.)

• **WPL – Waypoint location**

\$--WPL, llll.ll, a, yyyy.yy, a, c--c\*hh<CR><LF>  
1 2 3 4 5

- 1 : Waypoint latitude, N/S
- 2 : Waypoint latitude, N/S
- 3 : Waypoint longitude, E/W
- 4 : Waypoint longitude, E/W
- 5 : Waypoint identifier

• **ACK – Acknowledge alarm**

\$--ACK,xxx\*hh<CR><LF>  
1

- 1 : Unique alarm number (identifier) at alarm source



• **ALR – Set alarm state**

\$--ALR,hhmmss.ss,xxx,A, A,c--c\*hh<CR><LF>  
1 2 3 4 5

- 1 : Time of alarm condition change, UTC
- 2 : Unique alarm number (identifier) at alarm source
- 3 : Alarm condition (A = threshold exceeded, V = not exceeded)
- 4 : Alarm's acknowledge state, A = acknowledged / V = unacknowledged
- 5 : Alarm's description text

## Appendix 6 Compass Safe Distance

No	Name	Model	Compass Safe Distance [m]	
			Standard	Steering
1	AC Power Supply	NBG-320	0.3	0.2
2	AC Power Supply	NBD-577C	0.9	0.6
3	Dimmer	NCM-227	0.1	0.1
4	Printer	NKG-104	0.8	0.5
5	Select Switch	NCZ-777	0.2	0.1
6	Select Switch	NCZ-1663	0.1	0.1
7	Select Switch	NCZ-1537B	0.2	0.1
8	Junction Box	NQE-7700A	0.2	0.1
9	Output Buffer	NQA-4251A	0.1	0.1
10	Output Buffer	NQA-4351	0.1	0.1
11	Junction Box (note 1)	NQD-4410	0.2	0.1
12	Junction Box (note 1)	NQD-4411	0.2	0.1
13	Junction Box	CQD-10	0.3	0.2

note 1) Coaxial Cable Kit NQD-4414: consisting of NQD-4410 and NQD-4411

アスベストは使用していません  
Not use the asbestos

*For further information, contact:*



*Japan Radio Co., Ltd.*

*Since 1915*

URL Head office : <http://www.jrc.co.jp/eng/>

Marine Service Department

1-7-32 Tatsumi, Koto-ku, Tokyo 135-0053, Japan

e-mail : [tmsc@jrc.co.jp](mailto:tmsc@jrc.co.jp)

One-call : +81-50-3786-9201

ISO 9001, ISO 14001 Certified

CODE No.7ZPNA4699

AUG. 2018 Edition 1