

JUE-60GX

**Inmarsat
Global Xpress GX**

Mobile Earth Station

Instruction Manual

7ZPSC0584

Inmarsat GX Service systems	1
Introduction of the JUE-60GX	2
Components	3
Setup	4
Web Interface	5
Maintenance	6
After-sales service	7
Specification	8
Web Interface Menu Tree	APP A
Software Upgrading Procedure	APP B
Initializing the settings to the factory default state	APP C
List of Initial Values (BDE-Version 0100)	APP D
Troubleshooting & FAQ	APP E
LED of BDE	APP F
Abbreviations and Glossary	APP G
JRC Network	APP H
Hazardous substances of Electrical and electronic Products	APP I



Japan Radio Co., Ltd.

PREFACE

Thank you for purchase of the JRC Inmarsat Global Xpress GX Mobile Earth Station, JUE-60GX.

The JUE-60GX is an Inmarsat digital satellite communication terminal. The services of data communication, telephone, video chat and contents distribution are available on it with using Network Service Device (NSD) provided by Value Added Reseller (VAR).

The JUE-60GX is packaged and shipped under strict quality control with inspection criteria to deliver the equipment with highest quality, performance, and reliability needed to meet our customer's requirements and satisfaction.


JRC believes that you will use this equipment satisfactorily for a long time.

- Please read this manual carefully and carry out proper operation. This Manual describes a function and specification based on BDE-Version 0100.
- Please do not lose this useful manual, as you will have to refer to it from time to time.
- Network service is managed by Inmarsat co. or other network service providers. Network service may be changed or terminated without prior notice due to the circumstances of the network service providers.



JUE-60GX is manufactured in consideration of effects on environment.

● Safety Cautions ●



Cautions for High Voltage

High voltages, ranging from several hundreds to tens of thousands of volts, are used in electronic apparatus, such as radio and radar instruments. These voltages are totally harmless in most operations. However, touching a component inside the unit is very dangerous. (Any person other than authorized service engineers should not maintain, inspect, or adjust the unit.)

High voltages on the order of tens of thousand volts are most likely to cause instant deaths from electrical shocks. At times, even voltages on the order of several hundred volts could lead to electrocution. To defend against electrical shock hazards, don't put your hand into the inside of apparatus.

When you put in a hand unavoidably in case of urgent, it is strongly suggested to turn off the power switch and allow the capacitors, etc. to discharge with a wire having its one end positively grounded to remove residual charges. Before you put your hand into the inside of apparatus, make sure that internal parts are no longer charged. Extra protection is ensured by wearing dry cotton gloves at this time. Another important precaution to observe is to keep one hand in your pocket at a time, instead of using both hands at the same time. It is also important to select a secure footing to work on, as the secondary effects of electrical shock hazards can be more serious. In the event of electrical shocks, disinfect the burnt site completely and obtain medical care immediately.

Precautions for Rescue of Victim of Electric Shock

When a victim of electric shock is found, turn off the power source and ground the circuit immediately. If this is impossible, move the victim away from the unit as quick as possible without touching him or her with bare hands. He or she can safely be moved if an insulating material such as dry wood plate or cloth is used.

It is necessary to perform first aid immediately.

Breathing may stop if current flows through the respiration center of brain due to electric shock. If the electric shock is not large, breathing can be restored by artificial respiration. A victim of electric shock looks pale and his or her pulse may become very weak or stop, resulting in unconsciousness and rigidity at worst.

● Emergency Measures ●

Method of First-Aid Treatment


☆ Precautions for First-Aid Treatments

Apply artificial respiration to the person who collapsed, minimizing moving as much as possible avoiding risks. Once started, artificial respiration should be continued rhythmically.

- (1) Refrain from touching the patient carelessly as a result of the accident; the first-aider could suffer from electrical shocks by himself or herself.
- (2) Turn off the power calmly and certainly, and move the patient apart from the cable gently.
- (3) Call or send for a physician or ambulance immediately, or ask someone to call doctor.
- (4) Lay the patient on the back, loosening the necktie, clothes, belts and so on.
- (5)
 - (a) Feel the patient's pulse.
 - (b) Check the heartbeat by bringing your ear close to the patient's heart.
 - (c) Check for respiration by bringing your face or the back of your hand to the patient's face.
 - (d) Check the size of patient's pupils.
- (6) Opening the patient's mouth, remove artificial teeth, cigarettes, chewing gum, etc. if any. With the patient's mouth open, stretch the tongue and insert a towel or the like into the mouth to prevent the tongue from being withdrawn into the throat. (If the patient clenches the teeth so tight that the mouth won't open, use a screwdriver or the like to force the mouth open and then insert a towel or the like into the mouth.)
- (7) Wipe off the mouth to prevent foaming mucus and saliva from accumulating.

First Aid Method

Flow of Cardiopulmonary Resuscitation (CPR)



Specific Procedures for Cardiopulmonary Resuscitation (CPR)

1. Check the scene for safety to prevent secondary disasters

- Do not touch the injured or ill person in panic when an accident has occurred. (Doing so may cause electric shock to the first-aiders.)
- Do not panic and be sure to turn off the power. Then, gently move the injured or ill person to a safe place away from the electrical circuit.

2. Check for responsiveness

- Tap the shoulder of the injured or ill and shout in the ear saying, "Are you OK?"
- If the person opens his/her eyes or there is some response or gesture, determine it as "responding." But, if there is no response or gesture, determine it as "not responding."




3. If responding

- Give first-aid treatment.


4. If not responding

- Ask for help loudly. Ask somebody to make an emergency call and bring an AED.
 - Somebody has collapsed. Please help.
 - Please call an ambulance.
 - Please bring an **AED**.
 - If there is nobody to help, call an ambulance yourself.



5. Check for breathing

- Look to see if the chest and abdomen of the injured or ill person are rising and falling.



- If the injured or ill person is breathing, place him/her in the recovery position and wait for the arrival of the emergency services.
 - Position the injured or ill person on his/her side.





6. Cardiopulmonary resuscitation (CPR) (combination of chest compressions and rescue breaths)

a) Chest compressions


1) Position of chest compressions

- Position the heel of one hand in the center of the chest, approximately between the nipples, and place your other hand on top of the one that is in position.



2) Perform chest compressions


Perform uninterrupted chest compressions of 30 at the rate of about 100 - 120 times per minute, while locking your elbows positioning yourself vertically above your hands.



- With each compression, depress the chest wall to a depth of approximately 5 cm.

b) Combination of 30 chest compressions and 2 rescue breaths

- 1) If the first-aider is not trained in rescue breaths, he/she should perform only chest compressions.
- 2) If the first-aider is trained in rescue breath, and has the skill and will to do it, he/she should perform 30 chest compressions, then give 2 rescue breaths.
- 3) If there is a fear of infection, he/she should use a personal protective equipment (mouthpiece for rescue breathing).
- 4) Continuously perform the combination of 30 chest compressions and 2 rescue breaths without interruption.
- 5) If there are two or more first-aiders, alternate with each other approximately every two minutes (five cycles) without interruption.



7. When to stop cardiopulmonary resuscitation (CPR)

- a) When the injured or ill person has been handed over to the emergency services
- b) When the injured or ill person has started moaning or breathing normally, lay him/her on his/her side in a recovery position and wait for the arrival of emergency services.




8. Arrival and preparation of an AED

- a) Place the AED at an easy-to-use position. If there are multiple first-aiders, continue CPR until the AED becomes ready.
- b) Turn on the power to the AED unit. Depending on the model of the AED, you may have to push the power on button, or the AED automatically turns on when you open the cover.
- c) Follow the voice prompts of the AED.



9. Attach the electrode pads to the injured or ill person's bare chest

- a) Remove all clothing from the chest, abdomen, and arms.
- b) Open the package of electrode pads, peel the pads off and securely place them on the chest of the injured or ill person, with the adhesive side facing the chest. If the pads are not securely attached to the chest, the AED may not function. Paste the pads exactly at the positions indicated on the pads. If the chest is wet with water, wipe dry with a dry towel and the like, and then paste the pads. If there is a pacemaker or implantable cardioverter defibrillator (ICD), paste the pads at least 3 cm away from them. If a medical patch or plaster is present, peel it off and then paste the pads. If the injured or ill person's chest hair is thick, paste the pads on the chest hair once, peel them off to remove the chest hair, and then paste new pads.
- c) Some AED models require to connect a connector by following voice prompts.
- d) The electrode pads for small children should not be used for children over the age of 8 and for adults.



10. Electrocardiogram analysis

- a) The AED automatically analyzes electrocardiograms. Follow the voice prompts of the AED and ensure that nobody is touching the injured or ill person while you are operating the AED.
- b) On some AED models, you may need to push a button to analyze the heart rhythm.



11. Electric shock (defibrillation)

- a) If the AED determines that electric shock is needed, the voice prompt saying, "Shock is needed" is issued and charging starts automatically.
- b) When charging is completed, the voice prompt saying, "Press the shock button" is issued and the shock button flashes.
- c) The first-aider must get away from the injured or ill person, make sure that no one is touching him/her, and then press the shock button.
- d) When electric shock is delivered, the body of the injured or ill person may jerk.



12. Resurgence of cardiopulmonary resuscitation (CPR)

- a) Resume chest compressions by following the voice prompts of the AED.
 - With each compression, depress the chest wall to a depth of approximately 5 cm.
 - Perform compressions at the rate of 100 - 120 times per minute.



13. Automatic electrocardiogram analysis

- a) When 2 minutes have elapsed since you resumed cardiopulmonary resuscitation (CPR), the AED automatically analyzes the electrocardiogram.
- b) If you suspended CPR by following voice prompts and AED voice prompt informs you that shock is needed, give electric shock again by following the voice prompts.
If AED voice prompt informs you that no shock is needed, immediately resume CPR.

14. When to stop CPR (Keep the electrode pads on.)

- a) When the injured or ill person has been handed over to the emergency services
- b) When the injured or ill person has started moaning or breathing normally, lay him/her on his/her side in a recovery position and wait for the arrival of emergency services.



● BEFORE USING ●

JRC is indemnified for any damages from incorrect operation, malfunction, and other troubles except as outlined in the product warranty and by limitation of law.

Some functions of JUE-60GX may not work correctly owing to the hardware and software version of equipment connected to JUE-60GX. Please confirm that whether your equipment is connectable or not to the dealer or agent.

Your communication data are transmitted via the Inmarsat systems, therefore, there is a possibility that some errors may occur.

We strongly recommend important data be backed up to ensure safety and protection from loss.

Usually, digital scrambling of the Inmarsat system protects your communication data privacy.

However we caution you to understand that your communication data might be intercepted by special technology and unauthorized access to the communication theory.

Specifications of the JUE-60GX and its accessories may change without notice, for improvement.

Some functions may not be supported by a product version.

Please contact JRC for more information.

● Pictorial Indication ●

This Installation Manual

Before starting to use this device, read this instruction manual carefully to use it correctly.

This instruction manual also helps to solve problems.

Meanings of Pictorial Indication

Various pictorial indications are included in this manual and are shown on this equipment so that you can operate them safely and correctly and prevent any danger to you and / or to other persons and any damage to your property during operation. Such indications and their meanings are as follows.

Please understand them before you read this manual:

	DANGER	This indication is shown where incorrect equipment operation due to negligence may cause death or serious injuries.
	WARNING	This indication is shown where any person is supposed to be in danger of being killed or seriously injured if this indication is neglected and this equipment is not operated correctly.
	CAUTION	This indication is shown where any person is supposed to be injured or any property damage is supposed to occur if this indication is neglected and this equipment is not operated correctly.

Examples of Pictorial Indication



Electric Shock



The △ mark represents CAUTION (including DANGER and WARNING).

Detailed contents of CAUTION ("Electric Shock" in the example on the left) is shown in the mark.



Disassembling Prohibited



The ⊘ mark represents prohibition.

Detailed contents of the prohibited action ("Disassembling Prohibited" in the example on the left) is shown in the mark.



Disconnect the power plug



The ● mark represents instruction.

Detailed contents of the instruction ("Disconnect the power plug" in the example on the left) is shown in the mark.

Concerning Warning Label

Warning labels are put on the JUE-60GX.

Do not take off, destroy, or modify these labels.

* Windows Internet Explorer is the registered trademark of Microsoft Corporation.

Firefox is the registered trademark of Mozilla Foundation.


● Concerning warning label ●

Warning labels are put on the JUE-60GX ADE and BDE.

Do not take off, destroy, or modify these labels.

Warning Label of JUE-60GX ADE

(The illustration of upper part shows the safety Procedure for removing Radome from ADE.)



*1

*1: This mark means the attestation number which means safe, high-quality product and suits EU directive (Free circulation was permitted in the EU signatory).

Warning Label of JUE-60GX BDE



*1

*1: This mark means the attestation number which means safe, high-quality product and suits EU directive (Free circulation was permitted in the EU signatory).

● DURING OPERATION ●

DANGER



Do not touch any internal parts with your hands or tools.
It may cause fire, electrical shock or malfunction.

WARNING



Do not bring the power supply code close to the heat apparatus.
The coating of the code may be relieved, and it causes a fire and electric shock.



Keep out of the area within a radius of described below from your ADE respectively, while transmitting. It transmits microwave and strong microwave may cause injury.

JUE-60GX

Radiation Level	Distance
10 W/m ²	26 m
25 W/m ²	16 m
100 W/m ²	8 m

In case of approach within a radius of 26 meters by necessity, turn off the JUE-60GX and stop transmitting.



If an external matter, such as metal fragments, water, liquid, etc., infringe into your JUE-60GX, turn off the power and contact the dealer or agent you purchased.
Continuous operation may cause fire, electrical shock or malfunction.



Install JUE-60GX correctly in accordance with this manual.
Inappropriate installation may cause incorrect operation; fire, electrical shock, or malfunction.



Install ADE-BDE coaxial cable correctly in accordance with the Installation manual.
Especially waterproof should be treated correctly in accordance with the installation manual. Inappropriate installation may cause incorrect operation, fire, electric shock or malfunction.

WARNING



Use the specified power supply voltage only (90 VAC to + 264 VAC), otherwise trouble, fire, or electric shock or malfunction may occur.



Do not troubleshoot or repair the internal equipment of the JUE-60GX by yourself. Any electrical work by any person other than our trained maintenance staff may cause fire or abnormal operation of this equipment or electrical shock for you. This equipment meets the technical standard of the Ministry of Internal affairs and Communications.



Do not adjust the internal circuit without a calibrated measuring instrument or exchange the parts because the internal circuit has been adjusted finely to specifications. If the equipment works abnormally, please contact the purchasing dealer.



Do not remove, destroy, or modify warning labels. It may cause poor hazard prevention.



Do not insert a finger or foreign material into interspaces of fan. It may cause fire, electrical shock or malfunction.

CAUTION



Before using, read this instruction manual.
Incorrect operation may cause improper working operation or malfunction.



When a fault has been detected, refer to the “Appendix E”. If it is not improved, turn OFF and ON the power switch of main unit to reboot. Still it persists, stop operation and contact the dealer you purchased from.

ADE (Above Deck Equipment)



Do not deliver mechanical shock and/or force, because each unit of your ADE is a precision instrument. Unwanted shock and force may cause malfunction.



Do not paint the radome.
Painting of the radome may cause a decrease of the communication quality.

BDE (Below Deck Equipment)



Do not set/remove the ADE-BDE cable during power switch is turned on.
It may cause malfunction.



Do not remove the power supply cable before the power source disconnecting process is completed. It may cause malfunction.

Coaxial Cable and the other cables



Take care not to damage the connectors and the corrosion resistant sheath of cable. Otherwise, a trouble may occur.



Do not pull the cable by gripping connector plug only.
Otherwise, a trouble may occur.

Contents

PREFACE	i
• BEFORE USING •	ix
• Pictorial Indication •	x
• Concerning warning label •	xi
• DURING OPERATION •	xii
Section 1 Inmarsat GX systems.....	1-1
1.1 Outline	1-1
1.1.1 Coverage area of Inmarsat 5 th generation satellite	1-1
1.1.2 Inmarsat Global Xpress system	1-2
1.2 Inmarsat Global Xpress Services.....	1-4
1.3 Important reminder for using JUE-60GX	1-5
Section 2 Introduction of the JUE-60GX	2-1
2.1 Outline	2-1
2.2 Features.....	2-2
2.3 Interconnection diagram and components List.....	2-3
2.3.1 Interconnection diagram	2-3
2.3.2 Components list	2-4
2.4 Dimensional drawing (JUE-60GX standard components).....	2-5
2.4.1 ADE (Above Deck Equipment) JUE-60GX [NTG-428].....	2-5
2.4.2 BDE (Below Deck Equipment) JUE-60GX [NTF-329].....	2-6
2.5 Dimensional Drawing (Option).....	2-7
2.5.1 Coaxial cable [CFQ-3922A35]	2-7
Section 3 Components	3-1
3.1 Above Deck Equipment (ADE).....	3-1
3.2 Below Deck Equipment (BDE).....	3-2
3.2.1 Appearance.....	3-2
3.2.1.1 Front view	3-2
3.2.1.2 Rear view.....	3-2
3.2.2 Front view	3-3
3.2.3 Rear view	3-3
3.3 ADE - BDE connection cable.....	3-5
3.4 Communication devices	3-6
3.4.1 Device connection example.....	3-6
Section 4 Setup.....	4-1
4.1 Connecting devices and power on	4-1
4.1.1 Connecting devices and BDE	4-1

4.2 Browsing the Web Interface	4-2
4.2.1 BDE power on/off	4-3
4.2.1.1 Power on	4-3
4.2.1.2 Power off	4-6
4.3 Setting external input of BOW correction value, GYRO, and GPS.....	4-7
Section 5 Web Interface.....	5-1
5.1 Connection between PC and JUE-60GX	5-2
5.1.1 Setting the PC network.....	5-2
5.1.2 Connection between PC and BDE.....	5-6
5.2 JUE-60GX login and logout	5-7
5.2.1 Accessing JUE-60GX with the Web browser.....	5-7
5.2.2 Login.....	5-8
5.2.3 Logout.....	5-9
5.3 Overview of the Web interface.....	5-10
5.3.1 Screen structure of the Web interface	5-10
5.3.1.1 Top area.....	5-11
5.3.1.2 Navigation area	5-11
5.3.1.3 Operation area	5-12
5.3.2 Saving logs (common operation)	5-13
5.4 Menus available to all the users.....	5-14
5.4.1 Checking the JUE-60GX status ([Dashboard] - [Status] menu).....	5-14
5.4.2 Checking and saving an Alarmpack ([Logs] - [Alarmpack]).....	5-18
5.4.2.1 Expanding/shrinking the Alarmpack Log section	5-24
5.4.3 Checking and saving event logs ([Logs] - [Event Log]).....	5-25
5.4.4 Checking and saving statistics logs of the antenna control section ([Logs] - [AC Monitor]).....	5-27
5.4.5 Checking and saving system logs ([Logs] - [Syslog]).....	5-29
5.4.5.1 Displaying and filtering system logs	5-30
5.4.5.2 Saving system logs	5-32
5.5 Menus available to ADMIN users.....	5-34
5.5.1 Setting JUE-60GX basic data ([Settings] - [Terminal])	5-34
5.5.2 Setting transmission forbidden area and blocking area ([Settings] - [Tx Limit & Blockage]).....	5-36
5.5.3 Changing an ADMIN user password ([Settings] - [Account]).....	5-39
5.5.4 Upgrading the JUE-60GX software ([Tools] - [Software Upgrade]).....	5-40
5.5.5 Exporting/importing settings ([Tools] - [Export / Import])	5-41
5.5.5.1 Exporting setting data.....	5-41
5.5.5.2 Importing setting data.....	5-42
5.5.6 Using the diagnostic function ([Tools] - [Diagnostic])	5-44
5.5.6.1 Setting Syslog transfer	5-45
5.5.6.2 Checking the connection status by Ping	5-46
5.5.6.3 Setting GPS Auto Cold Start.....	5-47

5.5.7	Rebooting the system ([Tools] – [Reboot])	5-48
5.5.7.1	Rebooting procedure	5-48
5.5.8	Deleting alarmpacks/resetting to the factory default state ([Others] - [Factory Default])	5-49
5.5.8.1	Deleting alarmpacks	5-49
5.5.8.2	Resetting to the factory default state	5-49
5.5.9	Setting JRC LAN ([Others] - [JRC LAN])	5-50
Section 6	Maintenance	6-1
	Daily maintenance	6-1
Section 7	After-sales service	7-1
	When ordering repair	7-1
	Recommendation of professional maintenance	7-1
	Disposal of the JUE-60GX	7-1
Section 8	Specification	8-1
Appendix A	Web Interface Menu Tree	A-1
A.1	Menu for JUE-60GX GUEST users	A-1
A.2	JUE-60GX ADMIN users	A-2
Appendix B	Software Upgrading Procedure	B-1
B.1	Downloading the latest software	B-2
B.2	Upgrading software	B-3
B.2.1	Failing software upgrading	B-5
	Error display example	B-5
	Main error codes	B-5
	Main error causes	B-6
B.2.2	Software rollback function	B-7
	Switching the equipment setting to the normal mode (main mode)	B-7
B.3	Checking the software version	B-8
Appendix C	Initializing the settings to the factory default state	C-1
Appendix D	List of Initial Values (Version 0100)	D-1
Appendix E	Troubleshooting & FAQ	E-1
E.1	Power on, start and termination	E-1
E.2	Satellite acquisition, tracking, communication	E-3
E.3	Web interface	E-5
E.4	Corrective action when alarm occurs	E-6
E.5	Problem related to communication service	E-9
E.6	Other problem	E-10

Appendix F	LED of BDE	F-1
F.1	BDE LED display sequence and display at the occurrence of abnormality.....	F-2
F.1.1	LED display sequence.....	F-2
F.1.2	LED display sequence at software upgrading	F-4
Appendix G	Abbreviations and Glossary	G-1
Appendix H	JRC Network	H-1
Appendix I	Hazardous substances of Electrical and electronic Products ...	I-1

Section 1 Inmarsat GX systems

1.1 Outline

1.1.1 Coverage area of Inmarsat 5th generation satellite

Inmarsat Global Xpress system (abbreviated as Inmarsat GX system) covers the earth's surface except at the high latitude areas near the North Pole and the South Pole.

Inmarsat GX terminals are available for any type of vehicle or ship, and are capable of communicating day and night.


The Inmarsat GX systems coverage map displays the area of three satellite regions

- I5-F1 Europe, the Middle East, Africa and Asia
- I5-F2 The Americas and the Atlantic Ocean Region
- I5-F3 The Pacific Ocean Region
- I5-F4 Asia

One Inmarsat 5th generation satellite (geosynchronous satellite) is deployed in each ocean region. And each ocean region has an overlapped area with the neighboring regions. When JUE-60GX is in an overlapped area, the optimum satellite is selected automatically for communication.

Note

A geosynchronous satellite might be added or deployed to other position in the future.



1.1.2 Inmarsat Global Xpress system

The Inmarsat Global Xpress system consists of NOC and SAS Functions of each facility are as follows:

Network Operation Center (NOC)

The NOC located at the INMARSAT headquarters in London U.K., coordinates communication lines of the network 24 hours a day, 365 days a year.

The NOC maintains contact via dedicated satellite and terrestrial links with the NCSs and SASs in all Ocean regions.

The NOC performs the following:

- Coordination with the Satellite Control Center (SCC) for operation of satellites.
- Coordination with NCS and/or SAS for system operation.
- Collection of any status data in operation.
- Coordination of any test of satellite's performance.

OBC (Operational Backup Center):


OBC backs up data of NOC.

SAS (Satellite Access Station)

The SASs located in Fucino (Italy), Burum (Holland) and Hawaii (America) which are the gateway systems operating inter-working with public network (including telephone and Internet).

POP (Points Of Presence)

POP is the gateway to public communication lines.



1.2 Inmarsat Global Xpress Services

The Inmarsat Global Xpress system provides the following services.

All the services can be used concurrently.

<p>Internet access</p> 	<ul style="list-style-type: none">• Packet switching• Best effort <p>Note The maximum communication speed is determined by the communication charge contract.</p>
<p>Voice</p> 	<ul style="list-style-type: none">• VoIP• Enables voice communication during data communication <p>Note This service is need NSD provided by VAR.</p>
<p>Video chat</p> 	<ul style="list-style-type: none">• Videophone by using a smartphone or PC <p>Note This service cannot be used when a FB backup line is used.</p>
<p>Content distribution</p>	<ul style="list-style-type: none">• Distribution of newspaper, video, voice, and marine chart

1.3 Important reminder for using JUE-60GX

Note

- The Global Xpress services are operated by Inmarsat and some other network service providers. The Global Xpress services may be changed or terminated without prior notice due to the circumstance of the service providers.



Section 2 Introduction of the JUE-60GX

2.1 Outline

JUE-60GX is an inmarsat satellite communications system that supplies high-speed IP network service, Internet, e-mail, and IP phone, etc. The GX network service is available connecting Network Service Device (NSD) supplied by Value Added Reseller (VAR).

The JUE-60GX Mobile Earth Station (MES) is composed of Above Deck Equipment (ADE) and Below Deck Equipment (BDE).

ADE comprises an antenna equipment, an antenna interface module (AIM), Block up Converter(BUC), Low Noise Block (LNB), and a radome, and BDE comprises a broadband interface module (BIM) and a standard core module (SCM).

2.2 Features

Full support for technical requirements of the latest Fleet Xpress

JUE-60GX is specifically suitable for the Fleet Xpress technical requirements in the latest Global Xpress requirements. JUE-60GX is a suitable solution for Mobile Earth Station for any type of vessel, navigating the world's oceans.

High-quality communication

JUE-60GX can use the following services that are provided by Inmarsat.

- High-speed data communications using Internet Protocol techniques.
- Voice communications and multimedia sessions over Internet Protocol networks (need NSD)

Note

The service available to you is depending on the contract.
--

Compact design

The JUE-60GX can be installed on vessels of all sizes due to the compact and lightweight design of the ADE. The adoption of an active and Gyro-less antenna structure makes this unit a perfect fit for small vessels.


Since only two coaxial cables are used for the ADE-BDE connection, JUE-60GX can be installed easily. The Rewindless antenna achieves uninterrupted communication during circling.

Self-diagnosis system

The built-in self-diagnosis system continually monitors the status of the JUE-60GX and indicates the warnings if any errors are detected.

2.3 Interconnection diagram and components List

2.3.1 Interconnection diagram



2.3.2 Components list

	Name of equipment	Type	Q'ty
Standard Components	ADE	NTG-428	1
	BDE	NTF-329	1
	Instruction Manual	7ZPSC0584	1
	Installation Manual	7ZPSC0586	1
	Quick Reference Guide	7ZPSC0588	1
	CD-ROM	7ZPSC0602	1
	Supplied parts for ADE installation	MPXP35369	1
	Supplied parts for BDE installation	7ZXSC6002* (※)	1
Option	Coaxial cable (between ADE and BDE)	CFQ-3922A35 (35 m)	2
	Instruction Manual (Japanese)	7ZPSC0585	1
	Installation Manual (Japanese)	7ZPSC0587	1
	Quick Reference Guide (Japanese)	7ZPSC0589	1

(※) "*" means revision, such as A,B and so on

Coaxial cable

CFQ-3922A series (5D) and CFQ-3923A series (10D, maximum 60 m) coaxial cables are available.


Coaxial cable length (m)	Type	
	TX	RX
30	CFQ-3922A3	CFQ-3922A3
35	CFQ-3922A35 (standard)	CFQ-3922A35 (standard)
40	CFQ-3922A4 or CFQ-3923A4	CFQ-3923A4
50	CFQ-3922A5 or CFQ-3923A5	CFQ-3923A5
60	CFQ-3922A6 or CFQ-3923A6	CFQ-3923A6

If the cables are supplied by customer, refer the installation guide "3.1 Connecting cables". The following table lists the recommended cable type and maximum RX coaxial cable length.





Type	Maximum cable length
CNT-600-FR	100m
LMR-600-FR	100m
CNT-400-FR	70m
LMR-400-FR	70m
RG-214/U	35m
RG-223	18m

2.4 Dimensional drawing (JUE-60GX standard components)

2.4.1 ADE (Above Deck Equipment) JUE-60GX [NTG-428]




2.4.2 BDE (Below Deck Equipment) JUE-60GX [NTF-329]



Unit: mm
Mass: approx .6.5 kg

2.5 Dimensional Drawing (Option)

2.5.1 Coaxial cable [CFQ-3922A35]



Type	Length	Connector Dia.	Cable Dia.	Mass	Minimum bending radius	Remarks
CFQ-3922A35	35 m±0.5 m	30 mm	15 mm	8.8 kg	100 mm	N connector

Concerning cable length option, please refer to 2.3.2.

Section 3 Components

This section describes the configuration of JUE-60GX and connected equipment.

3.1 Above Deck Equipment (ADE)

The radome covers the antenna equipment, which is composed of:

- Above deck unit with built in Antenna Interface Module (AIM)
- Antenna pedestal
- Block UP Converter (BUC)
- GPS antenna
- Low Noise Block (LNB)
- Rotary joint

The above deck equipment (ADE) is connected to the below deck equipment (BDE) with two coaxial cables. Control signals and power to the above deck equipment (ADE) are transmitted through the coaxial cable on the RX side.



3.2 Below Deck Equipment (BDE)

3.2.1 Appearance


3.2.1.1 Front view



3.2.1.2 Rear view




3.2.2 Front view



No.	Name	Function outline
(1)	Power switch	Turns power on and off.
(2)	LED	Indicates the equipment status. The meanings and sequence of the LEDs are described in [Appendix F].

3.2.3 Rear view



No.	Name	Function outline	Supplement
(1)	GPS/GYRO connector	Connects GPS and GYRO	Maximum cable length: 1 km (complies with NMEA) Conversion cable for serial communication and power control is attached.
(2)	EXT connector	Connects JRC LAN. By connecting with JRC LAN, added values such as remote maintenance and status monitor functions are made available.	Connector shape: RJ-45 Maximum cable length: 100 m LAN Standard: 100Base-T
(3)	USER connector/ MGMT connector	USER: Connects the Network Service Device (NSD). MGMT: Connects NSD management port.	Connector shape: RJ-45 Maximum cable length: 100 m LAN Standard: 100Base-T


No.	Name	Function outline	Supplement
(4)	ADE- BDE (TX) connector	Used for the connection of a transmission coaxial cable of ADE.	Connector shape: SMA connector (ADE: N connector) Coaxial conversion cable is attached to connect with coaxial cable.
(5)	ADE- BDE (RX) connector	Used for the connection of a reception coaxial cable of ADE.	Connector shape: TNC connector (ADE: N connector) Coaxial conversion cable is attached to connect with coaxial cable.
(6)	Fan	Cools BDE.	The fan rotational speed fluctuates according to the temperature inside of the equipment.
(7)	AC power connector	Connects the cable that supplies power to BDE.	AC inlet 3P
(8)	Earth terminal screw	Used for grounding. The following effects are available. <ul style="list-style-type: none"> • Reduction of impact of lightning damage • Prevention of electrostatic discharge • Suppression of noise generated externally 	
(9)	Fuse	Melts down when overcurrent is detected and shuts out the circuit. Replacement procedure: Loosen the folder head in the anti-clockwise direction by 90 degrees with a slotted screwdriver. When the folder is ejected, remove the folder. Replace the fuse to a new one and set it in the folder. Insert the folder and tighten it in the clockwise direction.	Rated current: 6 A Quantity: 2

3.3 ADE - BDE connection cable

This cable is used for connecting ADE and BDE.

Memo

This coaxial cable can be connected in either direction.



Notes

Two coaxial cables are used, one for transmitting and one for receiving.

The following optional cables are made available.

- CFQ-3922A3 (30 m)
- CFQ-3922A35 (35 m)
- CFQ-3923A4 (40 m)
- CFQ-3923A5 (50 m)
- CFQ-3923A6 (60 m)

3.4 Communication devices

3.4.1 Device connection example

Refer to specification supplied by VAR.

Section 4 Setup

This section describes the procedure for connecting peripheral devices and BDE, BOW correction value adjustments, and external input settings of GYRO and GPS.


4.1 Connecting devices and power on

4.1.1 Connecting devices and BDE

Connect the setup PC and MGMT LAN with Ethernet cable.

Note

If NSD is connected to the MGMT LAN, temporarily disconnect the connection.



Set the IP address of the PC. Under the factory default settings, JUE-60GX is set as follows.

BDE IP address	192.168.1.2
ADE IP address	192.168.1.3
ADE/BDE subnet mask	255.255.255.0

Here, as an example, the IP address of PC is set as follows.

IP address	192.168.1.100
Subnet mask	255.255.255.0


4.2 Browsing the Web Interface

Display the Web interface with the Web browser of PC and access JUE-60GX.

Notes

- JUE-60GX officially supports Mozilla Firefox 23. Firefox upper-level versions and compatible browsers are also supported.
- Cookie must be enabled with the Web browser.

- 1 Start the Web browser.**
- 2 Enter `http://192.168.1.2:9443/` in the URL box and press the [Enter] key on the keyboard.**




Note

PC must be in the same network as BDE.

4.2.1 BDE power on/off

4.2.1.1 Power on

- 3 Check the following items before turning on the power.**
 - There are no obstructions between the antenna and the satellite.
 - The power breaker is set to on.
 - The coaxial cable from ADE is properly connected to the BDE.
- 4 Set the BDE power switch to on.**
The LED indicators on the front side lights in the following sequence.




How to read the LED panel

NET	TX	RX1	RX2	STATUS	CM PWR
■	■	■	■	■	■
READY	ANT	STS1	STS2	STS3	STS4
■	■	■	■	■	■


G Green On	R Red On	Y Yellow On
G Green Blink	R Red Blink	■ Off
 Undecided		

The shapes and precise colors of LED are different from the actual shapes and colors.


BDE power switch on




Starting boot loader




Starting OS



Completed OS start, starting core module (CM)





Completed CM start



To searching satellite

How to read the LED panel




Notes

- When the LED indication is different from any of the above, an error is assumed. For error indications and the meanings, refer to “Appendix F.1” and for error handling procedures, refer to “Appendix E”.
- Even if a large sound is emitted from ADE at power on, this does not mean a fault.

5 The automatic satellite search (acquisition) function operates.

- JUE-60GX calculates the satellite position from the current position information that was measured by GPS, automatically directs the antenna to the satellite direction, and acquires the satellite.
- After acquisition, the antenna direction angle is automatically controlled so that the received signal strength becomes the maximum.
- The LED indication at the front switches in the following sequence.



Notes


- When the LED indication is different from any of the above, an error is assumed. For error indications and the meanings, refer to “F.1” and for error handling procedures, refer to “Appendix E”.
- NET LED may not be lit in green for 10 minutes after power is turned on. This is due to initialization, satellite search, and network registration and does not mean a fault. It may take 20 to 30 minutes until NET LED is lit in green depending on the status of the wave propagation quality.
When the satellite search function fails, please consult with your distributor or JRC sales office.

4.2.1.2 Power off


Turn off the power switch.

READY LED starts blinking in red and power disconnection processing is executed during this time. At completion of power disconnection processing, all the LED indicators go off and the power is turned off.

BDE power switch off



Completed power off



 **CAUTION**



Do not unplug the power cable while power disconnection is in progress.

4.3 Setting external input of BOW correction value, GYRO, and GPS

This section describes the external input setting procedures of BOW correction value, GYRO, and GPS.


The BOW correction can offset the angle error from the bow. The more this value is correct, the faster antenna can find the satellite.

Carry out this setting by selecting [Settings] – [Terminal] menu of the Web interface.

For the Web interface use procedure, refer to “5.3”.

Notes
 These settings are enabled by logging into the system under the ADMIN user.
 The ADMIN user name under the factory default is “ADMIN” and the password is “000001”.


- 1 Select [Settings] - [Terminal] menu.
- 2 Set the following items.



Item	Contents
FWD from Bow	<p>Set a BOW correction value within the range of -180.0 to +180.0.</p> <p>The FWD mark on the ADE should be in the range of $\pm 1.5^\circ$ to ship's forward. If the ADE must be installed at an angle beyond this range, it can be installed at any angle by setting this angle.</p> <p>First, enter the approximate offset angle and click "set" and power off the Antenna and power on.</p> <p>Next, when the ADE can track the satellite stably, the [Auto Calc.] button is clicked on, the highly accurate BOW correction value is calculated automatically and renews an accurate value.</p> <p>Note To apply the value that is calculated automatically, it is also necessary to click on the [Set] button.</p> <p>Memo It takes about 1 minute for automatic calculation.</p>

GYRO Input	<p>Select the external GYRO input from the drop-down list.</p> <p>Disable: Not used.</p> <p>NMEA(4.8 kbps): Use serial (4.8 kbps) input.</p> <p>NMEA(38.4 kbps): Use serial (38.4 kbps) input.</p> <p>LAN: Use LAN input.</p> <p>Note</p> <p>Supported NMEA sentences:</p> <ul style="list-style-type: none"> •VHW (Water speed and Heading) •HDT (Heading True) •THS (True Heading and Status) <p>To reflect the setting change, the equipment must be restarted.</p>
GPS Input	<p>Select the external GPS input to be used from the drop-down list.</p> <p>Disable: Not used.</p> <p>NMEA(4.8 kbps): Use serial (4.8 kbps) input.</p> <p>NMEA(38.4 kbps): Use serial (38.4 kbps) input.</p> <p>LAN: Use LAN input.</p>

3 Save/apply the settings by clicking on [Set] button after the settings.



4 Restart the equipment to reflect the setting change.

Section 5 Web Interface

This section describes the procedure to connect PC and JUE-60GX, login to JUE-60GX from the Web browser, change setting and check status.

The following items are mainly described.

Item	Outline
5.1 Connection between PC and JUE-60GX	Describes the network setting of PC and cable connection between PC and JUE-60GX ports.
5.2 JUE-60GX login and logout	Describes the procedure for accessing JUE-60GX through the Web browser.
5.3 Overview of the Web interface	Describes the overview of the Web interface.
5.4 Menus available to all the users	<p>Describes the following menus that are available to all the users (GUEST and ADMIN).</p> <ul style="list-style-type: none"> • 5.4.1 Checking the JUE-60GX status ([Dashboard] - [Status] menu) • 5.4.2 Checking and saving an Alarmpack ([Logs] - [Alarmpack]) • 5.4.3 Checking and saving event logs ([Logs] - [Event Log]) • 5.4.4 Checking and saving statistics logs of the antenna control section ([Logs] - [AC Monitor]) • 5.4.5 Checking and saving system logs ([Logs] - [Syslog])
5.5 Menus available to ADMIN users	<p>Describes the following menus that are available to ADMIN users only.</p> <ul style="list-style-type: none"> • 5.5.1 Setting JUE-60GX basic data ([Settings] - [Terminal]) • 5.5.2 Setting transmission forbidden area and blocking area ([Settings] - [Tx Limit & Blockage]) • 5.5.3 Changing an ADMIN user password ([Settings] - [Account]) • 5.5.4 Upgrading the JUE-60GX software ([Tools] - [Software Upgrade]) • 5.5.5 Exporting/importing settings ([Tools] - [Export / Import]) • 5.5.6 Using the diagnostic function ([Tools] - [Diagnostic]) • 5.5.7 Rebooting the system ([Tools] - [Reboot]) • 5.5.8 Deleting alarmpacks/resetting to the factory default state ([Others] - [Factory Default]) • 5.5.9 Setting JRC LAN ([Others] - [JRC LAN])

Note

A required screen may not be able to be displayed depending on the JUE-60GX utilization status. In this case, click on the item again.

5.1 Connection between PC and JUE-60GX

5.1.1 Setting the PC network


Set the network in PC to connect PC with JUE-60GX.

In this section, it is assumed that Microsoft Windows 7 is used and JUE-60GX is started with the initial settings.

Note


The setting screen may vary depending on the operating environment.

- 1 Open the [Start] menu on the desktop and click on the [Control Panel].
The “Control Panel” window is displayed.
- 2 Click on [View network status and tasks].




The “Network and Shared Center” window is displayed.

3 Click on [Local Area Connection].




The "Local area connection status" dialog box is displayed.

4 Click on the [Properties] button.



The "Properties of local area connection" dialog box is displayed.

- 5 Select [Internet Protocol Version 4 (TCP/IPv4)] of the [Networking] tab and click on the [Properties] button.



The [Properties of Internet protocol (TCP/IP)] dialog box is displayed.


- 6 Select [Use next IP address] to set the IP address manually.
- 7 Set the IP address of PC. Under the factory default settings, JUE-60GX is set as follows.

BDE IP address	192.168.1.2
ADE IP address	192.168.1.3
ADE/BDE subnet mask	255.255.255.0

Here, as an example, the IP address of PC is set as follows.

IP address	192.168.1.100
Subnet mask	255.255.255.0

8 Click on the [OK] button.



Note
In this description, the factory default settings are used.

The [Properties of local area connection] dialog box is displayed.


9 Click on the [Close] button.

5.1.2 Connection between PC and BDE

- 1 Connect MGMT LAN and PC with an Ethernet cable.

Note

If NSD is connected to the MGMT LAN, temporarily disconnect the connection.



Memo

JUE-60GX automatically recognizes the Ethernet cable type (cross or straight).

5.2 JUE-60GX login and logout

5.2.1 Accessing JUE-60GX with the Web browser


Display the Web interface with the Web browser of PC and access JUE-60GX.

Notes

- JUE-60GX formally supports Mozilla Firefox 23. Firefox upper-level versions and compatible browsers are also supported.
- Cookie must be enabled with the Web browser.

1 Star the Web browser.

2 Enter <http://192.168.1.2:9443/> in the URL box and press the [Enter] key on the keyboard.

**Note**

PC must be in the same network as BDE. Make sure that the preparation described in "5.1.1" has been performed in advance.

The Web interface screen is displayed.

The screenshot shows the JRC Global Xpress JUE-60GX web interface. The top navigation bar includes the JRC logo, device name, signal strength indicator, and various status icons (NET, RDY, TX, ANT, RX1, ST1, RX2, ST2, STS, ST3, CMP, ST4). The user is identified as GUEST with a level of Guest. A 'Log in' button is visible in the top right corner. The left sidebar shows a navigation menu with 'GUEST', 'Dashboard', 'Status', and 'Logs'. The main content area displays the 'Status' page, which includes a 'Unit Status' section with details for Antenna Cont., AIM, BIM, and BUC. It also shows 'Satellite' information (Longitude, Sat-EL, Sat-AZ), 'Antenna' data (Heading, EL, Bearing, X), 'GPS' coordinates (Time, Latitude, Longitude), and 'Alarm' status (None). A copyright notice for Japan Radio Co., Ltd. is at the bottom.

5.2.2 Login

After accessing the Web interface, the screen displays the functions that are available to GUEST users.

GUEST users are only allowed to check the terminal status.

ADMIN users are allowed to set terminal settings in addition to the authorization available to GUEST users.

This section describes the procedure for logging into JUE-60GX from the Web interface screen as an ADMIN user.


- 1 Click on the [Log in] button at the top right corner of the screen.




The "User Login" screen is displayed.

2 Enter an ADMIN user name and a password and click on the [Log in] button.

Under the factory default setting, "ADMIN" is set as the ADMIN user name and "000001" as the password.




The ADMIN user screen is displayed.



ADMIN user dedicated menu

The login status is displayed on the right side of the top area.




Login status

Memo

While the system is logged in under the ADMIN user, the [Login] button is changed to the [Log out] button.

5.2.3 Logout

Click on the [Log out] button at the top right corner of the screen.



5.3 Overview of the Web interface

5.3.1 Screen structure of the Web interface

This section describes the screen structure of the Web interface.

Memo

For the subsequent explanation, the ADMIN user screen is used.

Top area
Refer to "5.3.1.1".

The screenshot shows the following components:

- Top area:** A red header bar containing the JRC logo, device name 'Global Xpress JUE-60GX', signal strength indicator, various status LEDs (NET, RDY, TX, ANT, RX1, ST1, RX2, ST2, STS, ST3, CMP, ST4), user information 'User: ADMIN Level: Admin', and a 'Log out' button.
- Navigation area:** A left sidebar menu with options: GUEST, Dashboard, Status (selected), Logs, ADMIN, Settings, Tools, and Others. Below the menu is the version '0100' and a circular antenna diagram with technical data: HD: 00, ELEV: 0.0, STATUS: Idle(0x20).
- Operation area:** The main content area titled 'Status' displaying unit and satellite information.


Unit Status			
Antenna Cont.	0x20 Idle		
AIM	3: Core Module connected	Int-GPS	Invalid
BIM	3: Core Module connected	Ext-GPS	Disable
BUC	1: Connected	GYRO	Disable
Satellite			
Longitude	Sat-EL	0.0
		Sat-AZ	0.0
Antenna			
Heading [deg]	---	Bearing [deg]	0.0
EL [deg]	2.2	X [deg]	2.1
GPS			
Time	00:03:06 --/--/----	Latitude
		Longitude
Alarm			
Alarm	None	BIM	----
		AIM	----
		CM	----
		BUC	----

Copyright©2014 Japan Radio Co., Ltd. All Rights Reserved.

Navigation area
Refer to "5.3.1.2".

Operation area
Refer to "5.3.1.3".


5.3.1.1 Top area

Item	Description
	<p>Reception level indicator</p> <p>The reception levels are displayed on the 6-level bar.</p> <p>Green normal state, white means the transmission inhibition state.</p> <p>For blocking, refer to “5.5.2”.</p> <p>The signal type is displayed on the left side of the bar.</p> <p>(Gsc): Receiving global beam (Dvbs2): Receiving spot beam (None): Indeterminate</p>
	<p>BDE LED display</p> <p>Displays communication and equipment statuses.</p> <p>For the details, refer to “Appendix F”.</p>
	<p>Displays login user information.</p> <p>The current login user name is displayed in the upper level and the user authorization level is displayed in the lower level.</p>
	<p>[Log in] button</p> <p>Click on this button when logging into the terminal as an ADMIN user.</p> <p>For the details, refer to “5.2.2”.</p>
	<p>[Log out] button</p> <p>Click on this button when logging out from the ADMIN user.</p> <p>For the details, refer to “5.2.3”.</p>


5.3.1.2 Navigation area

The functions that can be executed by users are displayed in menu format.

Menu that can be executed by all the users (GUEST/ADMIN)




Menu that can be executed by ADMIN users only



When a menu is selected, the equipment information and setting items related to the menu are displayed in the operation area.

The version number of the software and antenna information (including blocking information) are displayed below the menu.



Memo

The menu that is displayed in the navigation area varies depending on the login status.

5.3.1.3 Operation area

The equipment information and setting items of the menu that was selected in the navigation area are displayed.

5.3.2 Saving logs (common operation)

Logs can be saved in a file under the Web interface.

Logs include alarmpack log, event log, antenna control section log, and system log, and all the logs are saved in a same file.

Logs can be saved from the following menus.

Menu	Related section
[Logs] - [Alarmpack]	5.4.2.1
[Logs] - [Event Log]	5.4.3
[Logs] - [AC Monitor]	5.4.4
[Logs] - [Syslog]	5.4.5

For logs, click on the [File] button of the operation area in the menu that is shown above. Logs can be saved on these menus by the common procedure. In this section, [Logs] - [Alarmpack] is used as the example.



Notes

- It takes about 1 minute to save a log file.
- For logs of the antenna control section, while up to 100 items can be displayed on the screen, up to 7,200 events can be saved.

Memo

For system logs only, the log to be saved can be selected. Refer to “5.4.5.2” for the system log saving procedure.

1 Click on the [File] button.



Example: Alarmpack log

A file processing dialog is displayed.

2 Specify a file save destination and click on the [OK] button.

The file is saved.

5.4 Menus available to all the users

5.4.1 Checking the JUE-60GX status ([Dashboard] - [Status] menu)

Display procedure

Select [Dashboard] - [Status] in the navigation area.

Function outline

This function checks the statuses of JUE-60GX, satellite, antenna, GPS, and alarm.

Screen example



Status			
Unit Status			
(1)	Antenna Cont.	0x31 SEARCH: Measuring GSC noise	
(2)	AIM	3: Core Module connected	Int-GPS Valid (GGA, RMC) (5)
(3)	BIM	3: Core Module connected	Ext-GPS Valid (GGA, ZDA, RMC) (6)
(4)	BUC	1: Connected	GYRO Disable (7)
Satellite			
(8)	Longitude	180° 00' 00" E	Sat-EL 24.7 (9)
			Sat-AZ 114.4 (10)
Antenna			
(11)	Heading [deg]	---	Bearing [deg] 0.0 (13)
(12)	EL [deg]	0.0	X [deg] -83.2 (14)
GPS			
(15)	Time	08:53:43 04/DEC/2015	Latitude 32° 45' 00" N (16)
			Longitude 129° 50' 57" E (17)
Alarm			
(18)	Alarm	None	BIM ---- (19)
			AIM ---- (20)
			CM ---- (21)
			BUC ---- (22)

Copyright©2014 Japan Radio Co., Ltd. All Rights Reserved.

Unit Status

Displays the status of JUE-60GX.

No.	Item	Description
(1)	Antenna Cont.	Status of the antenna control section 0x00 Power ON: Checking the hardware 0x01 Boot Idle: Checking the program 0x1* Initializing: Initializing 0x2* Idle: Waiting for GPS signals 0x3* Searching: Searching satellite 0x4* Locked/Tracking: Satellite acquisition/tracking state 0x6* Miss-point: Detection of deterioration of reception level 0xa* Offbeam: Calibrating the cable 0x99 Error: Error status (* = an alphanumeric character)
(2)	AIM	ADE status 0:Under initialization: Initializing 1:AIM-BIM connected: Completed the connection of AIM and BIM. 2:Antenna control connected: Completed the connection of AIM and antenna control section. 3:Core Module connected: Completed the connection with the core module. 4:Processing: Processing (or power reduction mode) Disconnected: Not connected
(3)	BIM	Displays the BDE status 0:Under initialization: Initializing 1:AIM-BIM connected: Completed the connection of AIM and BIM. 2:Antenna control connected: Completed the connection of BIM and the antenna control section. 3:Core Module connected: Completed the connection with the core module. 4:Processing: Processing (or power reduction mode) Disconnected: Not connected
(4)	BUC	BUC status 0:Initializing: Not connected 1:Connected: Connected 2:Disconnected: Disconnected
(5)	Int-GPS	Displays the status of the built-in GPS. Disconnected: Not connected Invalid: Not received Valid (GGA) : Received GGA (Global Positioning System Fixed Data). Valid (GGA, ZDA) : Received GGA and ZDA (Time & Date). Valid (GGA, RMC) : Received GGA and RMC (Recommended Minimum Specific GNSS Data). Valid (GGA, ZDA, RMC): Received GGA, ZDA, and RMC.

No.	Item	Description
(6)	Ext-GPS	Displays the status of the external GPS Disable: Disabled by terminal setting Disconnected: Not connected Invalid: Not received Valid (GGA) : Received GGA (Global Positioning System Fixed Data). Valid (GGA, ZDA) : Received GGA and ZDA (Time & Date). Valid (GGA, RMC) : Received GGA and RMC (Recommended Minimum Specific GNSS Data). Valid (GGA, ZDA, RMC): Received GGA, ZDA, and RMC.
(7)	GYRO	Displays the status of the external GYRO. Disable: Disabled by terminal setting Disconnected: Not received Received heading: Received heading information.

Satellite

Displays the satellite information.

No.	Item	Description
(8)	Longitude	Displays the satellite longitude with “degrees/minutes/seconds + EW”. At non-acquisition, “---° ---’ ---“ --“ is displayed.
(9)	Sat-EL	Displays the angle of elevation of the satellite within the range from 0.0 to 90.0. At non-acquisition, “0.0” is displayed.
(10)	Sat-AZ	Displays the satellite azimuth within the range from 0.0 to 359.9. At non-acquisition, “0.0” is displayed.

Antenna

Displays the information relating to the antenna orientation.

No.	Item	Description
(11)	Heading [deg]	Displays the heading angle within the range from 0.0 to 359.9. At non-acquisition, “---“ is displayed.
(12)	EL [deg]	Displays the angle of elevation of the antenna within the range from -20.0 to 120.0.
(13)	Bearing [deg]	Displays the bearing angle within the range from 0.0 to 359.9.
(14)	X [deg]	Displays the X axial angle within the range from -30.0 to 30.0.

GPS

Displays GPS information.

No.	Item	Description
(15)	Time	Displays the GPS time. At non acquisition, the elapsed time since the startup of the equipment is displayed.
(16)	Latitude	Displays the latitude of GPS with “degrees/minutes/seconds + NS”. At non acquisition, ---° ---′ ---“ --“ is displayed.
(17)	Longitude	Displays the longitude of GPS with “degrees/minutes/seconds + NS”. At non acquisition, ---° ---′ ---“ --“ is displayed.

Alarm

Displays the alarm detection status.

For the alarm details, refer to the alarm table of “Appendix E4”.

No.	Item	Description
(18)	Alarm	Displays the unit name that alarm is currently being issued. Unit name: [AIM], [BIM], [CM], and [BUC] When no alarm is issued, None is displayed.
(19)	BIM	Displays the details of the BIM alarm that is currently being issued. When no alarm is issued, “---“ is displayed.
(20)	AIM	Displays the details of the AIM alarm that is currently being issued. When no alarm is issued, “---“ is displayed.
(21)	CM	Displays the details of the CM alarm that is currently being issued. When no alarm is issued, “---“ is displayed.
(22)	BUC	Displays the details of the BUC alarm that is currently being issued. When no alarm is issued, “---“ is displayed.

5.4.2 Checking and saving an Alarmpack ([Logs] - [Alarmpack])

Display procedure

Select [Logs] - [Alarmpack] in the navigation area.

Function outline

This function enables the checking of equipment-specific information, current equipment status (Current), past equipment startup status, and alarm fluctuation history (up to 50 items).

Alarm information can be saved in a file (refer to “5.3.2”).

Notes

The specification for recording logs in the alarmpack of JUE-60GX is different from other models in the following points.

1. Records logs without alarm in the alarmpack since the equipment status is recorded immediately after the startup of the equipment.
2. Records the alarmpack even if alarms are cleared since changes of alarm occurrence and clearance are recorded.

Screen example

Terminal Information

Equipment-specific information is displayed.

Refer to “5.3.2”.

Alarmpack

File

Terminal Information

JRC	ADE	Serial No.	MAC
	BDE		
Common		ACU Vendor	RF Terminal Type
		JRC	1060

(1)

Terminal Identification	LNB	Part No.	Serial No.	
		E0001660-0001	A00452A43	
		Manufacturer ID	Functional ID	
		10	?	
		Serial No.	Type	Rollback
	AIM		version_1	Main
	BIM		version_1	Main

(2)

Maintenance No.	Boot	Main RFS	Main App	Safe	Sub RFS	Sub App
	AIM	0100	0101	0017	0100	0016
	BIM	0100	0101	0017	0100	0016
	Boot	Main	System			
	Antenna	0.3	00.65	00.03		
	App					
	BUC	00.72				

(3)

No.	Item	Description
(1)	JRC	Displays the JRC manufacturing number (7 digits) and the MAC address of each of ADE and BDE.
(2)	Terminal Identification	Displays the hardware specific information of LNB, AIM, and BIM.
(3)	Maintenance No.	AIM/BIM: Displays the following information for each of AIM and BIM. Boot: Boot maintenance number Main RFS: Main RFS number Main App: Main application number Safe: Safe mode maintenance number Sub RFS: Sub RFS number Sub App: Sub application number Antenna: Displays the following antenna information. Boot: Boot maintenance number Main: Main antenna number System: System number BUC: Displays the following BUC information. App: Application number

Alarmpack Log section

This section displays the history at equipment startup and alarm occurrence/clearance. The top of the list indicates the current equipment status (Current) and the history of up to the past 50 items is displayed. Alarms are classified by unit (AIM, BIM, CM, and BUC). The unit name from which an alarm is issued is displayed in red. The unit name from which no alarm is issued is displayed in black. The history under which all the units are displayed in black indicates that the equipment has started or all alarms have been resolved.

Terminal status is recorded at startup and alarm status change.

Expand All Expand AIM Expand BIM Expand CM Expand BUC

Current 02:20:33 31/OCT/2019

All AIM BIM CM BUC

Refer to "5.4.2.1".

(4)

Refer to "5.4.2.1".

AIM-ALM None							
SAT-Long	179.6	SAT-AZ	125.1	SAT-EL	31.2		
Hunt-Freq	1890.000	Hunt-BW	31.999				
Search-Sts	0x44	Search-Mode	GYRO-less	Search-Opt	00000000	MissPoint	1
ANT-BR	130.8	ANT-EL	31.0	ANT-X	-0.2		
RSSI-Gsc	0	RSSI-Dvbs2	21780				
Int-GPS-Sts	Valid	Int-GPS-Sat	9	Int-GPS-Hd	213.6		
VibX-Max	0.0	VibX-Ave	0.0	VibY-Max	0.1	VibY-Ave	0.0
VibZ-Max	1.0	VibZ-Ave	0.9	Rol-Max	-0.5	Rol-Ave	0.0
Pit-Max	0.2	Pit-Ave	0.0	Impact-Acc	1440		
AIM-Tmp	42.0	Eth-Link	DOWN	Voltage-Min	47.0	Voltage-Ave	47.1
Keyline	On	Wlan-Ant	Ant-1				
Wlan-Tx	150	Wlan-Pwr	-36	Wlan-Ch	2442	Wlan-SSID	jrc
BIM-ALM None							
GPS-Lat	35° 39' 07" N	GPS-Lon	139° 48' 34" E	GPS-Time	02:20:33 31/OCT/2019		
GPS-InUse	IntGPS						
SPV-Sts	3	CM-RSSI1	---	CM-RSSI2	---		
GYRO-Hd	---	FWD	0.0	GYRO-Mode	Disable		
Ext-GPS-Sts	Disable	Ext-GPS-Sat	0	Ext-GPS-Mode	Disable	Ext-GPS-Data	---
BIM-Tmp	31.0	Eth-Link	15	Current	2.21	Fan-Acc	0
Keyline	On	Scm-Power	1	Wlan-Ant	Ant-1		
Wlan-Tx	150	Wlan-Pwr	-62				
CM-ALM None							
LED-NET	Green	LED-TX	Green	LED-RX1	Green	LED-RX2	Yellow
LED-ST5	Green	LED-CMP	Green	Lock	1		
BUC-ALM None							
Tx-Direct	e3e	HPA-Temp	48.9	Lo-PLL	Lock	Power	1
1	00:01:14 --/--/----			All	AIM	BIM	CM BUC
2	00:01:13 --/--/----			All	AIM	BIM	CM BUC
3	00:01:17 --/--/----			All	AIM	BIM	CM BUC
4	00:01:14 --/--/----			All	AIM	BIM	CM BUC
5	00:01:24 --/--/----			All	AIM	BIM	CM BUC
6	00:01:10 --/--/----			All	AIM	BIM	CM BUC
7	12:16:53 12/OCT/2019			All	AIM	BIM	CM BUC
8	00:01:23 --/--/----			All	AIM	BIM	CM BUC
9	00:01:14 --/--/----			All	AIM	BIM	CM BUC

No.	Item	Description
(4)	Alarm list	Current: Displays the current time and alarm information by unit (AIM, BIM, CM, and BUC). 1 to 50 (maximum): Displays the information on past alarms. For the details of the alarm information by unit, refer to the following table.

AIM

SAT-Long Longitude of the satellite	SAT-AZ Azimuth of the satellite	SAT-EL Angle of elevation of the satellite	
Hunt-Freq Hunt frequency	Hunt-BW Hunt bandwidth		
Search-Sts Antenna control status	Search-Mode Satellite search mode	Search-Opt Search options	MissPoint Miss point information
ANT-BR Antenna bearing	ANT-EL Angle of elevation of the antenna	ANT-X Antenna axial angle	
RSSI-Gsc RSSI of GSC	RSSI-Dvbs2 RSSI of DVBS2		
Int-GPS-Sts Internal GPS reception status	Int-GPS-Sat GPS observation mode	Int-GPS-Hd GPS heading	
VibX-Max Maximum vibration value of X axis	VibX-Ave Average vibration value of X axis	VibY-Max Maximum vibration value of Y axis	VibY-Ave Average vibration value of Y axis
VibZ-Max Maximum vibration value of Z axis	VibZ-Ave Average vibration value of Z axis	Rol-Max Maximum pitch in the rolling direction	Rol-Ave Average pitch in the rolling direction
Pit-Max Maximum pitch in the pitching direction	Pit-Ave Average pitch in the pitching direction	Impact-Acc Excessive impact accumulated time	
AIM-Tmp AIM substrate temperature	Eth-Link Ethernet port status	Voltage-Min Minimum voltage of AIM	Voltage-Ave Average voltage of AIM
Keyline Keyline information	Wlan-Ant No. of wireless LAN antennas		
Wlan-Tx Wireless LAN TX	Wlan-Pwr Wireless LAN transmission power	Wlan-Ch Wireless LAN communication channel	Wlan-SSID Wireless LAN SSID

BIM

GPS-Lat Latitude of own ship	GPS-Lon Longitude of own ship	GPS-Time UTC time	
GPS-InUse GPS in use			
SPV-Sts SPV status	CM-RSSI1 RSS1 of receiver 2	CM-RSSI2 RSS2 of receiver 2	
GYRO-Hd Ship's heading	FWD FWD from Bow	GYRO-Mode GYRO input setting	
Ext-GPS-Sts External GPS reception status	Ext-GPS-Sat No. of satellites that receive by external GPS	Ext-GPS-Mode External GPS input setting	Ext-GPS-Data External GPS reception sentence
BIM-Tmp BIM substrate temperature	Eth-Link Ethernet port status	Current Current value	Fan-Acc Accumulated FAN operation time
Keyline Keyline information	Scm-Power Power supply to SCM	Wlan-Ant No. of wireless LAN antennas	
Wlan-Tx Wireless LAN TX	Wlan-Pwr Wireless LAN transmission power		

CM

LED-NET NET LED status	LED-TX TX LED status	LED-RX1 RX1 LED status	LED-RX2 RX2 LED status
LED-STs STATUS LED status	LED-CMP CM POWER LED status	Lock CM locking status 0:Unlock 1:Lock	

BUC

<p>Tx-Ditect Transmission power</p>	<p>HPA-Temp BUC temperature</p>	<p>Lo-PLL PLL unlocking information</p>	<p>Power Power supply to BUC 0 :Keyline : PA On :OpenBMIP : enabled or unspecified 1 :Keyline : PA On :OpenBMIP : disabled 2 :Keyline : PA Standby :OpenBMIP : enabled 3 :Keyline : PA Standby :OpenBMIP : disabled</p>
---	-------------------------------------	---	---

5.4.2.1 Expanding/shrinking the Alarmpack Log section

Display of the Alarmpack Log section can be expanded or shrunk.

Terminal status is recorded at startup and alarm status change.

Alarmpack Log

Current 00:23:38 --/--/----

AIM-ALM [GPS]

Shrink All		Shrink AIM		Shrink BIM		Shrink CM		Shrink BUC	
All		AIM		BIM		CM		BUC	
SAT-Long	0.0	SAT-AZ	0.0	SAT-EL	0.0				
Hunt-Freq	0.000	Hunt-BW	0.000						
Search-Sts	0x20	Search-Mode	GYRO	Search-Opt	00000000	MissPoint	0		
ANT-BR	0.0	ANT-EL	-1.1	ANT-X	2.4				
RSSI-Gsc	8040	RSSI-Dvbs2	0						
Int-GPS-Sts	Invalid	Int-GPS-Sat	0	Int-GPS-Hd	0.0				
VibX-Max	0.0	VibX-Ave	0.0	VibY-Max	0.0	VibY-Ave	0.0		
VibZ-Max	1.0	VibZ-Ave	0.9	RoI-Max	2.2	RoI-Ave	2.1		
Pit-Max	-1.2	Pit-Ave	-1.1						
AIM-Tmp	30.3	Eth-Link	DOWN	Voltage-Min	47.7	Voltage-Ave	47.7		
Keyline	Off	Wlan-Ant	Ant-1						
Wlan-Tx	150	Wlan-Pwr	-14	Wlan-Ch	2442	Wlan-SSID	jrc		

When this section is clicked on, the display of the applicable unit is shrunk and the information is set to non-display. When [Shrink All] button is clicked on, information of all the units is shrunk and is set to non-display.



Terminal status is recorded at startup and alarm status change.

Alarmpack Log

Current 00:23:38 --/--/----

1 00:10:01 --/--/----

2 00:01:26 --/--/----

3 00:01:12 --/--/----

4 00:10:01 --/--/----

5 00:01:26 --/--/----

Expand All		Expand AIM		Expand BIM		Expand CM		Expand BUC	
All		AIM		BIM		CM		BUC	
All	AIM	BIM	CM	BUC					
All	AIM	BIM	CM	BUC					
All	AIM	BIM	CM	BUC					
All	AIM	BIM	CM	BUC					
All	AIM	BIM	CM	BUC					
All	AIM	BIM	CM	BUC					

When this section is clicked on, the display of the applicable unit is expanded and the information is displayed. When [Expand All] button is clicked on, information of all the units is expanded and is displayed.

When this item is clicked on, the information on the related unit is displayed. When the [All] button is clicked on, information on all the units is displayed.

Current 00:23:38 --/--/----

AIM-ALM [GPS]

All		AIM		BIM		CM		BUC	
SAT-Long	0.0	SAT-AZ	0.0	SAT-EL	0.0				
Hunt-Freq	0.000	Hunt-BW	0.000						
Search-Sts	0x20	Search-Mode	GYRO	Search-Opt	00000000	MissPoint	0		
ANT-BR	0.0	ANT-EL	-1.1	ANT-X	2.4				
RSSI-Gsc	8040	RSSI-Dvbs2	0						
Int-GPS-Sts	Invalid	Int-GPS-Sat	0	Int-GPS-Hd	0.0				
VibX-Max	0.0	VibX-Ave	0.0	VibY-Max	0.0	VibY-Ave	0.0		
VibZ-Max	1.0	VibZ-Ave	0.9	RoI-Max	2.2	RoI-Ave	2.1		
Pit-Max	-1.2	Pit-Ave	-1.1						
AIM-Tmp	30.3	Eth-Link	DOWN	Voltage-Min	47.7	Voltage-Ave	47.7		
Keyline	Off	Wlan-Ant	Ant-1						
Wlan-Tx	150	Wlan-Pwr	-14	Wlan-Ch	2442	Wlan-SSID	jrc		

5.4.3 Checking and saving event logs ([Logs] - [Event Log])

Display procedure

Select [Logs] - [Event Log] in the navigation area.

Function outline

This function enables the checking of up to 1,000 events that occurred in AIM and BIM.

Event logs can be saved in a file also (refer to “5.3.2”).

Screen example

Event Log

File

#	Date/Time	Event	Parameter 1	Parameter 2
1	00:09:56 --/--/----	Alarm Detected	[GPS] [COMM_GYRO]	
2	00:02:56 --/--/----	Connected	CM	
3	00:01:39 --/--/----	Alarm Detected	[COMM_GYRO]	
4	00:01:25 --/--/----	Start	App = 3470	Rollback = Main
5	00:04:36 --/--/----	Power Off	Reboot request	
6	00:03:15 --/--/----	Connected	CM	
7	00:02:00 --/--/----	Alarm Detected	[COMM_GYRO]	
8	00:01:45 --/--/----	Start	App = 3470	Rollback = Main

Refer to “5.3.2”

See below for the meaning of log.

Item	Description
Date/Time	Displays the logging time in the format of “00:00:00 DD/MMM/YYYY (UTC)”.
Event	Event For the details, refer to “Details of events and parameters”.
Parameter 1	Parameter For the details, refer to “Details of events and parameters”.
Parameter 2	Parameter For the details, refer to “Details of events and parameters”.

Details of events and parameters

Display name	Outline	Details	
		Parameter 1	Parameter 2
Start	Start of equipment	Software version at starting	"Rollback = Main" or "Rollback = Sub"
Power Off	Turning off power of equipment	Reason for power off Success: 0 = "Power switch"; Failure: 1 = "Sequence time out (T16)"; 2 = "Sequence time out (T8)"; 3 = "AIM-BIM disconnect"; 4 = "Antenna control disconnect"; 5 = "Antenna control status"; 6 = "Web reboot";	-
GPS Fixed	GPS signal reception	Latitude Web : "<degrees>° <minutes>' <seconds>" <N or S>"	Longitude Web : "<degrees>° <minutes>' <seconds>" <E or W>"
Searching Start	Start of satellite search	Transition of Search-Sts "Search-Sts : <Before Search-Sts> to <After Search-Sts>"	Satellite longitude , Hunt frequency "SAT-Long : <longitude> Hunt-Freq : <frequency>"
Satellite Found	Satellite detection	Transition of Search-Sts "Search-Sts : <Before Search-Sts> to <After Search-Sts>"	Satellite longitude , Hunt frequency "SAT-Long : <longitude> Hunt-Freq : <frequency>"
Satellite Locked	Satellite locking and tracking	Transition of Search-Sts "Search-Sts : <Before Search-Sts> to <After Search-Sts>"	Satellite longitude , Hunt frequency "SAT-Long : <longitude> Hunt-Freq : <frequency>"
In Network	Service availability status	-	-
Alarm	Alarm detection	The list of all alarms that are currently being issued.	-
Alarm Cleared	Recovery from alarm	The list of all alarms that are currently being issued.	-
OTC Started	One Touch Commissioning Started	-	-

5.4.4 Checking and saving statistics logs of the antenna control section ([Logs] - [AC Monitor])

Display procedure


Select [Logs] - [AC Monitor] in the navigation area.

Function outline

Up to 100 items of event log of the antenna section can be checked.

Event logs can be saved in a file (refer to “5.3.2”).

Screen example



AC Monitor

File

Refer to “5.3.2”

Log

```
No,ROLL MAX,ROLL AVE,PITCHING MAX,PITCHING AVE,IMPACT X MAX,IMPACT X
AVE,IMPACT Y MAX,IMPACT Y AVE,IMPACT Z MAX,IMPACT Z AVE,VOLT MIN,VOLT
AVE,GPS LAT,GPS LON,GPS TIME
0001,36.0,36.0,-27.0,-27.0,0.0,0.0,0.0,0.0,1.0,1.0,47.6,47.6,---,---,--,-
---,---,-- ,07:31:43 --/---/-----
0002,36.0,36.0,-27.0,-27.0,0.0,0.0,0.0,0.0,1.0,0.9,47.6,47.6,---,---,--,-
---,---,-- ,07:25:43 --/---/-----
0003,36.0,36.0,-27.0,-27.0,0.0,0.0,0.0,0.0,1.0,1.0,47.6,47.6,---,---,--,-
---,---,-- ,07:19:43 --/---/-----
0004,36.0,36.0,-27.0,-27.0,0.0,0.0,0.0,0.0,1.0,0.9,47.6,47.6,---,---,--,-
---,---,-- ,07:13:42 --/---/-----
0005,36.0,36.0,-27.0,-27.0,0.0,0.0,0.0,0.0,1.0,1.0,47.6,47.6,---,---,--,-
---,---,-- ,07:07:42 --/---/-----
0006,36.0,36.0,-27.0,-27.0,0.0,0.0,0.0,0.0,1.0,1.0,47.6,47.6,---,---,--,-
---,---,-- ,07:01:42 --/---/-----
0007,36.0,36.0,-27.0,-27.0,0.0,0.0,0.0,0.0,1.0,1.0,47.6,47.6,---,---,--,-
---,---,-- ,06:55:42 --/---/-----
0008,36.0,36.0,-27.0,-27.0,0.0,0.0,0.0,0.0,1.0,1.0,47.6,47.6,---,---,--,-
---,---,-- ,06:49:42 --/---/-----
0009,36.0,36.0,-27.0,-27.0,0.0,0.0,0.0,0.0,1.0,1.0,47.6,47.6,---,---,--,-
```

Record Interval: 6 minutes

See below for the meanings of the log.

Item	Description
No.	Record number
ROLL MAX	Maximum roll angle(deg.)
ROLL AVE	Average roll angle(deg.)
PITCHING MAX	Maximum pitch angle(deg.)
PITCHING AVE	Average pitch angle(deg.)
IMPACT X MAX	Maximum vibration acceleration in the X-axis direction
IMPACT X AVE	Average vibration acceleration in the X-axis direction
IMPACT Y MAX	Maximum vibration acceleration in the Y-axis direction
IMPACT Y AVE	Average vibration acceleration in the Y-axis direction
IMPACT Z MAX	Maximum vibration acceleration in the Z-axis direction
IMPACT Z AVE	Average vibration acceleration in the Z-axis direction
VOLT MIN	Minimum voltage (V)
VOLT AVE	Average voltage (V)
GPS LAT	GPS latitude (indicates degrees/minutes/seconds)
GPS LON	GPS longitude (indicates degrees/minutes/seconds)
GPS TIME	GPS time (hh:mm:ss)

Notes

- The maximum values, minimum values, and average values are the statistics of the past 6 minutes.
- The latest values (values at the time of recording) are displayed as GPS values.

5.4.5 Checking and saving system logs ([Logs] - [Syslog])

Display procedure

Select [Logs] - [Syslog] in the navigation area.

Function outline

System logs of JUE-60GX can be checked. The system log to be displayed can be selected by the filter function. System logs can be saved in a file.

Screen example


The screenshot displays the Syslog configuration page. At the top left, there is a 'Syslog' header. Below it, a box contains two buttons: 'All File' and 'Minimum File'. A line points from this box to the text 'Refer to "5.4.5.2"'. Below this is a 'Filter' section with several options: 'File' (radio buttons for 'All(RAM)' and 'Recent'), 'Level' (checkboxes for 'ERROR', 'WARNING', 'NOTICE', 'INFORMATION', 'DEBUG'), and 'Word' (checkboxes for 'AIM', 'BIM'). There is also a 'Rows' dropdown set to '100' (range '0~9999') and a 'keyword' input field. 'Update' and 'Reset' buttons are present. A line points from the 'Filter' section to the text 'Refer to "5.4.5.1"'. Below the filter is a 'Log' section with 'Results:0' and a large empty box for log entries. At the bottom, there are 'Download Displayed Log' and 'Set' buttons. The footer contains the copyright notice: 'Copyright©2014 Japan Radio Co., Ltd. All Rights Reserved.'

5.4.5.1 Displaying and filtering system logs

Logs are not displayed immediately after logging into the Web interface. Logs can be displayed in the following procedure.

1 Click on the [Update] button.

System logs are displayed in [Log].



The screenshot shows the Syslog web interface. At the top, there are buttons for "All File" and "Minimum File". Below that is a "Filter" section with the following options:

- File:** All(RAM), Recent, Rows: 100 (0~9999)
- Level:** ERROR, WARNING, NOTICE, INFORMATION, DEBUG
- Word:** AIM, BIM, keyword: []

There are "Update" and "Reset" buttons. The "Update" button is highlighted with a red box. Below the filter section is the "Log" area, which shows "Results:100" and a list of log entries. The log entries include timestamps, log levels, and messages such as "[GPS][MSG]GPVGTG,000-0,T,,000-0,N,000-0,K#20" and "[ANT]<RX> MSG=0x000c0004". At the bottom of the log area, there are "Download Displayed Log" and "Set" buttons.

Filtering a system log to be displayed

1 Set a selection filtering from [File], [Level], and [Word].

Filtering condition	Description
File	A log is filtered based on the file. Search is performed based on the file. All (RAM): Searches all the syslog files in RAM. Recent: Searches only the latest syslog file in RAM. Rows: Searches until the number of rows that are displayed reaches the specified number from all the syslog files in RAM.
Level	A log is filtered based on the log level (multiple levels can be selected). ERROR: Error log WARNING: Warning log NOTICE: Notice log INFORMATION: Information log DEBUG: Debugging log
Word	A log is filtered based on the character string. AIM: Log containing AIM BIM: Log containing BIM Word: Log containing the character string that is input in the text box that is displayed on the right side when this item is selected


2 Click on the [Update] button.

The selected system log is displayed in [Log].

Filtering example:

Clearing display of system log

Click on the [Reset] button.




The filter setting is cleared.

5.4.5.2 Saving system logs

System logs can be saved by setting the logs to be saved.


- 1 Select a file to be saved and click on the [Set] button.



Item	Description
Download Displayed Log	Targets the system log that is currently displayed for saving.
Download syslog in RAM	Targets the system logs that are stored in RAM for saving.
Download syslog in ROM	Targets system logs that are stored in ROM for saving.
Clear syslog in RAM	Deletes system logs that have been stored in RAM.

2 To save all the logs, click on the [File] button of [All].

To save logs excluding the system logs in ROM, click on the [File] button of [Minimum].



A file processing dialog is displayed.

3 Specify file save and click on the [OK] button.

The file is saved.

5.5 Menus available to ADMIN users

5.5.1 Setting JUE-60GX basic data ([Settings] - [Terminal])

Display procedure

Select [Settings] - [Terminal] of the navigation area.

Function outline

The JUE-60GX basic data is set.

Screen example

Terminal

Terminal Setting

(1)	Delivery Date	1 / JAN / 2013
(2)	FWD from Bow	0.0 Auto Calc. This takes 1 minute.
(3)	GYRO Input	NMEA(4.8k) *
(4)	GPS Input	Disable *
(5)	VDR Output	LAN *
(6)	Panel LED	On
(7)	Ethernet LED	On
(8)	Impact Indication	On

Set

* : reboot required

Impact Accumulator

(9)	Impact Accumulator Time	Clear
-----	-------------------------	-------

The setting procedure is as follows.

1 Set the following items.

No.	Item	Description
(1)	Delivery Date	Set the JUE-60GX operation starting date. The operation starting date not only indicates the communication starting date after installation of JUE-60GX but also is useful for judging the guarantee period. Set a correct date.
(2)	FWD from Bow	Set the FWD angle based on the bow angle within the range of -180.0 to +180.0. When the [Auto Calc.] button is clicked on, the value is calculated automatically. Note To set the value that is calculated automatically, click on the [Set] button. Memo It takes about 1 minute for automatic calculation.

No.	Item	Description
(3)	GYRO Input	<p>Select the external GYRO input from the combo box.</p> <p>Disable: Not used.</p> <p>NMEA(4.8 kbps): Use serial (4.8 kbps) input.</p> <p>NMEA(38.4 kbps): Use serial (38.4 kbps) input.</p> <p>LAN: Use LAN input.</p> <p>Note</p> <p>Supported NMEA sentences:</p> <ul style="list-style-type: none"> ·VHW (Water speed and Heading) ·HDT (Heading True) ·THS (True Heading and Status) <p>To reflect the setting change, the equipment must be restarted.</p>
(4)	GPS Input	<p>Select the external GPS input to be used from the combo box.</p> <p>Disable: Not used.</p> <p>NMEA(4.8 kbps): Use serial (4.8 kbps) input.</p> <p>NMEA(38.4 kbps): Use serial (38.4 kbps) input.</p> <p>LAN: Use LAN input.</p> <p>Note</p> <p>To reflect the setting change, the equipment must be restarted.</p>
(5)	VDR Output	<p>Set whether remote maintenance data is output to VDR.</p> <p>Disable: Not output</p> <p>LAN: Output with LAN</p> <p>Note</p> <p>To reflect the setting change, the equipment must be restarted.</p>
(6)	Panel LED	<p>Set whether the LED panel of BDE is set to OFF forcibly.</p> <p>When OFF is set, the LED panel goes off regardless of the equipment status.</p> <p>On: Not set to OFF forcibly (normally blinks).</p> <p>Off: Set to OFF forcibly (LED goes off).</p>
(7)	Ethernet LED	<p>Set whether Ethernet LED set to OFF forcibly.</p> <p>When OFF is set, the Ethernet LED goes off regardless of whether the terminal is connected to the LAN port.</p> <p>On: Not set to OFF forcibly (normally blinks).</p> <p>Off: Set to OFF forcibly (LED goes off).</p>
(8)	Impact indication	<p>Set whether Impact indication LED set to OFF forcibly.</p> <p>On: Not set to OFF forcibly (normally blinks).</p> <p>Off: Set to OFF forcibly (LED goes off).</p> <p>Note</p> <p>To reflect the setting change, the equipment must be restarted.</p>
(9)	Impact accumulator time	<p>Clear the Impact accumulator time.</p> <p>When press the [Clear] button, the accumulated counter returns to 0 and the Impact alarm is cleared.</p>

2 After setting, save/apply the setting by clicking on the [Set] button.

5.5.2 Setting transmission forbidden area and blocking area ([Settings] - [Tx Limit & Blockage])

Display procedure

Select [Settings] - [TX Limit & Blockage] in the navigation area.

Function outline

This function enables the setting of a transmission prohibition area and a blocking area.

For a transmission prohibition area, set in which people may enter under the radio wave transmission active state within the area of 26 m from the antenna. Since radio wave transmission is suspended when the antenna indicates the transmission prohibition area, safe equipment operation can be supported by setting a transmission prohibition area even if operation with a sufficient safe distance secured is difficult.

For a blocking area, set an area within which communication with a satellite is difficult due to obstacles such as mast or funnel of the ship. Registered transmission prohibited areas and blocking areas are displayed in the navigation area.

A total of up to 10 transmission prohibition areas and blocking areas can be set.

Screen example

TX Limit & Blockage

TX Limitation & Blockage Indication Area

No.	Function	EL Max	EL Min	AZ Begin	AZ End
1	Disable				
2	Disable				
3	Disable				
4	Disable				
5	Disable				
6	Disable				
7	Disable				
8	Disable				
9	Disable				
10	Disable				

AZ : Angle from Bow

Blockage Area Diagram

Copyright©2014 Japan Radio Co., Ltd. All Rights Reserved.

The area setting procedure is as follows.

- 1 When the area is set as a transmission prohibition area, select [TX Limitation] from the [Function] combo box of desired No..
- 2 When the area is set as a blocking area, select [Blockage Indication] from the [Function] combo box of desired No..
- 3 Set a range.

TX Limit & Blockage

TX Limitation & Blockage Indication Area

No.	Function	EL Max	EL Min	AZ Begin	AZ End
1	Blockage Indication	80	45	300	80
2	TX Limitation	60	50	0	359

EL Max	EL Min	AZ Begin	AZ End
Input an upper limit angle of EL within the range from -20 to 90.	Input a lower limit angle of EL within the range from -20 to 90.	Input a starting angle of AZ within the range from 0 to 359.	Input an ending angle of AZ within the range from 0 to 359.

- 4 Repeat steps 1 to 3 as required.
- 5 Save/apply the setting by clicking on the [Set] button after setting.


TX Limit & Blockage

TX Limitation & Blockage Indication Area

No.	Function	EL Max	EL Min	AZ Begin	AZ End
1	Blockage Indication	80	45	300	80
2	TX Limitation	60	50	0	359
3	Disable				
4	Disable				
5	Disable				
6	Disable				
7	Disable				
8	Disable				
9	Disable				
10	Disable				

AZ : Angle from Bow

The setting result is displayed in the Blockage Area Diagram.



A blocking area is displayed in blue.

A transmission prohibition area is displayed in red.

A Blockage Area Diagram is displayed in the navigation area other than [Settings] - [TX Limit & Blockage] screen.

5.5.3 Changing an ADMIN user password ([Settings] - [Account])

Display procedure

Select [Settings] - [Account] in the navigation area.

Function outline

Set an ADMIN user password.

Screen example

The screenshot shows the 'Account' settings page. It features a table with columns for 'ID', 'Name', 'Password', and 'Set'. The 'ADMIN' user (ID 1) has a password field containing six dots and a 'Set' button. The 'GUEST' user (ID 2) has 'N/A' in the password field. A copyright notice is visible at the bottom: 'Copyright©2014 Japan Radio Co., Ltd. All Rights Reserved.'

ID	Name	Password	Set
1	ADMIN	••••••	Set
2	GUEST	N/A	

The ADMIN user password change method is as follows.

- 1** Click on the [Password] input field of [ADMIN].
The input field becomes blank space.
- 2** Enter a password using 6 to 12 one byte alphanumeric characters.
- 3** Save/apply the setting by clicking on the [Set] button after setting.

This screenshot is identical to the previous one, but the 'Password' input field for the 'ADMIN' user is highlighted with a black border, indicating it is the active field for editing.

ID	Name	Password	Set
1	ADMIN		Set
2	GUEST	N/A	

5.5.4 Upgrading the JUE-60GX software ([Tools] - [Software Upgrade])

Display procedure


Select [Tools] - [Software Upgrade] in the navigation area.

Function outline

Upgrade software.

For the details, refer to “Appendix B”.

Screen example



The screenshot shows a web interface titled "Software Upgrade". It is divided into two main sections: "Upgrade File" and "Rollback".

Software Upgrade

Upgrade File

No file selected.

Please select upgrade file and push Upgrade Start button.

Rollback

Main

5.5.5 Exporting/importing settings ([Tools] - [Export / Import])


Display procedure

Select [Tools] - [Export / Import] in the navigation area.

Function outline

By exporting setting data of the equipment to PC, the setting data can be backed up. Setting data that has been saved can also be imported to the equipment.

Screen example



Export / Import

Export

Export

Import

Browse... No file selected.

Import

Terminal will automatically reboot to complete Import.

5.5.5.1 Exporting setting data

- 1 Click on the [Export] button.



Export / Import

Export

Export

A file processing dialog is displayed.


- 2 Specify an export destination of the setting data and click on the [OK] button.
The setting data is exported.

5.5.5.2 Importing setting data

Note


When setting data is imported, the original setting data cannot be restored.

- 1 Click on the [Browse...] button.




A file selection dialog is displayed.

- 2 Select setting data to be imported.
- 3 Click on the [Import] button.



4 Click on the [Yes] button.



5

Import starts.

When import is completed normally, the following message is displayed.



5 Automatic reboot of the system is done.

Automatic reboot is performed , to enable the imported configuration file.

5.5.6 Using the diagnostic function ([Tools] - [Diagnostic])

Display procedure

Select [Tools] - [Diagnostic] in the navigation area.

Function outline

This function performs a diagnostic test of JUE-60GX.

In [Setting Transmission Syslog], the Syslog messages that are recorded by JUE-60GX can be transferred to the user-specified server. For the setting procedure, refer to “5.5.6.1”.

In [Ping], the connection between JUE-60GX and a device can be checked by transmitting a ping packet to the specific host from the IP address of the selected unit. For the procedure, refer to “5.5.6.2”.

In [GPS Auto Cold Start], to set the self-diagnosis function of the built-in GPS.

Note

JRC shall not be liable for the communication charge problems that arise while this function is being used except when such a condition is included in the product guarantee or is applicable to the provision of the law.

Screen example

Diagnostic

Syslog Transmission Setting

Enable/Disable	Server IP	Protocol	Port No.(default:514)	Log Level	Set
Disable ▾	<input type="text"/>	UDP ▾	514	ERROR ▾	<input type="button" value="Set"/>

Ping

Source	Destination	Packet Length	Total Transmissions
192.168.1.2 ▾	<input type="text"/>	32	4

Result:

GPS Auto Cold Start

Enable/Disable	Set
Enable ▾	<input type="button" value="Set"/>

Copyright©2014 Japan Radio Co., Ltd. All Rights Reserved.

5.5.6.1 Setting Syslog transfer

To receive transferred syslog, the syslog server must be operating under the specified server IP address. The level of the syslog to be transferred is to be defined by the user. Syslog messages at the user-defined level and higher levels are transferred.

Diagnostic

Syslog Transmission Setting

Enable/Disable	Server IP	Protocol	Port No.(default:514)	Log Level	Set
Disable ▾	<input type="text"/>	UDP ▾	514	ERROR ▾	<input type="button" value="Set"/>

- 1** Select [Enable] from [Enable/Disable].
- 2** Enter the IP address of the external syslog server.
- 3** Select the protocol used for the syslog server to receive syslog.
- 4** Select the port number used for the syslog server to receive syslog.

5 Select a level of the log to be transferred in [Log Level].

Log level	Description
EMERGENCY	State that may cause system failure
ALERT	Error to be handled urgently
CRITICAL	Fatal error
ERROR	General error
WARNING	Warning
NOTICE	Notice
INFORMATION	Information
DEBUG	Debugging information

6 Click on the [Set] button.




5.5.6.2 Checking the connection status by Ping

Specify an IP address or a specific domain for a destination of ping packet.

Notes

- Do not display any other page or shut down the Web browser while the ping result is displayed in the page.
- An unexpected communication charge may occur for packet transmission/reception.



1 Enter the IP address of the transmission source in [Source].

Item	Description
Internal IP address of BIM	For checking the connection between internal units Fixed value: 192.168.1.2
External IP address of BIM (IP address of JRC LAN BIM)	For checking the connection with JRC LAN connection equipment Setting at the factory delivery: 192.168.60.152

2 Enter an IP address of the transmission destination in [Destination].

3 Enter a packet length (1-1472) in [Packet Length].

4 Enter the number of transmissions (1-50) in [Total Transmissions].

5 Click on the [Start] button.

Hint

To cancel ping transmission, click on the [Stop] button.

The communication result is displayed in [Result].

```
Result:
40 bytes from 192.168.60.153: seq=0 ttl=64 time=3.873 ms
40 bytes from 192.168.60.153: seq=1 ttl=64 time=4.190 ms
40 bytes from 192.168.60.153: seq=2 ttl=64 time=3.482 ms
40 bytes from 192.168.60.153: seq=3 ttl=64 time=3.124 ms
--- 192.168.60.153 ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max = 3.124/3.667/4.190 ms
```

5.5.6.3 Setting GPS Auto Cold Start

Set to perform the restoration and self-diagnosis of the built-in GPS.

GPS Auto Cold Start

Enable

1 Select [Enable] from the combo box.

2 Click on the [Set] button to save/apply the settings.

5.5.7 Rebooting the system ([Tools] – [Reboot])

Display procedure

Select [Tools] - [Reboot] in the navigation area.

Function outline


Reboot JUE-60GX system.

Screen example




5.5.7.1 Rebooting procedure

- 1 Click on the [Reboot] button.



- 2 Click on the [Yes] button.



Rebooting JUE-60GX is started.

5.5.8 Deleting alarmpacks/resetting to the factory default state ([Others] - [Factory Default])

Display procedure

Select [Others] - [Factory Default] in the navigation area.

Function outline

Delete all the alarmpacks or reset the equipment to the factory default state.

Note

After deletion/reset execution, the setting data cannot be restored.

Screen example




5.5.8.1 Deleting alarmpacks

- 1 Select [Terminal Logs] from the combo box.
- 2 Click on the [Return to Default] button.



- 3 Click on the [Yes] button.



Automatic reboot is performed , all of the alarm pack , event log , AC monitoring logs will be deleted.

5.5.8.2 Resetting to the factory default state

For resetting to the factory default state, refer to “Appendix C”.

5.5.9 Setting JRC LAN ([Others] - [JRC LAN])

Display procedure

Select [Others] - [JRC LAN] in the navigation area.

Function outline

Set the JUE-60GX network.

The EXT LAN Type item at the time of GX LAN selection , you can use the second unit of the NSD.

The EXT LAN Type item at the time of JRC LAN selection, by setting the IP addresses of BIM and AIM in the IP address in JRC LAN, the remote maintenance and status monitor functions that can be provided by VDR and INM-C of JRC become available.

Screen example

JRC LAN

JRC LAN Setting

(1)	EXT LAN	Type	GX LAN	*
(2)		Local VLAN ID	2	*
(3)	AIM	IP	192.168.60.153	
(4)	BIM	IP	192.168.60.152	
(5)	AIM/BIM	Subnet Mask	255.255.255.0/24	
(6)	GPS	IP	239.0.0.1	*
(7)	Gyro	IP	239.0.0.128	*
(8)	GPS/Gyro	Port	5101	*
(9)	RMS	IP	239.0.80.5	*
		Port	6001	*

Set

* : reboot required

Copyright©2014 Japan Radio Co., Ltd. All Rights Reserved.

JRC LAN

JRC LAN Setting

EXT LAN	Type	JRC LAN	*
	Local VLAN ID	2	*
AIM	IP	192.168.60.153	
BIM	IP	192.168.60.152	
AIM/BIM	Subnet Mask	255.255.255.0/24	
GPS	IP	239.0.0.1	*
Gyro	IP	239.0.0.128	*
GPS/Gyro	Port	5101	*
RMS	IP	239.0.80.5	*
	Port	6001	*

Set

* : reboot required

Copyright©2014 Japan Radio Co., Ltd. All Rights Reserved.

The setting procedure is as follows.

1 Set the following items.

No.	Item	Description
(1)	EXT LAN Type	JRC LAN connection or , choose whether to perform a second unit of NSD connection . Note To reflect the setting change, the equipment must be restarted.
(2)	Local VLAN ID	Set the VLAN ID at the time of JRC LAN connection . Note To reflect the setting change, the equipment must be restarted.
(3)	AIM IP	Set the IP address of AIM that can access JRC LAN.
(4)	BIM IP	Set the IP address of BIM that can access JRC LAN.
(5)	AIM/BIM Subnet Mask	Set a subnet mask of AIM/BIM. For the details, refer to “Net mask of AIM/BIM JRC IP”.
(6)	GPS IP	Set a multicast address for receiving signals from external GPS through LAN. Note To reflect the setting change, the equipment must be restarted.
(7)	Gyro IP	Set a multicast address for receiving GYRO signals through LAN. Note To reflect the setting change, the equipment must be restarted.
(8)	GPS/Gyro Port	Set the port number that waits for external GPS and gyro signals. Note To reflect the setting change, the equipment must be restarted.
(9)	RMS IP RMS Port	Set the IP address and port number (0 to 65535) of VDR or INM-C that is used by the remote maintenance system. Note To reflect the setting change, the equipment must be restarted.

Net masks of AIM/BIM JRC IP

No.	Item	Description	No.	Item	Description
1	0.0.0.0/0	Prefix 0 bit	18	255.255.128.0/17	Prefix 17 bit
2	128.0.0.0/1	Prefix 1 bit	19	255.255.192.0/18	Prefix 18 bit
3	192.0.0.0/2	Prefix 2 bit	20	255.255.224.0/19	Prefix 19 bit
4	224.0.0.0/3	Prefix 3 bit	21	255.255.240.0/20	Prefix 20 bit
5	240.0.0.0/4	Prefix 4 bit	22	255.255.248.0/21	Prefix 21 bit
6	248.0.0.0/5	Prefix 5 bit	23	255.255.252.0/22	Prefix 22 bit
7	252.0.0.0/6	Prefix 6 bit	24	255.255.254.0/23	Prefix 23 bit
8	254.0.0.0/7	Prefix 7 bit	25	255.255.255.0/24	Prefix 24 bit
9	255.0.0.0/8	Prefix 8 bit	26	255.255.255.128/25	Prefix 25 bit

No.	Item	Description	No.	Item	Description
10	255.128.0.0/9	Prefix 9 bit	27	255.255.255.192/26	Prefix 26 bit
11	255.192.0.0/10	Prefix 10 bit	28	255.255.255.224/27	Prefix 27 bit
12	255.224.0.0/11	Prefix 11 bit	29	255.255.255.240/28	Prefix 28 bit
13	255.240.0.0/12	Prefix 12 bit	30	255.255.255.248/29	Prefix 29 bit
14	255.248.0.0/13	Prefix 13 bit	31	255.255.255.252/30	Prefix 30 bit
15	255.252.0.0/14	Prefix 14 bit	32	255.255.255.254/31	Prefix 31 bit
16	255.254.0.0/15	Prefix 15 bit	33	255.255.255.255/32	Prefix 32 bit
17	255.255.0.0/16	Prefix 16 bit	34	255.255.128.0/17	Prefix 17 bit

2 After setting, save/apply the setting by clicking on the [Set] button.

Section 6 Maintenance

The life of the JUE-60GX depends on how well the equipment is maintained. Check the following items from time to time to ensure the best performance of your JUE-60GX.

- 1) Keep the input voltage within the specified range (90 VAC to 264 VAC).
- 2) Record the BIM current, BUC transmit power and AIM receiving level once at the normal condition. During the operation, compare level with the recorded normal values. This deed helps you to remove a fault before it develops into a serious one.

Daily maintenance

The following table shows daily maintenance with general tools.

 <h1 style="margin: 0;">WARNING</h1>	
	<p>Do not troubleshoot or repair the internal equipment of the JUE-60GX by yourself.</p> <p>Any electrical work by any person other than our trained maintenance staff may cause fire or abnormal operation of this equipment or electrical shock for you. This equipment meets the technical standard of the Ministry of Internal affairs and Communications.</p>
	<p>Do not adjust the internal circuit without a calibrated measuring instrument or exchange the parts because the internal circuit has been adjusted finely to specifications. If the equipment works abnormally, please contact the purchasing dealer.</p>

No.	Item	Maintenance
1	Cleaning	Clean the panel, switch, top cover, and the button cover with a soft cloth.
2	Fastening	Fasten the loose screw, nut, switch, and the connector.
3	Cleaning	Vacuum the dust of panel by cleaner at fixed intervals.

NOTE
Please send Installation Report (prepared by your agency) to JRC office to enable your warranty.



Section 7 After-sales service

When ordering repair

When a fault has been detected, refer to the “Appendix E”. If it is not improved, turn OFF and ON the power switch of the equipment to reboot. Still it persists, stop operation and contact the purchasing dealer.

During the guarantee term;

JRC will repair the equipment or exchange any parts proven to be malfunctioning under normal use. The user is requested to have operated the equipment as instructed in the instruction manual.

In the following cases, guarantee service is not accepted.

- Product Registration to JRC has not been made immediately after the JUE-60GX was commissioned. Product Registration to JRC is made by accessing to “<http://www.registration.msd.jp/msdroot/GX/FX/Page/TopMenu.aspx>” or sending Installation Report (prepared by agency) or Product Registration Sheet (attached on the last page of this manual) to JRC.
- The equipment has been subjected to accident, abuse, or misuse, shipping damage, alternations, incorrect and/or non-authorized service.
- The trouble, failure, malfunctioning and whatever is due to Act of God, fire, flood, explosion, accident, strikes, labor troubles or other industrial disputes, war (declared or undeclared), armed conflict, civil disturbance, embargoes, blockades, legal restrictions, riots, insurrections or any other cause beyond the control of JRC and the purchaser.

Service out of the guarantee term;

If the function is recoverable by a repair, JRC will arrange a charged service on customer’s demand.

To request a guarantee or non-guarantee service, please inform us of;

- Ship’s name, model name, date of manufacture, serial number.
- How trouble arose. Go into details as much as possible.
- Name of the office, organization etc. of the vessel, the contact place and the telephone/fax number.

Recommendation of professional maintenance

The performance of the set may degrade due to the aging of parts and so on, although the rate depends on how the equipment is used.

Maintenance by professional service engineer other than daily check by ship’s crew is recommended.

For this professional maintenance, please contact the purchasing dealer. This is a charged service.

Disposal of the JUE-60GX

Follow the rule of the pertinent local government when you abandon the JUE-60GX (ADE).


For details, contact the dealer, our service office (Refer to the list of offices at the end of the volume) or a concerned local government.

Section 8 Specification

1. Inmarsat GX equipment type		Category 1 Class 60	
2. Frequency	Transmit	29.0 to 30.0 GHz	
	Receive	19.2 to 20.2 GHz	
3. Maximum E.I.R.P		+49.0 dBW	
4. G/T (reception capability)		15 dBK	
5. Modulation		BPSK, QPSK, 8PSK	
6. Antenna	Size and type	φ65 cm Parabolic antenna	
	Polarization	Transmit: Right-hand circular polarization (RHCP) Receive: Left-hand circular polarization (LHCP)	
7. Power supply	Power supply voltage	90 VAC to 264 VAC	
	Power consumption	Up to 300 W	
8. External dimensions	ADE	φ842 mm x 923 mm (height)	
	BDE	430 mm x 88 mm x 469 mm (width/height/depth)	
9. Weight	ADE	Approx. 46 kg	
	BDE	Approx. 6.5 kg	
10. Environmental conditions			
1) Operating temperature	ADE	-25°C to +55°C	
	BDE	-15°C to +55°C	
2) Relative humidity		+40°C, 93%	
3) Vibration		Conforms to IEC 60945 4th edition.	
4) Ship's motion	Motion	Amplitude	Period
	Roll	+25°	6 s
	Pitch	+15°	6 s
	Yaw	+8°	10 s
	Turning Rate	+10°/s	
5) Solar Radiation (ADE)		670 watts/m ²	
6) IP rating	ADE	IP56 equivalent	
	BDE	IP22 equivalent	
7) Compass safety distance	ADE	1.5 m	
	BDE	1.2 m	
11. Elevation angle control range		-20 to 115 degrees	
12. Bearing angle control range		360 degrees (rewind-less)	
13. Interface		ETHERNET 2-ports: IEEE802.3 100Mbps GPS/GYRO: NMEA	


Appendix A Web Interface Menu Tree

A.1 Menu for JUE-60GX GUEST users



APP A

A.2 JUE-60GX ADMIN users



Appendix B Software Upgrading Procedure

Notes

- Although user settings will not be changed by software upgrading, it is recommended to backup the settings in advance.
- Do not connect a router or any other equipment. Connect PC directly to the MGMT LAN port of JUE-60GX.

Upgrade the software of this equipment using the following procedure.

Downloading the latest software of JUE-60GX

Check if the latest software has been uploaded on the Web site through the PC that is connected to the Internet. When the latest software has been uploaded, download the software.

Refer to “Appendix B.1” for the downloading procedure.



Upgrading the software from the Web interface

Directly connect PC to the JRC LAN port of JUE-60GX with an Ethernet cable, start the Web interface of JUE-60GX, and execute the upgrading.

For the upgrading procedure, refer to “Appendix B.2”.



Checking the software version

Check the software version to verify if the software of this equipment has been upgraded normally.

For the checking procedure, refer to “Appendix B.3”.

B.1 Downloading the latest software

The latest software of JUE-60GX is uploaded to the Inmarsat homepage.

1 Access the following URL.

<http://www.inmarsat.com/support/global-xpress-gx-firmware/>



Manufacturer	Terminal(s)	Version	Size	Download
Paradigm	Connect 70	1.3.1.12	41.9 MB	link
	Connect 100	1.3.1.12	41.9 MB	link
	Connect 100T	1.3.1.12	41.9 MB	link
	Connect 180	1.3.1.12	41.9 MB	link
Cobham	Explorer 3075 GX	1.55	9.3 MB	link
	Explorer 5075 GX	1.55	9.3 MB	link
	Explorer 7100 GX	1.55	9.3 MB	link
JRC	JUE-60GX	0.0.1.0	2.2 MB	link
Intellian	GX60	1.05	593 kb	link
	GX100	1.06	597 kb	link
	GX100PM	1.01	597 kb	link

Contact us
Email us with your enquiry

Partner search
Find a service provider

Subscribe
Stay up to date with news and information from Inmarsat

Support
[IsatPhone 2 support](#)
[Search support](#)
[FAQ](#)

2 Download the software.


If the version of the software that can be downloaded from the homepage is more current than your JUE-60GX software version, the software version can be checked by selecting [Logs] - [Alarmpack] of the Web interface. (Refer to "Appendix B.3".)

B.2 Upgrading software

Notes

- Do not turn off the power of the PC nor JUE-60GX during software transfer or upgrading.
- It may take 3 minutes or more for transfer or upgrading of application software.


- 1 Select [Tools] - [Software Upgrade] in the navigation area.
- 2 Click on the [Browse...] button of [Upgrade File].




APP B

The "Upload file" dialog is displayed.

- 3 Select a file of the upgrade software and click on the [Open] button.



4 Click on the [Upgrade Start] button.



Software upgrading starts.

Wait until software upgrading is completed and the result is displayed.




Notes

- Do not operate the Web interface until the result is displayed on the screen.
- Upgrading may take 3 minutes or more.
- If the result is not displayed even after 12 minutes have elapsed or more, perform the operation again.

When “Success” is displayed as the result on the screen after completion of upgrading, the upgrading has been completed.

If any message other than “Success” is displayed as the result, the upgrading failed. Refer to “Appendix B.2.1”.



5 Restart the equipment.

6 Check the software version by referencing “Appendix B.3”.


B.2.1 Failing software upgrading

When software upgrading fails, the error code and reason (cause of the error) are displayed on the screen.

Check the error contents and perform upgrading again.

If software upgrading fails continuously, stop the operation and examine the cause. When the equipment no longer operates normally, switch the equipment setting to the sub mode by referencing “Appendix B.2.2”.

Error display example



The screenshot shows a software upgrading interface. At the top, there is a section titled "Upgrade File" with a "Browse..." button and the file name "JUE-60GX_PKG_9999.jrc". Below this, the "Result:" is "Error". The "File:" is "JUE-60GX_PKG_9999.jrc". A red-bordered box highlights the error details: "Error code: 115 : BIM Not Npf." and "Reason: BIM : error on script(firmtool.sh)". At the bottom, there is an "Upgrade Start" button and a red text instruction: "Please reboot the system."

Main error codes

Error code	Assumed factor
40, 41, 50, 51, 102, 302	Duplicate execution of upgrading
115, 116, 117, 315, 316	Upgrade file specification error
206, 406	Falsification of upgrade file name
112, 127, 312, 327	Corruption of upgrade file
122, 322	Execution of the upgrading of the same version as the software that is currently active
123, 323	Execution of upgrade that causes the version of the software in normal mode and the version of the software in rollback mode to become identical.
128, 328	Rollback software upgrading in rollback mode
130-138, 330-338	Upgrading of the version that does not support the hardware
Others	Occurrence of internal error

Main error causes

Reason	Description
Transfer to BIM failed	Failure in transfer of the upgrade file to BIM
Under Upgrading	Duplicate upgrade execution
BIM : error on script (firmtool.sh)	Error occurred in BIM Error section: Script
BIM : error on task (upgrade)	Error occurred in BIM Error section: Upgrading thread
BIM : error on task (spv)	Error occurred in BIM Error section: SPV thread
BIM : error on task (web)	Error occurred in BIM Error section: WEB thread
BIM : error on task (snmp)	Error occurred in BIM Error section: SNMP thread
BIM : error on file copy to AIM	Error occurred in BIM Error section: File transfer to AIM
AIM : error on script (firmtool.sh)	Error occurred in AIM Error section: Script
AIM : error on task (upgrade)	Error occurred in AIM Error section: Upgrade thread
AIM : error on task (spv)	Error occurred in AIM Error section: SPV thread
Undefined	Error occurred due to the cause other than above


B.2.2 Software rollback function

If the equipment no longer operates normally due to some cause as a result of execution of software upgrading, the equipment can be started with the software under the factory default version by switching the equipment setting to the sub mode.

Note

The sub mode is a temporary measure. It is recommended to switch the rollback setting to the normal mode (main mode) after examining the cause of the upgrade failure.


- 1 Select [Tools] - [Software Upgrade] in the navigation area.
- 2 Select [Sub] from [Rollback] and click on the [Set] button.



The screenshot shows the 'Software Upgrade' interface. Under the 'Rollback' section, a dropdown menu is set to 'Sub' and the 'Set' button is highlighted with a black box. The 'Upgrade File' section above it shows a 'Browse...' button, 'No file selected.', and an 'Upgrade Start' button. A message below the 'Upgrade Start' button reads: 'Please select upgrade file and push Upgrade Start button.'

APP B

The software that is used is switched.



The screenshot shows the 'Software Upgrade' interface. Under the 'Rollback' section, a message box is highlighted with a black box, containing the text: 'Rollback status has changed. Please reboot the system.' The 'Sub' dropdown and 'Set' button are still visible above the message.

- 3 Restart the equipment.

Subsequently, JUE-60GX operates with the software under the factory default version.

Switching the equipment setting to the normal mode (main mode)

Select [Main] in [Rollback] and restart the equipment.

B.3 Checking the software version

Restart the equipment, check whether the software has been upgraded correctly by using the following procedure.

- 1 Display the alarmpack by selecting [Logs] - [Alarmpack] in the Web menu system.
- 2 Check the display of [Main App] of AIM and BIM.

Alarmpack

File This takes 1 minute.

Terminal Information

		No.	MAC		
JRC	ADE	GV	00:00:27: [REDACTED]		
	BDE	GV	00:00:27: [REDACTED]		
Common		ACU Vendor	RF Terminal Type		
		JRC	1004		
Terminal Identification	LNB	Part No.	Serial No.		
		E0001660-0	A00445A43		
	Manufacturer ID	Functional ID			
	10	?			
		Serial No.	Type		
AIM		A00017A47	version_1		
BIM		A00018A47	version_1		
Maintenance No.	Boot		Main RFS	Main App	Safe
	AIM		3046	3046	3046
	BIM		3046	3046	3046
	Boot		Main	System	
Antenna		0.3	00.54	00.03	

If the same number as “xxxx” of the software file, [JUE-60GX_PKG_xxxx.jrc], is displayed, the software has been upgraded correctly.

Appendix C Initializing the settings to the factory default state

The settings of JUE-60GX can be reset to the factory default state.

The following settings are reset.


- AIM/BIM setting
- Alarmpack
- Event log
- Antenna monitor log

- 1 Select [Others] - [Factory Default] in the navigation area.
- 2 Select [Terminal Logs] and click on the [Return to Default] button.

APP C



- 3 Click on the [Yes] button.



JUE-60GX starts in the factory default setting when the machine is Automatic restarted.



Appendix D List of Initial Values (Version 0100)

Item	Initial value	Set from the Web menu system	
		Section title/number	Setting name
JUE-60GX operation starting day/month/year	01/JAN/2013	5.5.1	Delivery Date
BOW correction value	0		FWD from Bow
External gyro input	NMEA(4.8k)		GYRO Input
External GPS input	Disable		GPS Input
VDR output	LAN		VDR Output
BDE LED On/Off	ON		Panel LED
BDE Ethernet LED On/Off	ON		Ethernet LED
Transmission prohibition area/blocking area	All Disable	5.5.2	Enable/Disable
Transmission prohibition area application setting	None checked		Tx Forbidden
Maximum elevation of the area	All empty		EL Max
Maximum elevation of the area	All empty		EL Min
Starting azimuth of the area	All empty		AZ Begin
Ending azimuth of the area	All empty	AZ End	
Rollback setting	Main	B.2.2	Rollback
Syslog transfer/no transfer	Disable	5.5.6	Enable/Disable
IP address of the log transfer server	No Data (Unregistered)		Server IP
Log transfer protocol	UDP		Protocol
Log transfer port number	514		Port Num.
Log collection level	ERR		Log Level
Extended LAN connection type setting	GX LAN	5.5.9	EXT LAN Type
RMS VLAN ID	2		Local VLAN ID
AIM IP address	192.168.60.153		AIM IP
BIM IP address	192.168.60.152		BIM IP
AIM/BIM subnet mask	255.255.255.0/24		AIM/BIM Subnet Mask
GPS IP address	239.0.0.1		GPS IP
GYRO IP address	239.0.0.128		Gyro IP
GPS/gyro port number	5101		GPS/Gyro Port
RMS message transmission IP address	192.168.60.3		RMS IP
RMS message transmission port number	6001		RMS Port

APP D



Appendix E Troubleshooting & FAQ

If a problem occurs, perform operation according to the FAQ items

If the problem cannot be solved, reboot the device.

If an error is still detected, collect device logs, and then stop using the device, and contact your distributor with the collected logs (refer to Section 7).

Even if the device is rebooted, saved data will not be deleted.

E.1 Power on, start and termination

Problem	Probable cause	Confirmation item
The BDE is not powered on. No BDE LED lights.	The power cable is disconnected.	Extract and then insert the power cable.
	The breaker in distribution board is OFF.	Confirm that the breaker in the distribution board is ON.
	The BDE power switch is OFF.	Turn the BDE power switch to OFF again, and then turn it to ON.
	The fuse is blown out.	If the problem cannot be solved according to the above confirmation items, replace the fuse with spare parts.
After power on, sweep takes place when STS1 to STS4 LEDs light in red.	Software is being modified.	Wait about 10 minutes. Since AIM and BIM software versions are different, AIM is upgraded to BIM software version.
STS1 to STS4 LEDs light in green and sweeping.	Automatic update is in process.	Wait about 3 minutes. AIM and BIM are upgraded.
STS1 to STS4 LEDs light in red blinking faster at once	Excessive vibration and impact on ADE.	Refer to "Appendix E.6 Problem related to vibration and impact"
The READY LED continues to light in red.	The device is started in Safe mode.	Turn the BDE power switch to OFF, and then turn it to ON.
READY LED blinks in red.	A hardware error is detected.	Confirm the LED of STS1 to STS4 LEDs lighting in red, and refer to "Appendix E.4 Corrective action when alarm occurs."
ANT LED lighted in red.	Satellite search failed.	Turn the BDE power switch to OFF, and then turn it to ON.

Problem	Probable cause	Confirmation item
ANT LED blinked in red.	The antenna points to the direction of transmission-prohibited area.	Confirm the antenna pointing direction through the Web interface. If the antenna points to the transmission-prohibited area, wait until the ship moves and the antenna pointing direction is outside the transmission-prohibited area.
	The antenna points to the blocking area direction.	Confirm the antenna pointing direction through the Web interface. If the antenna points to the blocking area, wait until the ship moves and a shield disappears between the antenna and the satellite.
STS1 LED lighted in red.	In BIM, an alarm is detected.	Refer to "Appendix E.4. Corrective action when alarm occurs."
STS2 LED lighted in red.	In AIM, an alarm is detected.	
STS3 LED lighted in red.	In CM, an alarm is detected.	
STS4 LED lighted in red.	In BUC, an alarm is detected.	
BDE is not powered off. READY LED continues to blink in red.	BDE is in process of termination.	BDE termination process takes about 20 seconds on average. However, BDE is not powered off even after one minute has elapsed, confirm that the BDE power switch is off, and extract and insert the power cable.
	The power was turned on during BDE termination process.	Turn off the power again, and wait for a while. BDE termination process takes about 20 seconds on average to up to one (1) minute.

Note

The motor driving noise from ADE is not trouble. The mechanical trouble of ADE is confirmable by "E.4 Corrective action when alarm occurs".

E.2 Satellite acquisition, tracking, communication

Question description	Probable cause	Confirmation item
The satellite is not acquired. ANT LED does not light in green.	The GPS signal is not received.	Wait until GPS changes from invalid to valid on the Web interface “Status” screen (refer to “5.4.1”).
	Blocking is occurring.	Confirm whether there is a shield between the antenna and the satellite. If there is a shield, wait until the ship moves and the shield disappears between the antenna and the satellite.
	Rain attenuation is occurring.	Confirm the weather around the ship. If rain falls heavily, wait until the weather becomes clear.
	If the problem cannot be solved according to the above items, turn off the power to BDE, and then turn it on to reboot BDE.	
IN_NETWORK state is not entered. NET LED does not light in green.	Blocking is occurring.	Confirm whether there is a shield between the antenna and the satellite. If there is a shield, wait until the ship moves and the shield disappears between the antenna and the satellite.
	Rain attenuation is occurring.	Confirm the weather around the ship. If rain falls heavily, wait until the weather becomes clear.
	The antenna points to the direction of the transmission-prohibited area.	Confirm the antenna pointing direction through the Web interface. If the antenna points to the transmission-prohibited area, wait until the ship moves and the antenna pointing direction is outside the transmission-prohibited area.
	The ship is outside the satellite coverage area.	Confirm whether the ship is within the satellite coverage area. If it is outside the coverage area, use the device after it enters the coverage area.
Even in IN_NETWORK state, communication service cannot be used. Although NET LED lights in green, communication service cannot be used.	Refer to the document about troubleshooting attached to NSD.	

Question description	Probable cause	Confirmation item
Reception signal intensity is weak.	Blocking is occurring.	Confirm whether there is a shield between the antenna and the satellite. If there is a shield, wait until the ship moves and the shield disappears between the antenna and the satellite.
	Rain attenuation is occurring.	Confirm the weather around the ship. If rain falls heavily, wait until the weather becomes clear.
Reception signal intensity changes.	Frequency switch occurred.	The reception signal intensity may change due to GSC and DVB-S2 frequency switch. This symptom is normal operation.
	Handover occurred.	The reception signal intensity may change due to spot beam hand handover (switch). This symptom is normal operation.
	Blocking is occurring.	Confirm whether there is shield between the antenna and the satellite. If there is a shield, wait until the ship moves and the shield disappears between the antenna and the satellite.
	Rain attenuation is occurring.	Confirm the weather around the ship. If rain falls heavily, wait until the weather becomes clear.
The satellite tracking is unstable. STS1 to STS4 LEDs light in red blinking faster occasionally	Excessive vibration and impact on ADE.	Refer to "Appendix E.6 Problem related to vibration and impact"

E.3 Web interface

Question description	Probable cause	Confirmation item
The Web interface cannot be displayed.	The Ethernet cable is not connected to JRC LAN.	Confirm that the PC is securely connected to the BDE using the Ethernet cable. If link between the BDE and PC is established, the Ether port Link LED lights.
	TCP/IP is not set.	Confirm that network IP, subnet mask and default gateway set in PC match those set in the BDE.
	URL is not correct.	Confirm whether the IP address entered in the URL box is the IP address and port number of the BDE. Default URL of Web interface: http://192.168.1.2:9443
	PC local area connection is disabled (Windows 2000 or later).	Confirm that local area connection is set to "enable" in the property specification of local area connection.
	PC local area connection is bridge connection.	Use the mouse to right-click on the local area connection icon to delete bridge.
When the button is clicked on the JRC Web interface menu screen, an error message appears.	The Web browser version is not supported.	JUE-60GX supports Mozilla Firefox 23 or later version officially. It can also be used under the higher-order version or compatible system.

E.4 Corrective action when alarm occurs

If an alarm relevant to the items listed in the following table occurs, perform operation according to the confirmation items. If the alarm cannot still be corrected, contact your distributor.

Unit	Alarm name	Outline	Probable cause	Confirmation item
STS1 LED BDE	[COMM_ADE]	ADE communication error	Communication error due to poor contact	Confirm the coaxial cable connection.
			Unit is reset.	If this alarm is frequently displayed, the coaxial cable may be disconnected or the unit may be faulty.
	[COMM_ANT]	Antenna Control connection error	Communication error due to poor contact	Confirm the coaxial cable connection.
	[EXT_GPS]	External GPS signal reception error	External GPS stopped.	Although external GPS signal input is set, position information is not input from external GPS. Confirm that GPS is powered on.
	[COMM_GYRO]	GYRO signal reception error	GYRO stopped.	Although GYRO signal input is set, HEADING information is not input from the GYRO interface. Confirm that GYRO is powered on.
	[UGD_ERR]	Software upgrade error	File specification error Unit is reset.	Confirm that the correct file has been selected for software upgrade, and then execute software upgrade again. If software upgrade fails several times, turn off the power to the main unit, and then turn it on to reboot the main unit.

Unit	Alarm name	Outline	Probable cause	Confirmation item
STS2 LED AIM LED	[GPS]	Internal GPS signal reception error	Blocking occurred.	The built-in GPS cannot determine position information. Confirm whether blocking state is entered. If this alarm is frequently displayed even after blocking is cleared, the unit may be faulty.
	[IMPACT]	Excessive impact on ADE	A strong impact can be applied to ADE for a long time.	Since a strong impact is applied to ADE for a long time, mechanical failure possibility is increasing. Check the ADE installation by referring to "E.6 Problem related to vibration and impact " in this manual and "Appendix D Precautions for ADE equipment" and "2.2.2 Recommended prop example" in the installation manual.
ST3 LED CM	[COMM_CM]	CM communication error	Unit reboot due to automatic upgrade	Since CM is rebooted when it is automatically upgraded from SAS, a CM communication error temporarily occurs. If this alarm is displayed frequently or for an extended period of time, the unit may be faulty.
			Unit is reset.	
ST4 LED BUC	[COMM_BUC]	BUC communication error	Unit reboot due to automatic upgrade	Since BUC is rebooted when it is automatically upgraded from SAS, a BUC communication error temporarily occurs. If this alarm is displayed frequently or for an extended period of time, the unit may be faulty.
			Unit is reset.	
			Communication error due to poor contact	
	[LOUNLOCK]	Local oscillator unlock	Poor contact of coaxial cable for transmission	Confirm the connection of coaxial cable for transmission.

If the following alarms occur, turn off the power to the BDE, and then turn it on to reboot the main unit.

Unit	Alarm name	Outline
ST1 LED BIM	[CURR]	Current error (GPIO detection error)
	[CUR_THR]	Current value error
	[FAN_TMP]	BIM FAN temperature error
	[FAN_REV]	BIM FAN rotation error
	[UGD_ERR]	Upgrade error
	[COMM_ADE]	ADE communication error
	[EXT_GPS]	External GPS communication error
	[COMM_GYRO]	Gyro communication error
	[BIM_TEMP]	BIM temperature error
ST2 LED AIM	[MTR_U]	U-axis motor protection error
	[MTR_X]	X-axis motor protection error
	[MTR_EL]	EL-axis motor protection error
	[MTR_AZ]	AZ-axis motor protection error
	[AX_U]	U-axis sensor error
	[AX_X]	X-axis sensor error
	[AX_EL]	EL-axis sensor error
	[AX_AZ]	AZ-axis sensor error
	[LVL_X]	X-axis clinometer sensor error
	[LVL_Y]	Y-axis clinometer sensor error
	[RATE_X]	X-axis angular velocity sensor error
	[RATE_Y]	Y-axis angular velocity sensor error
	[RATE_Z]	Z-axis angular velocity sensor error
	[GPS]	Internal GPS reception error
	[TUNER]	TUNER error
	[AGC_VLT]	AGC Voltage error
	[COMM_ANT]	Antenna Control communication error
	[AIM_TEMP]	AIM temperature error
[VOLT]	AIM voltage value error	
ST3 LED CM	[COMM_CM]	CM communication error
ST4 LED BUC	[COMM_BUC]	BUC communication error
	[FAN]	FAN error
	[HIPWR]	High power
	[LOUNLOCK]	Local oscillator unlock
	[OVERTEMP]	BUC high temperature error

E.5 Problem related to communication service

Refer to the document on troubleshooting attached to NSD.

E.6 Problem related to vibration and impact


Overview

An Impact alarm function has been added from the V0018 software to notify excessive impact on ADE. When an excessive impact is detected, LED blinks real time for notification. When the accumulated time is exceeded, alarm records. The default thresholds for each are as follows.

<default value>

impact gravity acceleration threshold (G-th): 2[G]

accumulated time threshold (ACC-th): 1440[min]=24[hour]




If an Impact alarm occurs

Please check the installation requirements of ADE then contact JRC and Inmarsat.

For checking the equipment conditions of ADE, refer to "Appendix D, Precautions for ADE equipment" and "2.2.2 Recommended prop example" in the equipment manual.

E.6.1 LED blinking indication

Two LED lighting modes, normal mode and caution mode, are available. When an excessive impact is detected, it switches to caution mode and indicates in real time by blinking faster at once the all LED of STS1-4.




Please note the caution mode behavior is different before and after the accumulated-time-threshold (ACC-th) is exceeded.

Before exceeding the ACC-th

- The LED lights in caution mode when it exceeds G-th and returns to normal mode when it falls below G-th.
- Impact alarm is not recorded

After exceeding the ACC-th

- Impact alarm is recorded only once
- The LED will continue to light in caution mode even if it falls below G-th.
- Impact alarm continues until the accumulative counter is cleared



E.6.2 Alarm recording

If the accumulative impact time exceeds the threshold, an IMPACT alarm will be occurred and recorded in the Alarmpack.

The screenshot shows the JRC Global Xpress JUE-60GX dashboard. The left sidebar contains navigation options: GUEST, Dashboard, Status, Logs, ADMIN, Settings, Tools, Others, SERVICE, and Service Setting. The main content area is titled 'Status' and includes the following sections:

- Unit Status:** Antenna Cont. (0x20 Idle), AIM (3: Core Module connected), BIM (3: Core Module connected), BUC (1: Connected), Int-GPS (Valid (GGA, RMC)), Ext-GPS (Disable), GYRO (Received heading).
- Satellite:** Longitude (62° 36' 00" E), Sat-EL (2.9), Sat-AZ (261.3).
- Antenna:** Heading [deg] (0.0), EL [deg] (3.5), Bearing [deg] (261.3), X [deg] (1.2).
- GPS:** Time (06:11:43 07/APR/2021), Latitude (36° 36' 31" N), Longitude (138° 10' 49" E).
- Alarm:** Alarm ([AIM]), BIM (---), AIM ([IMPACT]), CM (---), BUC (---).

The accumulative impact time (unit: minutes) is displayed in Impact-Acc in the ALM-AIM area of [Logs]-[Alarmpack].

The transition value of the Impact-acc are recorded in alarmpack.csv, eventlog.csv, life_time_log.txt included in alarmpack.

Current	09:56:52 07/APR/2021		All	AIM	BIM	CM	BUC
AIM-ALM [IMPACT]							
SAT-Long	179.6	SAT-AZ	124.2	SAT-EL	29.5		
Hunt-Freq	1890.000	Hunt-BW	31.999				
Search-Sts	0x20	Search-Mode	GYRO	Search-Opt	00000000	MissPoint	1
ANT-BR	117.9	ANT-EL	28.1	ANT-X	1.8		
RSSI-Gsc	0	RSSI-Dvbs2	0				
Int-GPS-Sts	Valid	Int-GPS-Sat	9	Int-GPS-Hd	104.5		
VibX-Max	2.0	VibX-Ave	0.3	VibY-Max	1.0	VibY-Ave	0.0
VibZ-Max	1.0	VibZ-Ave	0.7	Rol-Max	1.4	Rol-Ave	0.2
Pit-Max	2.1	Pit-Ave	0.4	Impact-Acc	1440		
AIM-Tmp	28.0	Eth-Link	DOWN	Voltage-Min	47.3	Voltage-Ave	47.5
Keyline	Off	Wlan-Ant	Ant-1				
Wlan-Tx	150	Wlan-Pwr	-63	Wlan-Ch	2442	Wlan-SSID	jrc

E.6.3 Disable LED indication

Select [Settings] – [Terminal] in the navigation area.

Change the [Impact Indication] pull-down menu in Terminal Setting from [On] to [Off].

After setting, save/apply the setting by clicking on the [Set] button.

Terminal

Terminal Setting

Delivery Date	1 / JAN / 2013
FWD from Bow	0.0 Auto Calc. This takes 1 minute.
GYRO Input	NMEA(4.8k) *
GPS Input	Disable *
VDR Output	LAN *
Panel LED	On
Ethernet LED	On
Impact Indication	On

Set

* : reboot required

APP E

E.6.4 Clear Impact alarm

Select [Settings] – [Terminal] in the navigation area.

When press the [Clear] button on the Impact Accumulator, the counter returns to 0 and the alarm is cleared.

Impact Accumulator

Impact Accumulator Time	Clear
-------------------------	-------


Note

- Generally, do not run the clear operation until the cause of the alarm is resolved.

E.7 Other problem

Turn off the power to the BDE, and then turn it on to reboot the BDE.


Appendix F LED of BDE





APP F

F.1 BDE LED display sequence and display at the occurrence of abnormality

F.1.1 LED display sequence






F.1.2 LED display sequence at software upgrading



F.1.3 LED display sequence at vibration and impact





Appendix G Abbreviations and Glossary

A

ADE (Above Deck Equipment)

AIM (Antenna Interface Module)

* Antenna interface module used in GX system. One of the substrate compose ADE.

ANT (Antenna)

AOR (Atlantic Ocean Region)

AZ (AZimuth)

B

BDE (Below Deck Equipment)

BIM (Broadband Interface Module)

* Network interface module used in GX system. One of the substrate compose BDE.

BPS (Bit Per Second)

BOW

* The BOW correction is function to correct offset the angle error from the bow.

BR (BeaRing)

BUC (Block Up Converter)

C

COMM (Communication)

CPU (Central Processing Unit)

CM (Core Module)

* Modem circuit used in GX system. One of the substrate compose BDE.

D

DC (Direct Current)

E

EIRP (Effective Isotropically Radiated Power, a measure of transmitted power)

* One of the indexes that indicate transmission performance. Parameter that is determined by converting the strength of radio waves that are radiated in all the directions of the space from the transmission antenna to the isotropic radiation source.

EL (Elevation)

EXT (External)

F

FBB (Fleet Broadband)

G

GPS (Global Positioning System)

GX (Global Xpress)

* The 5th generation satellite communications system operated by Inmarsat.

H

HD (HeaDing)

HPA (High Power Amplifier)

I

INFO (Information)

INMARSAT (International Maritime Satellite Organization)

IOR (Indian Ocean Region)

L

LAN (Local Area Network)

LED (Light Emitting Diode)

LNB (Low Noise Block converter)

M

MAC address (Media Access Control Address)

MES (Mobile Earth Station)

N

NMEA (National Marine Electronics Association)

NOC (Network Operation Center)

NSD (Network Service Devise)

* Router device of GX and FB network.

O

Ocean region

* Ocean region that is covered by the INMARSAT satellite that allows MES (mobile earth station) to send and receive messages

OBC (Operational Backup Center)

OSC (Oscillator)

P

Packet

* Unit of data for transmitting communication data by dividing data into a certain size by attaching an address. By transmitting data by dividing into packets, the line can be used efficiently.

PC (Personal Computer)

POP (Post Office Protocol)

* Application-layer Internet standard protocol used by local e-mail clients to retrieve e-mail from a remote server over a TCP/IP connection

POR (Pacific Ocean Region)

Protocol

* Set of mutually determined conventions for communication performed by computers via the network

PWR (Power)

R

RAM (Random Access Memory)

* Electronic parts for temporarily saving data. RAM is used by connecting to CPU (Central Processing Unit) and data can be read from and written to RAM. Data is cleared when the power is turned off.

ROM (Read Only Memory)

RMS (Remote Maintenance System)

* JRC's original onboard equipment performance and functionality monitoring system using VDR as a server.

RSSI (Received Signal Strength Indicator)

RX (Receive/Receiver)

S

SAS (Satellite Access Station)

SCC (Satellite Control Center)

SCM (Standard Core Module)

* Modem circuit used in GX system. One of the substrate compose BDE.

STS (Status)

T

TCP (Transmission Control Protocol)

TX (Transmit/ Transmitter)

U

UTC (Universal Coordinated Time)

V

VoIP (Voice over Internet Protocol)

VDR (Voyage Data Recorder)



Appendix H JRC Network

If your JUE-60GX has problems in operation, please contact the dealer you purchased it from.
For assistance in finding a Service Center, please access one of the following web sites.

JRC web site

JRC Japan	http://www.jrc.co.jp
JRC Amsterdam	http://jrc.am/
JRC Seattle	http://jrc.am/





电器电子产品有害物资申明
日本无线株式会社

Declaration on hazardous substances
of Electrical and electronic Products
Japan Radio Company Limited

有害物质的名称及含量
(Names & Content of hazardous substances)

形式名(Type): JUE-60GX

名称(Name): INMARSAT Global Xpress GX Mobile Earth Station

部件名称 (Part name)	有害物质 (Hazardous Substances)					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
室外装置 (Above Deck Equipment)	○	○	○	○	○	○
室内装置 (Below Deck Equipment)	○	○	○	○	○	○
外部设备(Peripherals) · 电线类(Cables) · 手册/Documents)	○	○	○	○	○	○

本表格依据SJ/T 11364 的规定编制。
(This table is prepared in accordance with the provisions of SJ/T 11364.)

○: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 标准规定的限量要求以下。
(Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the requirement in GB/T 26572.)

×: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572 标准规定的限量要求。
(Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.)

APP I



アスベストは使用していません
Not use the asbestos

For further information, contact:

JRC *Japan Radio Co., Ltd.*

Since 1915

URL Head office : <http://www.jrc.co.jp/eng/>

Marine Service Department

1-7-32 Tatsumi, Koto-ku, Tokyo 135-0053, Japan

e-mail : tmsc@jrc.co.jp

One-call : +81-50-3786-9201

ISO 9001, ISO 14001 Certified